



Manual

Cordless hedge trimmer

Applies for:

Code	Model
102490	MAX-40C



40 V = 26"
Cut length

MAX-40C

CAUTION



Read this manual thoroughly
before using the tool.



Technical data	3
Power requirements	3
 General power tool safety warnings	4
 Safety warnings for the use of hedge trimmers	5
Parts	7
Preparation	8
Start up	9
Operation	10
Maintenance	11
Environment protection	11
Notes	12
Authorized service centers	13
Warranty policy	14

CAUTION

To gain the best performance of the tool, prolong the duty life, make the Warranty valid if necessary, and to avoid hazards of fatal injuries please read and understand this Manual before using the tool.

Keep this manual for future references.

The illustrations in this manual are for reference only. They might be different from the real tool.



MAX-40C

Code	•	102490
Description	•	Cordless hedge trimmer
Cut length	•	26"
Voltage	•	40 V ==
Cut capacity	•	1/2"
Blade	•	Double action
Distance between teeth	•	15/16"
Batteries	•	Ion-lithium 20 V == 4 Ah Charging time: 1 hour 20 minutes approximately
Charger	•	Input: Tension: 127 V ~ Frequency: 60 Hz Current: 2 A

The charger power cable has cable clamps type: Y

The construction class of the tool is: Class III

The construction class of the charger is: Reinforced insulation

WARNING Avoid the risk of electric shock or severe injury. When the power cable gets damaged it should only be replaced by the manufacturer or at a TRUPER® Authorized Service Center.

The build quality of the electric insulation is altered if spills or liquid gets into the tool while in use.


Do not expose to rain, liquids and/or dampness.

WARNING Before gaining access to the terminals all power sources should be disconnected.



Power requirements

WARNING Tools with double insulation are equipped with a polarized plug (one prong is wider than the other). This plug will only fit in the right way into a polarized outlet. If the plug cannot be introduced into the outlet, reverse the plug. If it still doesn't fit, call a qualified electrician to install for you a polarized outlet. Do not alter the plug in any way. Double insulation eliminates the need of both a grounded third power cord with three prongs or a grounded power connection.



WARNING When using an extension cable, verify the gauge is enough for the power that your product needs. A lower gauge cable will cause voltage drop in the line, resulting in power loss and overheating. The following table shows the right size to use depending on cable's length and the ampere capability shown in the tool's nameplate. When in doubt use the next higher gauge.

Amperes Capacity	Number of Conductors	Extension gauge from 6 ft to 49 ft	Extension gauge higher than 49 ft
from 0 A and up to 10 A		18 AWG(*)	16 AWG
from 10 A and up to 13 A		16 AWG	14 AWG
from 13 A and up to 15 A		14 AWG	12 AWG
from 15 A and up to 20 A	3 (one grounded)	8 AWG	6 AWG

* It is safe to use only if the extensions have a built-in artifact for over current protection.

AWG = American Wire Gauge. Reference: NMX-J-195-ANCE-2006

WARNING When operating power tools outdoors, use a  VOLTECK grounded extension cable labeled "For Outdoors Use". These extensions are especially designed for operating outdoors and reduce the risk of electric shock.





⚠ WARNING! Read carefully all safety warnings and instruction listed below. Failure to comply with any of these warnings may result in electric shock, fire and / or severe damage. **Save all warnings and instructions for future references.**

Work area

Keep your work area clean, and well lit.

Cluttered and dark areas may cause accidents.



Never use the tool in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.

Sparks generated by power tools may ignite the flammable material.



Keep children and bystanders at a safe distance while operating the tool.

Distractions may cause loss of control.

**Electrical Safety**

The tool plug must match the power outlet. Never modify the plug in any way. Do not use any adapter plugs with grounded power tools.

Modified plugs and different power outlets increase the risk of electric shock.



Avoid body contact with grounded surfaces, such as pipes, radiators, electric ranges and refrigerators.

The risk of electric shock increases if your body is grounded.

Do not expose the tool to rain or wet conditions.

Water entering into the tool increases the risk of electric shock.

Do not force the cord. Never use the cord to carry, lift or unplug the tool. Keep the cord away from heat, oil, sharp edges or moving parts.

Damaged or entangled cords increase the risk of electric shock.

When operating a tool outdoors, use an extension cord suitable for outdoor use.

Using an adequate outdoor extension cord reduces the risk of electric shock.

If operating the tool in a damp location cannot be avoided, use a ground fault circuit interrupter (GFCI) protected supply.

Using a GFCI reduces the risk of electric shock.

Personal safety

Stay alert, watch what you are doing and use common sense when operating a tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.

A moment of distraction while operating the tool may result in personal injury.

Use personal protective equipment. Always wear eye protection.

Protective equipment such as safety glasses, anti-dust mask, non-slip shoes, hard hats and hearing protection used in the right conditions significantly reduce personal injury.



Prevent unintentional starting up. Ensure the switch is in the "OFF" position before connecting into the power source and / or battery as well as when carrying the tool.

Transporting power tools with the finger on the switch or connecting power tools with the switch in the "ON" position may cause accidents.

Remove any wrench or vice before turning the power tool on.

Wrenches or vices left attached to rotating parts of the tool may result in personal injury.

Do not overreach. Keep proper footing and balance at all times.

This enables a better control on the tool during unexpected situations.

Dress properly. Do not wear loose clothing or jewelry. Keep hair, clothes and gloves away from the moving parts.

Loose clothes, jewelry or long hair may get caught in moving parts.



If you have dust extraction and recollection devices connected onto the tool, inspect their connections and use them correctly. Using these devices reduce dust-related risks.

Power Tools Use and Care

Do not force the tool. Use the adequate tool for your application.



The correct tool delivers a better and safer job at the rate for which it was designed.

Do not use the tool if the switch is not working properly.

Any power tool that cannot be turned ON or OFF is dangerous and should be repaired before operating.



Disconnect the tool from the power source and / or battery before making any adjustments, changing accessories or storing.

These measures reduce the risk of accidentally starting the tool.

Store tools out of the reach of children. Do not allow persons that are not familiar with the tool or its instructions to operate the tool.



Power tools are dangerous in the hands of untrained users.

The machine must not be used by children or persons with reduced physical, sensory or mental capacities; nor by persons with no experience or knowledge in its use, unless they are supervised by a person responsible for their safety or have received prior instructions on the use of the machine.

Children must be supervised to ensure that they do not play with the machine.

Service the tool. Check the mobile parts are not misaligned or stuck. There should not be broken parts or other conditions that may affect its operation. Repair any damage before using the tool.

Most accidents are caused due to poor maintenance to the tools.

**Keep the cutting accessories sharp and clean.**

Cutting accessories in good working conditions are less likely to bind and are easier to control.

Use the tool, components and accessories in accordance with these instructions and the projected way to use it for the type of tool when in adequate working conditions.

Using the tool for applications different from those it was designed for, could result in a hazardous situation.

Use and care of the battery-operated tool

Recharge only with the charger specified by TRUPER®.

A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

Use power tools only with specifically designated battery packs.

Use of any other battery packs may create a risk of injury and fire.

When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws, or other small metal objects, that can make a connection from one terminal to another.

Shorting the battery terminals together may cause burns or a fire.

Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.

Liquid ejected from the battery may cause irritation or burns.

Service

Repair the tool in a TRUPER® Authorized Service Center using only identical spare parts.

This will ensure that the safety of the power tool is maintained.

Safety rules for the use of hedge trimmers

• Safety is a combination of common sense, an alert mind and knowledge of how the tool works.

CAUTION • Read the manual carefully before starting to use the tool. Pay CAUTION to the safety rules, warning symbols and danger, caution and warning notices in the manual and on the labels attached to the tool.

WARNING • The tool is designed for bush cutting only. Do not attempt to cut other types of material.

Batteries and charger

DANGER • Use only Truper Max chargers to charge the tool battery. Using any other charger may result in fire or risk of injury.

DANGER • Use only batteries specifically designed for the tool. Other batteries may create a risk of fire or explosion.

• Connect the charger to an alternating current (AC) supply only.

DANGER • Do not use the charger outdoors.

• Watch polarity "+/-" when charging.

• Never recharge a leaking battery.

• Do not use batteries or the charger for purposes other than those for which they were designed.

• Do not modify the contacts of the battery or the charger.

• Do not expose the batteries to temperatures above 122 °C.

DANGER • Never expose batteries to fire, they could explode.

CAUTION • Batteries should be kept away from any metallic object such as paper clips, coins, keys, nails, screws or any other object that could cause the terminals to make contact, since it would cause a short circuit that could cause burns or fire.

CAUTION • Under extreme conditions, battery fluid may leak. If so, avoid any contact. If accidental contact occurs, wash with abundant water, rinse with lemon juice and vinegar. If the liquid enters in contact with the eyes, wash with abundant water during several minutes and look for medical help immediately. The liquid expelled from the batteries could cause irritation or burns.

CAUTION • To maximize battery life, fully discharge the battery at least once a month. Do not leave the battery uncharged for more than three months. Always charge the battery to its maximum capacity. Before using the machine for the first time, charge the battery for a minimum of 1.5 hours.

• Avoid stopping constantly while operating the tool to prevent damage to the battery.

• Do not dispose of batteries in fire, the battery may explode. Consult local codes for possible special disposal instructions.

• Do not open or mutilate batteries. Released electrolyte is corrosive and may cause eye or skin damage. May be toxic if swallowed.

• Do not charge the battery in the rain or in damp places.

Before operating the tool

• Do not use the tool in the rain or in wet conditions. The electric motor is not waterproof.

• Novice users should be trained by an experienced user in the use of the tool.

• The tool should not be used by children or persons under 18 years of age. Persons over 16 years of age may do so if they are trained under the supervision of an expert.

DANGER • Never use the tool when you are tired, ill or under the influence of drugs, alcohol or medication.

CAUTION • Wear appropriate clothing to operate the tool: tight fitting clothing, heavy-duty protective gloves and safety glasses with side shields in accordance with ANSI Z87.1.

• Make sure the tool is in perfect condition for safe use. Do not turn it on if it is improperly adjusted or not fully assembled or has any loose bolts.

• Do not use the tool without the protective guards properly mounted and secured.

• Check the work area and remove any stones, glass, nails, wires, ropes or any foreign objects. They could be thrown or become entangled in the tool.

• Make sure visibility and light conditions are adequate to see clearly, otherwise do not use the tool.

When operating the tool

- Keep all parts of the body away from the cutting blade. Do not remove the cut material or hold the material to be cut when the blades are moving. Make sure the switch is off when removing jammed material.
- Hold the tool by insulated gripping surfaces only, as the cutting blade may contact hidden electrical wiring to prevent possible electrical shock.

⚠ DANGER • Keep hands away from the blade. Contact with the blade will result in serious personal injury.

⚠ WARNING • Keep both feet firmly on the floor and both hands holding the tool by the handles. Never operate the tool with only one hand, otherwise the operator and others present may be injured.

⚠ CAUTION • If the blade comes in contact with a fence or any other hard object, immediately turn off the engine and remove the battery cartridge. Check the blade for damage and, if damaged, repair it immediately.


- Before checking the tool, servicing, repairing faults or removing material caught in the blade, always switch off the tool and remove the battery cartridge.

⚠ WARNING • Never point the blades at yourself or others.

⚠ CAUTION • If the blades become jammed during operation, turn the tool off and remove the battery cartridge, then remove foreign objects using a tool such as pliers. Do not do this by hand as the blades may move when removing foreign objects and cause injury.

After operating the tool

- When moving, even while working, or storing the tool, turn off the motor, remove the batteries and replace the blade sheath.
- Clean the tool, and especially the blade, after use and before long-term storage. Lightly oil the blade and replace the sheath.
- Store the tool with its sheath on, in a dry place, out of the reach of children. Never store the tool outdoors.




Considerations for the use of batteries

- The batteries come DISCHARGED from the factory. They will need to be charged for approximately 1.5 hours before use.
- The normal charging temperature is from 32 °F to 113 °F. Out of that range the load is suspended automatically until it reaches the correct temperature, the normal discharge / working temperature is 32 °F to 167 °F. If 167 °F is exceeded the electronic control shuts off power to the tool until the temperature reaches the optimum temperature range again. When the battery is under normal voltage during work, the tool stops working.
- Between each charge, give the charger 15 minutes of rest.
- In a hot environment or after prolonged use, the battery may become too hot to recharge. Allow the battery to cool down before attempting to recharge it.


Batteries charge

- Connect the charger plug to a 127 V~
- Insert the batteries into the charger by sliding them as shown in the picture. The red light should illuminate, indicating that charging has started.
- When the batteries are fully charged, the green light will turn on and the red light will turn off.
- Disconnect the charger from the power supply when charging is complete.
- If the red-light remains on exceeding the recommended charging time or if the red and green light flash alternately it is a sign that the battery is defective. Replace it with a new one.
- If the red-light flashes it is a sign that the battery temperature is below 32 °F or above 113 °F. Wait until the battery temperature is in the proper range to charge the battery.



Batteries

- Once the batteries are charged, insert them into their respective receptacles under the main handle.
- Slide the battery into its socket until you hear a click to make sure they are seated properly.
- To remove the battery, press the latch (A) and slide the battery out.
- To make sure the batteries are charged, press the indicator button (B) next to each battery. The color of the light indicates the charge level.



Remaining battery capacity

Indicator lamp	Green	51% to 100%
	Orange	
	Red	
Illuminated	Orange	26% to 50%
OFF	Red	10% to 25%

NOTE: Depending on the conditions of use and ambient temperature, the indication may differ slightly from the actual capacity.

Tool/batteries protection system

⚠ CAUTION • The tool is equipped with a system that automatically stops the tool to prolong both its useful life and that of the batteries, this happens in the following cases:

Overload. When the tool is forced, the battery consumes abnormally high current levels. Suspend overexertion work and turn the tool back on.


Overheating. Let the tool and battery cool before turning it back on.

Over-discharge. The battery level is low. In this case, remove the battery from the tool and charge it.

Blade sheath


⚠️ WARNING • Be careful not to touch the blades when installing or removing the blade cover.

- To remove the cover, press where the arrows indicate and pull the cover out.
- To put the sheath back on, insert the blade into the sheath as far as it will go so that it is secured by the sheath itself.



Handle angle adjustment

- Press the lock button (F), and then rotate the handle to adjust the angle. Once the desired angle is set, release the button to lock it.
- The handle angle can be adjusted to either the right or the left up to 90° in 45° increments.



Turning ON


- To turn on the tool, hold the auxiliary handle (E) firmly with one hand and with the other press the switch latch (C) and pull the switch trigger (D).

- Fully depress the switch trigger.

⚠️ WARNING • The switch lock prevents accidental starting. NEVER use the tool if it starts just by squeezing the switch trigger (D) and without depressing the switch lock (C). Go to a TRUPER® Authorized Service Center to repair the tools BEFORE using it.


- To turn the tool off, release the switch trigger so it returns to the "OFF" position.

⚠️ CAUTION • Before inserting the batteries in the tool, always check that the switch trigger and its safety are activated correctly and return to the "OFF" position when released.



Working conditions

- Do not cut branches of 13 mm diameter (A) with the tool. Cut branches 10 cm below the cutting height using branch cutters before using the tool (B).




- Do not cut dead trees or similar hard objects. Doing so may damage the tool.
- Do not trim grass or brush while using the cutting blades. The cutting blades may become entangled in the grass or brush.




Basic operation

- Hold the tool with both hands and turn the tool on as instructed on page 9.
- Tilt the blade in the cutting direction and move it calmly and slowly at a speed of 3 to 4 seconds per meter.




Cutting tips

- To cut the top of a hedge evenly, tie a hedge at the height the hedge should be.
- Use a string as a reference so that the blade maintains the same height throughout the cut.



- To cut the side of the hedge evenly, cut from the bottom down to the top, aligning the blade to the edge of the hedge.
- The above point also applies to shaping the hedge (box trimming, rounding, etc.), trim from the root to the top for a good finish.



WARNING Always keep both hands on the tool handles.

Cleaning and care

- Regularly inspect all mounting bolts and make sure they are tightened correctly. If any of the screws are loose, tighten them immediately.
- Use a clean, soft cloth to clean the tools. Never use alcohol or detergent. Remove the batteries before cleaning.
- Never use gasoline, benzine, thinner, alcohol or similar. They may cause discoloration, deformation or cracking.

Storage

- Place the blade sleeve so that the blade is not exposed.
- Store the tool out of the reach of children, in a safe place.

Cleaning and care of the blade


- Regularly inspect all mounting bolts and make sure they are tightened properly. If any of the screws are loose, tighten them immediately.
- Use a brush to clean the blade. Remove the batteries before cleaning the blade.
- Lubricate the blade after each use and before long term storage.

Service

Tools should only be serviced at a TRUPER® Authorized Service Center. Service and maintenance by unqualified persons may be dangerous and may result in personal injury and void the product warranty.

Environmental protection

Electrical appliances and batteries should not be disposed of with household waste. Please deliver this device as well as its batteries with the contacts insulated with adhesive cloth to a recycling center. Check the location of the nearest recycling center in your community



Authorized service centers

TRUPER
max

In the event of any problem contacting a TRUPER Authorized Service Center, please see our webpage WWW.TRUPER.COM to get an updated list, or call our toll-free numbers **800 690-6990** or **800 018-7873** to get information about the nearest Service Center.

AGUASCALIENTES	DE TODO PARA LA CONSTRUCCIÓN GRAL. BARRAGÁN #1201, COL. GREMIAL, C.P. 20030, AGUASCALIENTES, AGS. TEL.: 449 994 0537	
BAJA CALIFORNIA	SUCRAL Tijuana AV. LA ENCANTADA, LOTE #5, PARQUE INDUSTRIAL EL FLORIDO II, C.P. 22244, Tijuana, B.C. TEL.: 664 969 5100	
BAJA CALIFORNIA SUR	FIX FERRETERÍAS FELIPE ÁNGELES ESQ. RUIZ CORTÍNEZ S/N, COL. PUEBLO NUEVO, C.P. 23670, CD. CONSTITUCIÓN, B.C.S. TEL.: 613 132 1115	
CAMPECHE	TORNILLERÍA Y FERRETERÍA AAA AV. ALVARO OBREGÓN #524, COL. ESPERANZA C.P. 24080 CAMPECHE, CAMP. TEL.: 981 815 2808	
CHIAPAS	FIX FERRETERÍAS AV. CENTRAL SUR #27, COL. CENTRO, C.P. 30700, TAPACHULA, CHIS. TEL.: 962 118 4083	
CHIHUAHUA	SUCRAL CHIHUAHUA AV. SILVESTRE TERRAZAS #12-11, PARQUE INDUSTRIAL BAFAR, CARRETERA MÉXICO CUAHUTÉMOC, C.P. 31415, CHIHUAHUA, CHIH. TEL. 614 434 0052	
CIUDAD DE MÉXICO	FIX FERRETERÍAS EL MONSTRUO DE CORREGIDORA, CORREGIDORA # 35, COL. CENTRO, C.P. 06600, CUAHUTÉMOC, CDMX. TEL: 55 5522 5031 / 5522 4861	
COAHUILA	SUCRAL TORRÉON CALLE METAL MECÁNICA #280, PARQUE INDUSTRIAL ORIENTE, C.P. 27278, TORRÉON, COAH. TEL.: 871 209 68 23	
COLIMA	BOMBAS Y MOTORES BYMTESA DE MANZANILLO BLVD. MIGUEL DE LA MADRID #190, COL. 16 DE SEPTIEMBRE, C.P. 28229, MANZANILLO, COL. TEL: 314 332 1986 / 332 2013	
DURANGO	TORNILLOS ÁGUILA, S.A. DE C.V. MAZURIO #200, COL. LUIS ECHEVERRÍA, DURANGO, DGO. TEL.: 618 817 1946 / 618 818 2844	
ESTADO DE MÉXICO	SUCRAL CENTRO JILOTEPEC PARQUE INDUSTRIAL # 1, COL. PARQUE INDUSTRIAL JILOTEPEC, JILOTEPEC, EDO. DE MÉX. C.P. 54257 TEL: 761 782 9101 EXT. 5/278 Y 5102	
GUANAJUATO	CÍA. FERRETERA NUEVO MUNDO S.A. DE C.V. AV. MÉXICO - JAPÓN #225, CD. INDUSTRIAL, C.P. 38010, CELAYA, GTO. TEL: 461 617 7578 / 79 / 80 / 88	
GUERRERO	CENTRO DE SERVICIO ECLIPSE CALLE PRINCIPAL MZ.1 L1, #1, COL. SANTA FE, C.P. 39010, CHILPANCINGO, GRO. TEL: 747 478 5793	
HIDALGO	FERREPRECIOS S.A. DE C.V. LIBERTAD ORIENTE #304 LOCAL 30, INTERIOR DE PASAJE ROBLEDO, COL. CENTRO, C.P. 43600, TULANCINGO, HGO. TEL.: 775 753 6615 / 775 753 6616	
JALISCO	SUCRAL GUADALAJARA AV. ADOLFO B. HORN # 6800, COL: SANTA CRUZ DEL VALLE, C.P. 45655, TLAJOMULCO DE ZÚÑIGA, JAL. TEL.: 33 3606 5285 AL 90	
MICHOACÁN	FIX FERRETERÍAS AV. PASEO DE LA REPÚBLICA #3140-A, COL. EX-HACIENDA DE LA HUERTA, C.P. 58050, MORELIA, MICH. TEL.: 443 334 6858	
MORELOS	FIX FERRETERÍAS CAPITAN ANZURES #95, ESQ. JOSÉ PERDIZ, COL. CENTRO, C.P. 62740, CUAUTLA, MOR. TEL: 735 352 8931	
NAYARIT	HERRAMIENTAS DE TEPIC MAZATLÁN #117, COL. CENTRO, C.P. 63000, TEPIC, NAY. TEL: 311 258 0540	
NUEVO LEÓN	SUCRAL MONTERREY CARRETERA LAREDO #300, 1B MONTERREY PARKS, COLONIA PUERTA DE ANAHUAC, C.P. 66052, ESCOBEDO, NUEVO LEÓN, TEL.: 81 8352 8791 / 81 8352 8790	
OAXACA	FIX FERRETERÍAS AV. 20 DE NOVIEMBRE #910, COL. CENTRO, C.P. 68300, TUXTEPEC, OAX. TEL: 287 106 3092	
PUEBLA	SUCRAL PUEBLA AV. PERIFÉRICO #2-A, SAN LORENZO ALMECATLA, C.P. 72710, CUATLACINGO, PUE. TEL: 222 282 8282 / 84 / 85 / 86	
QUERÉTARO	ARU HERRAMIENTAS S.A DE C.V. AV. PUERTO DE VERACRUZ #110, COL. RANCHO DE ENMEDIO, C.P. 76842, SAN JUAN DEL RÍO, QRO. TEL.: 427 268 4544	
QUINTAÑA ROO	FIX FERRETERÍAS CARRETERA FEDERAL MZ. 46 LT. 3 LOCAL 2, COL. EJIDAL, C.P. 77710 PLAYA DEL CARMEN, Q.R. TEL: 984 267 3140	
SAN LUIS POTOSÍ	FIX FERRETERÍAS AV. UNIVERSIDAD #1850, COL. EL PASEO, C.P. 78320, SAN LUIS POTOSÍ, SLP. TEL: 444 822 4341	
SINALOA	SUCRAL CULIACÁN AV. JESÚS KUMATE SUR #4301, COL. HACIENDA DE LA MORA, C.P. 80143, CULIACÁN, SIN. TEL: 667 173 9139 / 173 8400	
SONORA	FIX FERRETERÍAS CALLE 5 DE FEBRERO #517, SUR LT. 25 MZ. 10, COL. CENTRO, C.P. 85000, CD. OBREGÓN, SON. TEL: 644 413 2392	
TABASCO	SUCRAL VILLAHERMOSA CALLE HELIO LOTES 1, 2 Y 3 MZ. #1, COL. INDUSTRIAL, 2A ETAPA, C.P. 86010, VILLAHERMOSA, TAB. TEL: 993 353 7244	
TAMAULIPAS	VM ORINGS Y REFACCIONES CALLE ROSITA #527 ENTRE 20 DE NOVIEMBRE Y GRAL. RODRIGUEZ, FRACC. REYNOSA, C.P. 88780, REYNOSA, TAMS. TEL.: 899 926 7552	
TLAXCALA	SERVICIOS Y HERRAMIENTAS INDUSTRIALES PABLO SIDAR #132, COL. BARRO DE SAN BARTOLOMÉ, C.P. 90970, SAN PABLO DEL MONTE, TLAX. TEL.: 222 271 7502	
VERACRUZ	LA CASA DISTRIBUIDORA TRUPER BLVD. PRIMAVERA ESQ. HORTENSIA S/N, COL. PRIMAVERA C.P. 93308, POZA RICA, VER. TEL.: 782 823 8100 / 826 8484	
YUCATÁN	SUCRAL MÉRIDA CALLE 33 #600 Y 602, LOCALIDAD ITZINCAB Y MULSAY, MPIO. UMÁN, C.P. 97390, MÉRIDA, YUC. TEL.: 999 912 2451	

Code	Model	Brand
102490	MAX-40C	TRUPER max

Warranty. Duration: 5 year. Coverage: parts, components and workmanship against manufacturing or operating defects, except if used under conditions other than normal; when it was not operated in accordance with the instructive; was altered or repaired by personnel not authorized by TRUPER®. To make the warranty valid, only present the product in the establishment where you bought it or in Corregidora 35, Centro, Cuauhtémoc, CDMX, 06060, where you can also purchase parts, components, consumables and accessories. The costs of transportation of the product that derive from its fulfillment of its service network are included. TRUPER will not require any proof of purchase to make the warranty effective. Phone number 800-018-7873. Made in China. Imported by TRUPER, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Phone number 761 782 9100.

Stamp of the business. Delivery date:

