

ENGLISH



TRUPER®
PRO

Manual

Dual action polisher

900 W

Power


6"

Disc

Applies for:

Model **Code**

PULA-6A 102333



PULA-6A



Read this manual thoroughly
before using the tool.



Technical data	3
Power requirements	3
 General power tool safety warnings	4
 Safety warnings for the use of car polishers	5
Parts	5
Assembly	6
Start up	7
Maintenance	8
Authorized service centers	9
Warranty policy	10

CAUTION

To gain the best performance of the tool, prolong the duty life, make the Warranty valid if necessary, and to avoid hazards of fatal injuries please read and understand this Manual before using the tool.

Keep this manual for future references.

The illustrations in this manual are for reference only. They might be different from the real tool.

Use and care recommendations



RESPECT THE WORK CYCLES. 30 min of work per 15 min of rest.



Maximum 3 hours daily.



AVOID using the cord to move, lift or disconnect the tool.



ALWAYS operate the machine using the main handle along with either the auxiliary handle, the "D" handle, or the ergonomic front handle.



AVOID pressing down on the surface with the polisher. Let the movement of the bonnet do the work instead.



Keep the tool's ventilation slots **CLEAN**.



Perform regular MAINTENANCE on your machine (page 8).

PULA-6A

Code	•	102333			
Description	•	Dual action polisher			
Discs	•	6"			
Voltage	•	127 V~			
Frequency	•	60 Hz			
Current	•	7.5 A			
Power	•	900 W			
Speed	•	1 400 RPM - 5 100 RPM			
Work cycle	•	30 minutes of work and 15 minutes of rest. Maximum 3 hours per day			
Conductors	•	18 AWG x 2C with insulation temperature of 221 °F			
Insulation	•	Class II	IP Grade	•	IPX1
Orbit diameter	•	3/5"	Excentricity	•	3/10"

The power cable has cable clamps type: Y
 The construction class of the tool is: Reinforced insulation.
 The thermal insulation class of the motor wiring is: Class E

WARNING Avoid the risk of electric shock or severe injury. When the power cable gets damaged it should only be replaced by the manufacturer or at a TRUPER Authorized Service Center.


The build quality of the electric insulation is altered if spills or liquid gets into the tool while in use. Do not expose to rain, liquids and/or dampness.

WARNING Before gaining access to the terminals all power sources should be disconnected.



Power requirements

WARNING Tools with double insulation and reinforced insulation are built with a polarized plug (one prong is wider than the other) This plug fits in any polarized outlet and can only be connected one way. If the plug does not fit completely into the outlet, reverse the plug. If it is not fitting, call a qualified electrician or install a polarized outlet. Do not alter the plug in any way. Double insulation eliminates the need of a three-prong grounded power plug or a grounded electric system.



WARNING When using an extension cable, make it has sufficient gauge to carry the current your tool will draw. A lower gauge cable will cause voltage drop in the line, resulting in power loss and the motor will overheat. The following table shows the right size to use depending on cable's length and the ampere capability shown in the tool's nameplate. When in doubt use the next higher gauge.

Ampere Capacity	Number of Conductors	Extension Gauge	
		From 6 ft to 49 ft	Higher than 49 ft
From 0 A and up to 10 A		18 AWG	16 AWG
From 10 A and up to 13 A		16 AWG	14 AWG
From 13 A and up to 15 A	3 (one grounded)	14 AWG	12 AWG
From 15 A and up to 20 A		8 AWG	6 AWG

* It is safe to use only if the extensions have a built-in artifact for over current protection.

AWG = American Wire Gauge. Reference: NMX-J-195-ANCE

WARNING When using power tools outdoors use VOLTECK grounded extension cable labeled "Outdoors Use". These extension cables are specially manufactured for outdoors use and reduce the risk of electric shock.



General power tool
safety warnings

⚠ WARNING! Read carefully all safety warnings and instructions listed below. Failure to comply with any of these warnings may result in electric shock, fire and / or severe damage. **Save all warnings and instructions for future references.**

Work area

Keep your work area clean, and well lit.

Cluttered and dark areas may cause accidents.



Never use the tool in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.

Sparks generated by power tools may ignite the flammable material.



Keep children and bystanders at a safe distance while operating the tool.

Distractions may cause loss of control.



Electrical Safety

The tool plug must match the power outlet. Never modify the plug in any way. Do not use any adapter plugs with grounded power tools.

Modified plugs and different power outlets increase the risk of electric shock.



Avoid body contact with grounded surfaces, such as pipes, radiators, electric ranges and refrigerators.

The risk of electric shock increases if your body is grounded.

Do not expose the tool to rain or wet conditions.

Water entering into the tool increases the risk of electric shock.

Do not force the cord. Never use the cord to carry, lift or unplug the tool. Keep the cord away from heat, oil, sharp edges or moving parts.

Damaged or entangled cords increase the risk of electric shock.

When operating a tool outdoors, use an extension cord suitable for outdoor use.

Using an adequate outdoor extension cord reduces the risk of electric shock.

If operating the tool in a damp location cannot be avoided, use a ground fault circuit interrupter (GFCI) protected supply.

Using a GFCI reduces the risk of electric shock.

Personal safety

Stay alert, watch what you are doing and use common sense when operating a tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.

A moment of distraction while operating the tool may result in personal injury.

Use personal protective equipment. Always wear eye protection.

Protective equipment such as safety glasses, anti-dust mask, non-slip shoes, hard hats and hearing protection used in the right conditions significantly reduce personal injury.



Prevent unintentional starting up. Ensure the switch is in the "OFF" position before connecting into the power source and / or battery as well as when carrying the tool.

Transporting power tools with the finger on the switch or connecting power tools with the switch in the "ON" position may cause accidents.

Remove any wrench or vice before turning the power tool on.

Wrenches or vices left attached to rotating parts of the tool may result in personal injury.



Do not overreach. Keep proper footing and balance at all times.

This enables a better control on the tool during unexpected situations.



Dress properly. Do not wear loose clothing or jewelry. Keep hair, clothes and gloves away from the moving parts.

Loose clothes, jewelry or long hair may get caught in moving parts.

If you have dust extraction and recollection devices connected onto the tool, inspect their connections and use them correctly.

Using these devices reduce dust-related risks.



Power Tools Use and Care

Do not force the tool. Use the adequate tool for your application.

The correct tool delivers a better and safer job at the rate for which it was designed.

Do not use the tool if the switch is not working properly.

Any power tool that cannot be turned ON or OFF is dangerous and should be repaired before operating.



Disconnect the tool from the power source and / or battery before making any adjustments, changing accessories or storing.

These measures reduce the risk of accidentally starting the tool.

Store tools out of the reach of children. Do not allow persons that are not familiar with the tool or its instructions to operate the tool.



Power tools are dangerous in the hands of untrained users.

Service the tool. Check the mobile parts are not misaligned or stuck. There should not be broken parts or other conditions that may affect its operation. Repair any damage before using the tool.

Most accidents are caused due to poor maintenance to the tools.



Keep the cutting accessories sharp and clean.

Cutting accessories in good working conditions are less likely to bind and are easier to control.

Use the tool, components and accessories in accordance with these instructions and the projected way to use it for the type of tool when in adequate working conditions.

Using the tool for applications different from those it was designed for, could result in a hazardous situation.



Service

Repair the tool in a TRUPER Authorized Service Center using only identical spare parts.

This will ensure that the safety of the power tool is maintained.



This tool is in compliance with
the Official Mexican Standard
(NOM - Norma Oficial Mexicana).

Safety warnings for the use of car polishers

TRUPER
PRO

- This power tool is designed to function as a polisher. Read all safety warnings, instructions and specifications supplied with this power tool. Failure to follow all instructions listed below could result in electric shock, fire and/or serious injury.
- Operations such as grinding, wire brushing or cutting are not recommended for use with this power tool. Operations for which the power tool is not designed may present a hazard and result in personal injury.
- The specified speed of the accessory must be at least the same as the maximum speed marked on the power tool. Accessories running faster than their specified speed may break or disintegrate.
- The outside diameter and thickness of your accessory must be within the stated capacity of your power tool. Incorrectly sized accessories cannot be adequately protected or controlled.
- Never keep your car running when using the polisher in an enclosed area.
- Test your polisher before starting work. In case the tool emits a strange sound or vibrates irregularly, turn it off. Disconnect the tool and take it to a TRUPER Authorized Service Center.
- When not in service, the tool should be turned off and unplugged.
- To avoid accidental starting, keep fingers away from the on/off switch when connecting the polisher to the socket.
- To avoid electric shock, keep the tool dry and clean, free of any oil and grease residue.

⚠ CAUTION • During the polishing operation keep the cord away from the polisher path, otherwise it could be caught and cut by the disc, exposing the operator to electric shock.



• Do not force the tool. Hold it firmly by both handles without exerting downward pressure. Failure to do so will slow down the movement of the machine, reduce the quality of the work and could cause severe damage to the tool.

• Take care of your tool. Your job will be easier if you keep your tool in good condition.

⚠ CAUTION • Do not use accessories that are not specifically designated and recommended by the tool manufacturer. Fitting any accessory to the power tool does not ensure safe operation.

⚠ CAUTION • Do not use accessories that require liquid coolant. Use of water or other liquid coolant may electrocute or shock you.



⚠ CAUTION • Do not allow any loose portion of the tassel or its cords to rotate freely. Cut off any protruding cords. Tassel cords may become entangled in your fingers or may snag on the workpiece.

Kickback and related warnings

Kickback is the sudden, forceful movement of the tool in the opposite direction to the movement of the work attachment that can cause the operator to lose control or even cause injury.

Kickback is the result of poor procedures and/or operating conditions that can be avoided by taking the following precautionary measures.


- Hold the tool firmly with both hands. Position your body and arms to allow you to resist the force of any kickback. For maximum control over kickback or torque reaction during start-up always use the auxiliary handle if provided with the equipment. By following these precautions, the operator can control kickback.
- Never place your hand near the rotating attachment. The accessory could kickback on your hand.
- Do not place your body in the direction the tool would move if kickback were to occur. Remember that kickback throws the tool in the opposite direction of the accessory's movement at the point of contact.
- Be especially careful when working sharp corners or edges. Avoid bouncing and/or snagging the accessory. Corners, sharp edges and bouncing tend to snag the rotating accessory and cause loss of control or kickback.
- Do not operate the electric tool while carrying it. Accidental contact with the rotating accessory can cause it to catch on clothing, pulling the accessory toward your body.
- Keep people at a safe distance from the work area.
- Anyone entering the work area should wear personal protective equipment.



Assembly

Installation of the disc with hook and loop fastening


1. Place the polisher upside down.
2. Position the disc so that the center aligns with the screw hole.
3. Screw it in using the hex key, turning clockwise until the disc is secure.



Installation of the D-type handle

- Remove the screws/cap that come in the handle placement holes.
- Align the D-Handle (A) to the polisher head and align it with the screw holes (B).
- Move the handle to the desired angle.
- Screw the D-Handle securely to the polisher head with the screws and wrench provided.

IMPORTANT Do not use the screws/cap that you removed from the machine.




Auxiliary handle assembly

CAUTION Before performing any operation, always make sure that the auxiliary handle (E) is firmly installed. Place the auxiliary handle in either of the two positions which you prefer.

Polishing pads

- Polishing pads (C) or any other polishing accessory is mounted directly to the disc with hook and loop system (D).
- To install the pad, first remove any dirt or foreign material. Place the pad on the hook and loop fastening disc so that the edges are aligned.
- The polisher includes three interchangeable pads:

 1. Wine: for removing scratches.
 2. Yellow: for removing fine lines.
 3. Orange: for final finishing.



Polishing pads

- To remove the pad, simply pull it by the edge.

CAUTION Make sure the pad and pad are aligned and properly installed. Otherwise, the pad will cause excessive vibration which may cause loss of control or the pad may be ejected from the tool.

Start up

Power on and operation control

- Intermittent operation:

Connect the plug to the power outlet.

Press the switch (A) to start the tool.

To discontinue use, simply release the switch.

- Continuous operation:



Connect the plug to the power outlet.

Press the switch (A) and lock it by pressing the continuous use button (B).

To interrupt operation, press and then release the switch.

CAUTION The switch can be locked in the on position for operator comfort during prolonged use. Use care when locking the tool in the on position and keep the tool securely fastened.

CAUTION Do not turn the tool on with the lockout switch activated. The tool will start unsupported and may cause personal injury or breakage.



Speed control

- The tool can be operated at different speeds. These are selected by setting the speed control to a given number from 1 to 6 (C). The speed increases as the control is turned to a higher number and decreases as it is turned to a lower number.
- Generally, low speeds are recommended for small work areas and high speeds for large areas. Use the speed that best suits the working conditions.
- Refer to table (D) for the relationship between speed control number settings and approximate speed.

NOTICE Continued use of the tool at low speeds for an extended period of time will result in motor overload and poor tool operation.




NOTICE The speed adjustment dial can only be turned to 6 and back to 1. Do not force it beyond 6 or 1, or the speed adjustment function may stop working.

D Speed table


1	1 400 RPM
2	1 800 RPM
3	2 800 RPM
4	3 700 RPM
5	4 500 RPM
6	5 100 RPM

How to hold the tool properly

- Always hold the tool with both hands: Grip the main handle with one hand and use the other for the secondary handle (whether it's the auxiliary, D-type, or ergonomic handle), depending on which best suits the area that needs polishing.
- Be careful not to obstruct the ventilation slots.



Replacements & available consumables


Replacement	Code	Item
 D handle	102743	MAN-PULA-6A
 6" polyurethane disc pads	102740	ES-PULA-6A
 6" wool polishing bonnet	103420	BOR-PULA-6A
 Base hook and loop	102741	PAD-PULA-6A
 Replacement carbon brushes	102742	CB-PULA-6A

Polish

- Move the polisher back and forth over the work surface with long strokes.
 - Note that excessive pressure, incorrect angle or improper movements can cause swirl marks or burn marks in the finish. To avoid these, do not use high speeds when polishing small areas, press the pad lightly on the surface and keep the polisher in constant motion without leaving it static in one spot, especially near edges or changes in the work surface.
 - Follow the instructions on the polishing products to obtain a quality job.
- CAUTION** • Be vigilant when polishing rough surfaces, with seams or nooks and crannies where the pad can get stuck. A stuck pad can cause you to lose control of the tool and/or burn the finish. To reduce this risk, use low speeds on rough surfaces, and in the case of complicated surfaces such as mirrors or moldings, avoid using the tool and polish by hand.
- The most common mistake is applying too much wax. If the buffering pad absorbs too much wax it will not last long and the polishing job will be more difficult and will take a long time to finish.
 - Always unplug the tool before cleaning.
 - Never use water or other liquids, only a brush.
 - To prevent the motor from overheating, the ventilation slots should be cleaned regularly.
 - Check that all components of the tool are securely fastened.
 - The housing should not be cracked or damaged.
 - Always check that the cable is not cut or stripped.
 - After prolonged use the grease in the tool head should be changed at a TRUPER Authorized Service Center.

Replacing the PAD with hook and look attachment (A)

- Turn the polisher upside down.
- Remove the attachment mounted on the disc.
- Using the hex wrench remove the center screw, remove the worn hook and loop attachment disc and replace it with a new one.
- Replace the screw to secure the velcro disc.



Carbon replacement


- It is necessary to replace worn out carbons (burnt, broken or less than 5 mm long) with new ones.
- When replacing the carbons, always replace both carbons.
- Use a screwdriver to remove the cover of the carbons (B).
- Remove the worn carbons from the carbon holder and remove the accumulated dust with compressed air.
- Insert the new carbons in reverse order. The carbons should fall into the carbon holders easily.
- After inserting the new carbons, allow the tool to run for 10 minutes without a workload to give the carbons a better fit.
- Only TRUPER replacement carbons, designed with the proper hardness and electrical resistance for each type of motor, should be used. Out of specification carbons can damage the motor.

Repairs

Use only spare parts and accessories recommended by the manufacturer. In case the tool does not work, the repair should be carried out by a TRUPER Authorized Service Center.

Storage

- Store the tool neatly in a dry place and protected from water and dust.



Authorized service centers

In the event of any problem contacting a TRUPER Authorized Service Center, please see our webpage WWW.TRUPER.COM to get an updated list, or call our toll-free numbers 800 690-6990 or 800-018-7873 to get information about the nearest Service Center.

AGUASCALIENTES	DE TODO PARA LA CONSTRUCCIÓN GRAL. BARRAGÁN #1201, COL. GREMIAL, C.P. 20030, AGUASCALIENTES, AGS. TEL.: 449 994 0537	MORELOS	FIX FERRETERÍAS CAPITÁN ANZURES #95, ESQ. JOSÉ PERDIZ, COL. CENTRO, C.P. 62740, CUAUTLA, MOR. TEL.: 735 552 8931
BAJA CALIFORNIA	SUCURSAL TIJUANA AV. LA ENCANTADA, LOTE #5, PARQUE INDUSTRIAL EL FLORIDO II, C.P. 22244, TIJUANA, B.C. TEL.: 664 969 5100	NAYARIT	HERRAMIENTAS DE TEPIC MAZATLÁN #117, COL. CENTRO, C.P. 63000, TEPIC, NAY. TEL.: 311 258 0540
BAJA CALIFORNIA SUR	FIX FERRETERÍAS FELIPE ÁNGELES ESQ. RUIZ CORTÍNEZ S/N, COL. PUEBLO NUERO, C.P. 23670, CD. CONSTITUCIÓN, B.C.S. TEL.: 613 132 1115	NUEVO LEÓN	SUCURSAL MONTERREY CARRETERA LAREDO #500, 1B MONTERREY PARKS, COLONIA PUERTA DE ANÁHUAC, C.P. 66052, ESCOBEDO, NUEVO LEÓN, TEL.: 81 8352 8791 / 81 8352 8790
CAMPECHE	TORNILLERÍA Y FERRETERÍA AAA AV. ÁLVARO OBREGÓN #524, COL. ESPERANZA C.P. 24080 CAMPECHE, CAMP. TEL.: 981 815 2808	OAXACA	FIX FERRETERÍAS AV. 20 DE NOVIEMBRE #910, COL. CENTRO, C.P. 68300, TUXTEPEC, OAX. TEL.: 287 106 3092
CHIAPAS	FIX FERRETERÍAS AV. CENTRAL SUR #27, COL. CENTRO, C.P. 30700, TAPACHULA, CHIS. TEL.: 962 118 4083	PUEBLA	SUCURSAL PUEBLA AV. PERIFÉRICO #2-A, SAN LORENZO ALMECATLA, C.P. 72710, CUÁUTLACINGO, PUE. TEL.: 222 282 8282 / 84 / 85 / 86
CHIHUAHUA	SUCURSAL CHIHUAHUA AV. SILVESTRE TERRAZAS #128-11, PARQUE INDUSTRIAL BAFAR, CARRETERA MÉXICO CUAUHTEMOC, C.P. 31415, CHIHUAHUA, CHIH. TEL.: 614 434 0052	QUERÉTARO	ARU HERRAMIENTAS S.A. DE C.V. AV. PUERTO DE VERACRUZ #110, COL. RANCHO DE ENMEDIO, C.P. 76842, SAN JUAN DEL RÍO, QRO. TEL.: 427 268 4544
CIUDAD DE MÉXICO	FIX FERRETERÍAS EL MONSTRUO DE CORREDIGORA, CORREDIGORA # 35, COL. CENTRO, C.P. 06090, CUAUHTEMOC, CDMX. TEL.: 55 5522 5031 / 5522 4861	QUINTANA ROO	FIX FERRETERÍAS CARRETERA FEDERAL MZ. 46 LT. 3 LOCAL 2, COL. EJIDAL, C.P. 77710 PLAYA DEL CARMEN, Q.R. TEL.: 984 267 3140
COAHUILA	SUCURSAL TORREÓN CALLE METAL MECÁNICA #280, PARQUE INDUSTRIAL ORIENTE, C.P. 27278, TORREÓN, COAH. TEL.: 871 209 68 23	SAN LUIS POTOSÍ	FIX FERRETERÍAS AV. UNIVERSIDAD #1850, COL. EL PASEO, C.P. 78320, SAN LUIS POTOSÍ, S.L.P. TEL.: 444 822 4341
COLIMA	BOMBAS Y MOTORES BYMTESA DE MANZANILLO BLVD. MIGUEL DE LA MADRID #190, COL. 16 DE SEPTIEMBRE, C.P. 28239, MANZANILLO, COL. TEL.: 314 332 1986 / 332 8013	SINALOA	SUCURSAL CULIACÁN AV. JESÚS KUMATE #4301, COL. HACIENDA DE LA MORA, C.P. 80143, CULIACÁN, SIN. TEL.: 667 173 9139 / 173 8400
DURANGO	TORNILLOS ÁGUILA, S.A. DE C.V. MAZURIÓ #200, COL. LUIS ECHEVERRÍA, DURANGO, DGO. TEL.: 618 817 1946 / 618 818 2844	SONORA	FIX FERRETERÍAS CALLE 5 DE FEBRERO #517, SUR LT. 25 MZ. 10, COL. CENTRO, C.P. 85000, CD. OBREGÓN, SON. TEL.: 644 413 2392
ESTADO DE MÉXICO	SUCURSAL CENTRO JILOTEPEC PARQUE INDUSTRIAL # 1, COL. PARQUE INDUSTRIAL JILOTEPEC, JILOTEPEC, EDO. DE MÉX. C.P. 54257 TEL.: 761 782 9101 EXT. 5/28 Y 5/102	TABASCO	SUCURSAL VILLAHERMOSA CALLE HELIO LOTES 1, 2 Y 3 MZ. #1, COL. INDUSTRIAL, 2A ETAPA, C.P. 86010, VILLAHERMOSA, TAB. TEL.: 993 353 7244
GUANAJUATO	CÍA. FERRETERA NUEVO MUNDO S.A. DE C.V. AV. MÉXICO - JAPÓN #225, CD. INDUSTRIAL, C.P. 38010, CELAYA, GTO. TEL.: 461 617 7578 / 79 / 80 / 88	TAMAULIPAS	VM ORINGS Y REFACCIONES CALLE ROSITA #527 ENTRE 20 DE NOVIEMBRE Y GRAL. RODRÍGUEZ, FRACC. REYNOSA, C.P. 88780, REYNOSA, TAMS. TEL.: 899 926 7552
GUERRERO	CENTRO DE SERVICIO ECLIPSE CALLE PRINCIPAL MZ.1 LT. 1, COL. SANTA FE, C.P. 39100, CHILPANCINGO, GRO. TEL.: 747 478 5793	TLAXCALA	SERVICIOS Y HERRAMIENTAS INDUSTRIALES PABLO SIDAR #152, COL. BARRIO DE SAN BARTOLOMÉ, C.P. 90970, SAN PABLO DEL MONTE, TLAX. TEL.: 222 271 7502
HIDALGO	FERREPRESOS S.A. DE C.V. LIBERTAD ORIENTE #304 LOCAL 30, INTERIOR DE PASAJE ROBLEDO, COL. CENTRO, C.P. 43600, TULANCINGO, HGO. TEL.: 775 753 6615 / 775 753 6616	VERACRUZ	LA CASA DISTRIBUIDORA TRUPER BLVD. PRIMAVERA. ESQ. HORTENSIA S/N, COL. PRIMAVERA C.P. 93308, POZA RICA, VER. TEL.: 782 823 8100 / 826 8484
JALISCO	SUCURSAL GUADALAJARA AV. ADOLFO B. HORN #6800, COL. SANTA CRUZ DEL VALLE, C.P.: 45655, TLAJOMULCO DE ZÚÑIGA, JAL. TEL.: 33 3606 5285 AL 90	YUCATÁN	SUCURSAL MÉRIDA CALLE 33 #600 Y 602, LOCALIDAD ITZINCAB Y MULSAY, MPIO. UMÁN, C.P. 97390, MÉRIDA, YUC. TEL.: 999 912 2451
MICHOACÁN	FIX FERRETERÍAS AV. PASEO DE LA REPÚBLICA #3140-A, COL. EX-HACIENDA DE LA HUERTA, C.P. 58050, MORELIA, MICH. TEL.: 445 334 6858		

Model	Code	Brand
PULA-6A	102333	TRUPER PRO

Warranty. Duration: 3 year. Coverage: parts, components and workmanship against manufacturing or operating defects, except if used under conditions other than normal; when it was not operated in accordance with the instructive; was altered or repaired by personnel not authorized by TRUPER®. To make the warranty valid, present the product, stamped policy or invoice or receipt or voucher, in the establishment where you bought it or in Corregidora 35, Centro, Cuahtémoc, CDMX, 06060, where you can also purchase parts, components, consumables and accessories. It includes the costs of transportation of the product that derive from its fulfillment of its service network. Phone number 800-018-7873. Made in China. Imported by TRUPER, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Phone number 761 782 9100.



Stamp of the business. Delivery date:

Sello del establecimiento comercial. Fecha de entrega:



Industria 1, Pachuca Industrial Jilotepec, Jilotepec, Edo. de Mex. C.P. 54257, Tel. 761 782 9100.
red de servicios. Tel. 800-018-7873. Made in/Hecho en China. Importador TRUPER, S.A. de C.V. Pachuca
consumibles y accesorios. Incluye los gastos de transportación del producto que deviven de su cumplimiento de
o en Corregidora 35, Centro, Cuautitlán, CDMX, 66060, donde también podrá adquirir partes, componentes,
presente el producto, poliza sellada o factura recibida o comprabante, en el establecimiento donde lo compró
instintivamente; fue allorado o reparado por personal no autorizado por TRUPER®. Para hacer efectiva la garantía
funcionamiento, excepto si se uso en condiciones distintas a las normales; cuando no fue operado conforme
Garantía. Duración: 3 años. Cobertura: piezas, componentes y mano de obra contra defectos de fabricación o
industriales.

Modelo	Código	Marca	PULL-6A	102333	TRUPER PRO
--------	--------	-------	---------	--------	------------

garantía
poliza de

TRUPER
PRO




TRUE PRO

Centros de servicio autorizados

WWW.TURPER.COM donde obtendrá un listado actualizado, o llame al: 800 690 6990 o 800-018-7873 donde le informarán cuál es el Centro de Servicio más cercano.

informarán cuál es el Centro de Servicio más cercano.

VERACRUZ LA CASA DISTRIBUIDORA TRUPER SUCURSAL MÉRIDA MPI CLAVE 33 #600-6202 LOCALIDAD ITZINCAB Y MUJASAY, TEL.: 999 912 2451
YUCATÁN SUCURSAL MERIDA MPI CLAVE 33 #600-6202 LOCALIDAD ITZINCAB Y MUJASAY, TEL.: 782 283 1800 / 926 8848
NARVÍA HERMÁNIETAS DE TEPIC SUCURSAL MÉRIDA CENTRO C.P. 42400, CIUDAD MÉRIDA #90, 18 MONTERREY PARKS. TEL.: 551 258 9835
MONTERÍA YAHUANICAS DE TEPIC SUCURSAL MÉRIDA CENTRO C.P. 42400, CIUDAD MÉRIDA #90, 18 MONTERREY PARKS. TEL.: 551 258 9835
OAXACA FIX HERMÁNIETAS SUCURSAL MÉRIDA AV. 20 DE NOVIEMBRE #1901, COL. CENTRO, C.P. 68300, TUTEPIC, OAX. TEL.: 287 106 2902
PUEBLA PUERAS HERMÁNIETAS SUCURSAL MÉRIDA AV. PUEBLA #2-A SAN LORENZO ALMECTLA, C.P. 72710, CIUDAD ALMECTLA, PUE.
QUERÉTARO AV. HERMÁNIETAS SA DE C.V. ENMIENDA, C.P. 76040, SAN JUAN DEL RIO, QRO. TEL.: 472 282 5447
INTIAMA ROO FIX HERMÁNIETAS SUCURSAL MÉRIDA AV. 19 DE ENERO #100, COL. BANCHOC, C.P. 78320, C.P. 77101 PLAZA DEL CARMEN, Q.R. TEL.: 984 262 3140
SINALOA SUCURSAL MÉRIDA AV. EJES KUMAMBE S/N #301, COL. AGUAENDA DELA MOA #2004, CIUDAD KUMAMBE, SINALOA, MEXICO. TEL.: 667 173 1939 / 173 8400
SONORA FIX HERMÁNIETAS SUCURSAL MÉRIDA AV. 19 DE ENERO #500, COL. BANCHOC, S/N. CENTRO C.P. 83000, M.L. 1, C.P. 83200, SON. TEL.: 664 413 3292
TABASCO SUCURSAL VILLAHERMOSA CALLE 100 LOTES 1 Y 2 MZ. #1, COL. INDUSTRIAL, 2A ETAPA C.P. 86100, VILLAHERMOSA, TAB. TEL.: 993 353 7244
TAMAULIPAS SERVICIOS Y HERMÁNIETAS INDUSTRIALES PARLO SIDAR #132, COL. BARRIO DE SAN BARTOLOME, C.P. 88030 SAN PEDRO DEL MONTE, TAMAULIPAS. TEL.: 222 271 7520
TLAXCALA TLAXCALA Y HERMÁNIETAS BVL. PRIMERA ESQ. HORNETIS S/N COL. PARLO SIDAR #132, COL. BARRIO DE SAN BARTOLOME, C.P. 99030 SAN PEDRO DEL MONTE, TAMAULIPAS. TEL.: 782 283 1800 / 926 8848
VERACRUZ VERACRUZ Y HERMÁNIETAS BVL. PRIMERA ESQ. HORNETIS S/N COL. PARLO SIDAR #132, COL. BARRIO DE SAN BARTOLOME, C.P. 99030 SAN PEDRO DEL MONTE, TAMAULIPAS. TEL.: 782 283 1800 / 926 8848
YUCATÁN SUCURSAL MÉRIDA MPI CLAVE 33 #600-6202 LOCALIDAD ITZINCAB Y MUJASAY, TEL.: 782 283 1800 / 926 8848





- Tenga cuidado de no obstruir las ranuras de ventilación.

Como sujetar adecuadamente la herramienta

1	1 400 / min
2	1 800 / min
3	2 800 / min
4	3 700 / min
5	4 500 / min
6	5 100 / min

④ Tabla de velocidades



• **Rapid Tethering** in espaldas, siquimientre jiribas tendrán que ser de fondo.


• **ATENCIÓN!** Asegúrate de que la almohadilla y la espalda estén alineadas y debidamente instaladas. De lo contrario, la espalda ocasionalmente una vibración pudiente causar la pérdida de control o la espalda perderá su apoyo.

• Para remover la espuma, simplemente jalela lo más dura por el borde.


Almohadillas de plástico

Montaje

TRUPEER PRO



- La pluma incluye tres almohadillas intercambiables:
- 1. Vino: para quitar rayones.
- 2. Almohadilla: para remover líneas finas.
- 3. Naranja: para rasparlo final.
- Para instalar la almohadilla se monta directamente al disco con fijación hook and loop (D).
- Las espesas para pulido (C) o cualquier otro accesorio para pulir se monta directamente al disco con fijación hook and loop (D).
- Para instalar la almohadilla se sucede el disco de fijación hook and loop de los demás.
- Para instalar la almohadilla se sucede el mango auxiliar en la almohadilla de los demás.




Almohadillas de pulido

Posiciones según su preferencia.

fríamente. Coloque el mango auxiliar en alguna de las 2

aségurese siempre de que el mango auxiliar (E) este instalado



Montaje del mango auxiliar

No utilice los tornillos/tapa que retira de la máquina.

tornillos y llaves incluidos.

• Automóvil firmemente el mango tipo D a la cabeza de la pulidora con los

• Mueva el mango al ángulo deseado.

• Alinee el mango tipo D (A) a la cabeza de la pulidora y hágalo coincidir

con los tornillos/tapa que viene en los orificios de

• Retire los tornillos/tapa que vienen en los orificios de

Montaje del mango tipo D

de las manecillas del reloj hasta que se asegure el disco.

• Automóvil utilizando la llave hexagonal girando en sentido


• Apriete para el tornillo.

2. Posicione el disco de modo que coincida el centro con el

• Coloque la pulidora boca arriba.

Instalación del disco con fijación hook and loop

Montaje



Partes

TRUPER PRO



ADVERTENCIA Al operar herramientas eléctricas en exteriores, utilice una extensión aerillizada marcada como "USO EXTERIOR" marca **VOLTÉCK**. Estas extensiones son especiales para el uso en exteriores y reducen el riesgo de sufrir una descarga eléctrica.

AWG = Calibre de cable estadounidense (American Wire Gauge). Referencia: NMX-J195-NCCE


* Se permite utilizar siempre que cumpla las extensiones mismas que tienen con un artefacto de protección contra sobrecorriente.

de 0 A hasta 10 A	18 AWG(*)	3 (uno a tierra)	16 AWG	14 AWG	12 AWG	14 AWG	16 AWG	18 AWG	16 AWG	14 AWG	12 AWG	10 A hasta 15 A	de 13 A hasta 20 A	de 10 A hasta 15 A	de 0 A hasta 10 A
-------------------	-----------	------------------	--------	--------	--------	--------	--------	--------	--------	--------	--------	-----------------	--------------------	--------------------	-------------------

Capacidad en	Número de	Conductores	Calibre de extensión	Amperes
			de 1,8 a 15 m	mayor de 15 m

Al usar un cable de extensión, asegúrese de usar el calibre suficiente para trasportar la corriente que se consume en herramienta. Un cable de un calibre inferior o de menor diámetro que el cable de la herramienta dependiendo de la longitud del cable y de la capacidad de amperes indicada en la placa de datos de la herramienta. Si tiene perdida de potencia y sobrecalefamiento del motor. La siguiente tabla muestra lo tanto que debe usarse.

Al usar un cable de extensión, asegúrese de usar el calibre suficiente para transportar la corriente que se consume en herramienta. Una herramienta que requiere más corriente que el cable de la herramienta.



ADVERTENCIA Las herramientas de doble aislamiento y aislamiento reforzado tienen conexión a tierra. Los cables de alimentación a las terminales, todos los circuitos de alimentación deben ser desconectados.

ADVERTENCIA Antes de conectar acceso a la llave, todos los circuitos de alimentación deben ser desconectados.



La construcción del aislamiento eléctrico de esta herramienta es alterada por salpicaduras o derriamamiento de líquidos durante su operación. No la exponga a la lluvia, liquidos o humedad.

Automatizado TRUPER, con el fin de evitar algún riesgo de sacudida o accidente considerable.

Si el cable de alimentación se daña, este debe ser reemplazado por el fabricante o Centro de Servicio.

La clase de aislamiento térmico de los devanados del motor: Clase E.

La clase de construcción de la herramienta es: Aislamiento reforzado.

El cable de alimentación tiene sujetacables tipo Y.

Diametro de orbita	• 15 mm	Excentricidad	• 75 mm
--------------------	---------	---------------	---------

Aislamiento	• Clase II	Grado IP	• IPX1
-------------	------------	----------	--------

Conductores	• 18 AWG x 2C con temperatura de aislamiento de 105 °C
-------------	--

Ciclo de trabajo	• 30 minutos de trabajo por 15 minutos de descanso. Máximo 3 horas diarias.
------------------	---

Velocidad	• 1400 r/min - 5 100 r/min
-----------	----------------------------

Potencia	• 900 W
----------	---------

Corriente	• 7,5 A
-----------	---------

Frecuencia	• 60 Hz
------------	---------

Tensión	• 127 V~
---------	----------

Discos	• 6" (15 cm)
--------	--------------

Descripción	• Pulidora de doble acción
-------------	----------------------------

Código	• 10233
--------	---------



A Realice **MANTENIMIENTO** periódico a su máquina (página 8).



A **RESPECTE LOS CICLOS DE TRABAJO.** 30 min de trabajo por 15 minutos de descanso. Máximo diario de 3 horas.

RECOMENDACIONES DE USO Y CUIDADOS

- 10 Poliza de garantía.
 - 9 Centros de servicio autorizados.
 - 8 Mantenimiento.
 - 7 Puesta en marcha.
 - 6 Montaje.
 - 5 Partes.
 - 5 Para uso de plásticos para autos.
 - 4 Advertencias de seguridad para herramientas eléctricas.
 - 3 Requerimientos técnicos.
 - 3 Especificaciones técnicas.
- A** **ATENCIÓN**

Indice

PERU TRUPER



Lea este instructivo por completo
antes de usar la herramienta.


ATENCIÓN

PULA-6A

Este instructivo es para:
Modelo Código
PULA-6A 102333

6" 900 W
150 mm Disco
Potencia

doble acción
Pulidora
Instructivo de



TRUPER® PRO

ESPAÑOL
ENGLISH