


Manual

Inverter Welders

40%
Work Cycle

Applies for:

Code	Model
13694	SOIN-160



SOIN-160



Read this manual thoroughly
before using the tool.



Technical specifications	3
Power Requirements	3
 General Power Tools Safety Warnings	4
 Safety Warnings for Inverter Welders	5
Parts	6
Installation	7
Start Up	8
Maintenance	10
Simbology	10
Troubleshooting	11
Notes	12
Authorized Service Centers	13
Warranty Policy	14

CAUTION

To gain the best performance of the tool, prolong the duty life, make the Warranty valid if necessary, and to avoid hazards of fatal injuries please read and understand this Manual before using the tool.

Keep this manual for future references.

The illustrations in this manual are for reference only. They might be different from the real tool.

Use and care recommendations

THERMAL PROTECT

When the machine overheats, the thermal protector will activate, turning the welder off and turning the LED light ALARM on.
Let the welder cool for 15 minutes and turn it back on.



It is recommended to use a 12 AWG extension cord and connect it to an INDEPENDENT CHARGING CENTER.



Perform periodic **MAINTENANCE** to your machine (page 10).

Technical specifications

 TRUPER®

SOIN-160

Code •	13694
Description •	Inverter Welder
Input	
Power •	220 V ~
Frequency •	50 Hz / 60 Hz
Current •	32 A
No. of Phases •	2 phase
Output	
Input Rated Capacity •	7.0 kVA
Open Circuit Voltage •	65 V c.c.
Current Range •	20 A - 160 A
Work Cycle •	40% 4 minutes' work per 6 minutes' rest. Output values specified are with a 68 °F Temperatures higher than the work cycle may be reduced.
Cooling Type •	Fan Forced
Weight •	8.6 lb
Output terminals •	3/8" quick connector
Insulation •	Class I
Conductors •	12 AWG x 3C with 221 °F insulation temperature Power cord grips: Type "Y". Build quality: Basic insulation. Thermal insulation winding: Class H

WARNING Avoid the risk of electric shock or severe injury. When the power cable gets damaged it should only be replaced by the manufacturer or at a  TRUPER® Authorized Service Center. The build quality of the electric insulation is altered if spills or liquid gets into the tool while in use. Do not expose to rain, liquids and/or dampness.


WARNING Before gaining access to the terminals all power sources should be disconnected.



Power Requirements

WARNING If faults or breakdowns happen. Ground connection offers a trajectory with minimum resistance for electric power. It reduces the risk of electric shock. This tool is built with a power cable with an earth conductor and a plug with ground connection. The plug shall be connected into a power outlet installed and grounded according to all local codes.

WARNING Do not modify the plug supplied. If the plug cannot be fitted to the socket, have a qualified electrician to install the suitable socket.



• When using the welder together with more tools using the same ground connect those in parallel, never connect a series.

CAUTION • The gauge of the ground conductor cable shall not be of a smaller gauge than the power supply cable.

CAUTION • Connection to the power supply shall only be carried out by a professional electrician.

CAUTION • Double check the input connection voltage stipulated in the welder nameplate matches the power supply voltage.

CAUTION • The power supply cord shall meet the following requisites:



Switch	≥30 A
Fuse (Work Rated Current)	30 A (*)
Electric Wire	≥2.5 mm ²

* The current for fuse fusion is double of its rated current.

• If extensions between the welder and the work piece are needed, the soldering cable gauge shall be increased to keep the welder energy output with a potential drop not higher than 4 V

⚠️ WARNING! Read carefully all safety warnings and instructions listed below. Failure to comply with any of these warnings may result in electric shock, fire and / or severe damage. Save all warnings and instructions for future references.

Work area

Keep your work area clean, and well lit.

Cluttered and dark areas may cause accidents.



Never use the tool in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.

Sparks generated by power tools may ignite the flammable material.



Keep children and bystanders at a safe distance while operating the tool.

Distractions may cause loss of control.

**Electrical Safety**

The tool plug must match the power outlet. Never modify the plug in any way. Do not use any adapter plugs with grounded power tools.



Modified plugs and different power outlets increase the risk of electric shock.

Avoid body contact with grounded surfaces, such as pipes, radiators, electric ranges and refrigerators.

The risk of electric shock increases if your body is grounded.

Do not expose the tool to rain or wet conditions.

Water entering into the tool increases the risk of electric shock.

Do not force the cord. Never use the cord to carry, lift or unplug the tool. Keep the cord away from heat, oil, sharp edges or moving parts.

Damaged or entangled cords increase the risk of electric shock.

When operating a tool outdoors, use an extension cord suitable for outdoor use.

Using an adequate outdoor extension cord reduces the risk of electric shock.

If operating the tool in a damp location cannot be avoided, use a ground fault circuit interrupter (GFCI) protected supply.

Using a GFCI reduces the risk of electric shock.

Personal safety

Stay alert, watch what you are doing and use common sense when operating a tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.

A moment of distraction while operating the tool may result in personal injury.

Use personal protective equipment. Always wear eye protection.

Protective equipment such as safety glasses, anti-dust mask, non-skid shoes, hard hats and hearing protection used in the right conditions significantly reduce personal injury.



Prevent unintentional starting up. Ensure the switch is in the "OFF" position before connecting into the power source and / or battery as well as when carrying the tool.

Transporting power tools with the finger on the switch or connecting power tools with the switch in the "ON" position may cause accidents.

Remove any wrench or vice before turning the power tool on.

Wrenches or vices left attached to rotating parts of the tool may result in personal injury.

Do not overreach. Keep proper footing and balance at all times.

This enables a better control on the tool during unexpected situations.

Dress properly. Do not wear loose clothing or jewelry. Keep hair, clothes and gloves away from the moving parts.

Loose clothes or long hair may get caught in moving parts.



If you have dust extraction and recollection devices connected onto the tool, inspect their connections and use them correctly.

Using these devices reduce dust-related risks.

Power Tools Use and Care

Do not force the tool. Use the adequate tool for your application.



The correct tool delivers a better and safer job at the rate for which it was designed.

Do not use the tool if the switch is not working properly.

Any power tool that cannot be turned ON or OFF is dangerous and should be repaired before operating.

Disconnect the tool from the power source and / or battery before making any adjustments, changing accessories or storing.

These measures reduce the risk of accidentally starting the tool.

Store tools out of the reach of children. Do not allow persons that are not familiar with the tool or its instructions to operate the tool.



Power tools are dangerous in the hands of untrained users.

Service the tool. Check the mobile parts are not misaligned or stuck. There should not be broken parts or other conditions that may affect its operation. Repair any damage before using the tool.

Most accidents are caused due to poor maintenance to the tools.



Keep the cutting accessories sharp and clean.

Cutting accessories in good working conditions are less likely to bind and are easier to control.

Use the tool, components and accessories in accordance with these instructions and the projected way to use it for the type of tool when in adequate working conditions.

Using the tool for applications different from those it was designed for, could result in a hazardous situation.

Service

Repair the tool in a **TRUPER® Authorized Service Center** using only identical spare parts.

This will ensure that the safety of the power tool is maintained.



Children or people with reduced physical, sensory or mental capabilities shall not operate the tool, neither inexperienced people or without knowledge in the use of the tool, unless supervised by a person responsible of their safety or if receiving previous instructions about the tool operation.

Children shall be kept under supervision to double-check they will not play with the tool. Tight supervision shall be used with children or disabled persons to prevent from using or being close to any household tool.

Safety Warnings for Inverter Welders



Protection Equipment for Welding

- ⚠ WARNING** • Wear a welding mask to protect eyes and face when soldering. Assure the mask protective glass shade is adequate for the soldering process to carry out.
- ⚠ CAUTION** • Wear leather gloves specially made for welding as well as leather dungarees and gaiter.
- Wear robust clothing and long sleeves made of fire-resistant materials such as wool or leather.
 - Use special screens or curtains to insulate the work place from passersby, to protect them from sparks, flares and slag originated by the soldering process.
 - Benches and work tables where work pieces shall rest, must have orifices or slots that can easily let through residues originated by the soldering process.



Prevent Electric Shock

- ⚠ CAUTION** • Verify there is a safe connection for the input and output cables. They shall be correctly insulated and the connections in good repair (check and eliminate any possibility of electric shock).
- ⚠ CAUTION** • Double check the welder is plugged to a reliable ground connection.
- ⚠ CAUTION** • Do not expose the welder to rain or humidity.
- ⚠ CAUTION** • The user shall be insulated from the work piece and ground connection stepping onto insulating and dry mats.
- ⚠ DANGER** • For any reason touch the two poles in the welder circuit (welding stick and work piece).
- ⚠ WARNING** • Do not try to adjust the welder current when carrying out a soldering job.
- ⚠ CAUTION** • Connect the ground clamp to the work piece as close as possible to the welding zone. This prevents the current to flow long distances and eliminate the possibility of short circuit.
- ⚠ WARNING** • The work piece shall make contact with the ground connection clamp before operating the welder. Do not disconnect until finishing welding because it can lead to an electric discharge and severe injury.
- ⚠ WARNING** • Disconnect the welder from the power supply before carrying any maintenance jobs.



Fire Prevention

- ⚠ CAUTION** • Have always handy a fire extinguisher in good conditions.
- ⚠ WARNING** • There shall not be flammable or explosive materials in the work area (no less than 36'). Do not carry out soldering jobs where the sparks can reach or fall onto flammable or explosive materials.



Prevent Health Risks








- ⚠ WARNING** • Vapor and gases produced while soldering is dangerous to your health. Work in well ventilated areas or with adequate ventilation systems.
- ⚠ WARNING** • Do not breath in smokes and gasses emanated from the soldering process. Keep your head away from vapors.
- ⚠ DANGER** • If ventilation is poor use an adequate autonomous breathing device because the gases generated when soldering may displace air and cause a fatal accident.
- ⚠ CAUTION** • Do not operate the welder near de-greasing agents, cleaning products or aerosol containers. Heat and radiation from the welding process may react to those vapors forming toxic gases.
- ⚠ CAUTION** • Avoid soldering metals covered in lead, zinc or cadmium. Those materials generate toxic gases. Otherwise, remove the covering from the welding area. Make sure the work area is well ventilated or wear an adequate autonomous breathing device.



Prevent Injuries and Accidents

- ⚠ WARNING** • Risks of electric shock:
An electric shock coming from the soldering electrode may cause death. Do not weld under rain or snow. Do not touch the electrode with your bare hands. Do not wear damp or damaged gloves. Personal protection against electric shock: insulation from the work piece. Do not open the equipment enclosure. Do not weld on top of drums or any closed container.
- ⚠ WARNING** • Soldering sparks may cause explosion or fire.
- ⚠ WARNING** • Risks generated by the welding arc:
Radiation coming out from the arc may burn eyes and damage skin. Wear face mask and protection glasses. Wear hearing protection and protective clothes that protect skin up to the neck. Wear full-body protective clothes.
- ⚠ WARNING** • Risk induced by electro-magnetic fields:
Welding current produces electro-magnetic fields. Do not use this power source if having a medical implant. Never roll up the welding cable around your body. Set together and parallel both welding cables so the fields of each cable counteract.
- ⚠ WARNING** • Do not use the welder power source to de-ice pipes.
- ⚠ CAUTION** • Never allow unexperienced people to dismantle or regulate the welder.
- ⚠ WARNING** • Double check that the operator and the welder are away from the sparks and residues trajectory originated by the soldering process.
- The welder shall be operated in a place protected from sun and rain. Away from places where violent vibrations are present.
 - Store the welder in a place free of humidity with a range of temperature from -13 °F to 131 °F
- ⚠ CAUTION** • To prevent rollover, the equipment shall be inclined 10° maximum.
- There shall be a 11.8" space around the welding machine to allow good ventilation.
- ⚠ CAUTION** • Double check no foreign metal piece is inside the welder.
- ⚠ WARNING** • Any problem with the welder that cannot be fixed by the operator making the adjustments needed for a good welding job shall be carry out in a **TRUPER** Authorized Service Center. For any reason try to open the welder housing to carry out any type of maintenance.





To get better results use
a **TRUPER**® cable set with
soldering clamp **CAB-200**

Connections

CAUTION To prevent electric shock please consult information in the "Electrical Requirements" section in pages 3 and 5.

- The fast connections in the electrode holder and the grounding clamp are inserted and turned one quarter of a turn in a clockwise direction in the outlets found in the front panel to be secured.

Inverse Polarity (A)

- Connect the grounding clamp cable to the negative (-) clamping screw in the welder.
- Connect grounding clamp cable (C) to the work piece.
- Connect the electrode holder cable to the positive (+) clamping screw in the welder.

This configuration generates more heat in the electrode, thus producing more heat with basic electrodes making it ideal to weld thick pieces.



Direct Polarity (B)

- Connect the grounding clamp cable to the outlet (+).
- Connect the grounding clamp (C) to the work piece.
- Connect the electrode holder to the outlet (-).

This configuration generates more heat in the work piece producing less warping of the piece and narrower cords making it ideal to solder thin pieces.


- Connect the feeding cable (D) to the network into the corresponding voltage.

WARNING Before using the welder, it shall be correctly grounded. Failure to comply with this warning propitiates severe personal injuries.




Preparation

- Only experience, practice and care can guarantee a good welding job.
- The factors intervening in the welding process are many: required current, distance between the electrode and the work piece, soldering speed and direction, thickness and type of the material, the work piece position, electrode angle and also gauge, type of material and electrode covering. Therefore, it is advisable that before welding to carry out practice some in scrap material to determine which are the specific requirements needed for the job to perform.
- The area on the work piece where the soldering will be applied shall be clean, free of rust and paint.
- Joints between sheets with gauges higher than 1/8" shall be beveled to have an adequate weld (**A**).



Welding

- Set the switch (**B**) into the ON (**I**) position. The indicating light will be illuminated.
- Turn the current adjusting control (**C**) until reaching the amperes needed for the job.
- Hold the electrode holder or torch as comfortable as possible. Bear in mind that during the welding process, the angle, movement and distance regarding the work piece shall be constant and uniform.
- Aim the electrode tip to the joint to be worked with to generate the arc and start welding.
- Once the arc is lit start soldering keeping always the electrode tip 0.08" away from the work piece. If you make the weld having the electrode supported on the work piece, it could adhere and the weld would have a low quality.
- In case of overheating, the welder will stop functioning and the thermal protection indicator light (**D**) will be lit. Do not turn off the welder and wait until the indicator light is off to use it again.



Supplies

For coated electrode processes (SMAW)

Type: 6013 / 6011
Diameter: 3/32", 1/8", 5/32"

Type: 7018
Diameter: 3/32", 1/8", 5/32"

Slag Removal


- Upon finishing welding, use the wire brush included to remove the slag from the weld bead surface.
- CAUTION** • Wait until the slag has cooled down and hardened to remove it.
- When hitting or brushing slag to remove it there can be particles flying out. Wear eye protection and keep bystanders away.



Electrode Replacement

- When the electrode has been consumed 0.4" to 0.8" away from the electrode holder, it is necessary to replace it with a new one to keep on welding.
- CAUTION** • Electrodes are burned in high temperature. Do not try to manipulate the remains of the electrode with your hand. Set the remains in a metal container.
- Open the electrode holder nipper to hold the new electrode by the end that is not covered. Do not hold the electrode by the covered part.

Examples of welding



- The correct use and regular cleansing extend the useful life of the welder.

CAUTION • Only qualified personnel shall carry out repairs. We recommend visiting a **C TRUPER®** Authorized Service Center to repair your welder, get supplies or accessories.

Regular Maintenance

- Clean dust from the welder with compressed air. If there is too much dust present, clean immediately. Under normal conditions clean once a year. If the welder is exposed to a lot of dust, cleaning should be carried out every three months.
- Altogether with cleaning make a checkup to assure there are no loose parts or components in the welder.
- Keep the welder plug in good repair.
- The plug shall be checked before each use.

Storage

- In the event the welder will be stored a long period of time, keep it in a dry, well ventilated place to prevent humidity getting inside, or to generate rust or toxic gas. Storage temperature vary between -13 °F to 131 °F and relative humidity shall not be over 90%.

Symbology


---	DC symbol
	Electric arc manual welding with coated electrode
	Inert metal – active gas welding, including the use of flux core
	Input circuit, single-phase alternating current and rated frequency symbol
x	Work cycle symbol (service factor)
I ₂	Nominal welding current symbol
U ₂	Conventional load voltage symbol
U _{0...V}	Rated open circuit voltage
U _{1...V}	Rated power voltage
I _{1 max...A}	Maximum rated power
I _{1 eff...A}	Maximum effective power
IP	Protection degree (solid objects and water submersion)
	Converter - transformer - single-phase static frequency rectifier
~	AC symbol
SMAW	Electric-arc manual welding with coated electrodes
TIG	Gas shielded arc welding system
MIG	Metal inert gas welding
	Tungsten inert gas welding

Troubleshooting



Problem	Cause	Solution
The thermal protection light is ON.	<ul style="list-style-type: none">The welder has no adequate ventilation.Environment temperature is too high.The welder has been used longer than the recommended work cycle.	<ul style="list-style-type: none">Keep the welder least 11.8" away from any walls at to allow air circulation.The welder will recuperate once the temperature gets back to the right range to operate.The welder will recuperate once the temperature gets back to the right range to operate.
The current adjusting control is not working.	<ul style="list-style-type: none">The potentiometer is broken.	<ul style="list-style-type: none">Go to a TRUPER Authorized Service Center to replace the potentiometer.
The fan is not working or turns very slowly.	<ul style="list-style-type: none">Faulty switch.Faulty fan.Fault in the connections.	<ul style="list-style-type: none">Go to a TRUPER Authorized Service Center to replace the switch.Go to a TRUPER Authorized Service Center to repair the fan.Check all the connections.
There is no open circuit voltage.	<ul style="list-style-type: none">High Voltage, low voltage or one phase is missing.The welder is overheating.Faulty switch.	<ul style="list-style-type: none">The welder will recuperate once the temperature is back into the adequate range to operate.Go to a TRUPER Authorized Service Center to replace the switch.
The electrode holder is too hot; connections + and - are hot.	<ul style="list-style-type: none">The electrode capacity is too low.The cable gauge is too small.Loose connections.More resistance between the electrode holder and the cable.	<ul style="list-style-type: none">Replace the electrode holder with another one with more capacity.Replace the cable with another one within the requirements (see page 3).Clean the rust accumulation and tighten the connections.Clean the rust accumulation and tighten the connections.
Energy source is off.	<ul style="list-style-type: none">The welder is hover-heated.	<ul style="list-style-type: none">There is no fault. It is normal that power supply gets cut when the welder goes above its normal working temperature. Wait until the temperature is back to the adequate working range to turn it on again.

If after all the recommended actions have been carried out the problems persist, contact a **TRUPER** Authorized Service Center.



Authorized Service Centers



In the event of any problem contacting a Truper Authorized Service Center, please see our webpage www.truper.com to get an updated list, or call our toll-free numbers **800 690-6990** or **800 018-7873** to get information about the nearest Service Center.

AGUASCALIENTES	DE TODO PARA LA CONSTRUCCIÓN GRAL. BARRAGÁN #1201, COL. GREMIAL, C.P. 20030, AGUASCALIENTES, AGS. TEL.: 449 994 0537
BAJA CALIFORNIA	SUCRAL TIJUANA AV. LA ENCANTADA, LOTE #5, PARQUE INDUSTRIAL EL FLORIDO II, C.P. 22244, TIJUANA, B.C. TEL.: 664 969 5100
BAJA CALIFORNIA SUR	FIX FERRETERÍAS FELIPE ANGELES ESQ. RUIZ CORTÍNEZ S/N, COL. PUEBLO NUEVO, C.P. 23670, CD. CONSTITUCIÓN, B.C.S. TEL.: 613 132 1115
CAMPECHE	TORNILLERÍA Y FERRETERÍA AAA AV. ALVARO OBREGÓN #524, COL. ESPERANZA C.P. 24080 CAMPECHE, CAMP. TEL.: 981 815 2808
CHIAPAS	FIX FERRETERÍAS AV. CENTRAL SUR #27, COL. CENTRO, C.P. 30700, TAPACHULA, CHIS. TEL.: 962 118 4083
CHIHUAHUA	SUCRAL CHIHUAHUA AV. SILVESTRE TERRAZAS #12-11, PARQUE INDUSTRIAL BAFAR, CARRETERA MÉXICO CUAHUTÉMOC, C.P. 31415, CHIHUAHUA, CHIH. TEL. 614 434 0052
MEXICO CITY	FIX FERRETERÍAS EL MONSTRUO DE CORREDOR, CORREDOR # 22, COL. CENTRO, C.P. 06060, CUAHUTÉMOC, CDMX. TEL: 55 5522 5031 / 5522 4861
COAHUILA	SUCRAL TORREÓN CALLE METAL MECÁNICA #280, PARQUE INDUSTRIAL ORIENTE, C.P. 27278, TORREÓN, COAH. TEL.: 871 209 6823
COLIMA	BOMBAS Y MOTORES BYMTESA DE MANZANILLO BLVD. MIGUEL DE LA MADRID #190, COL. 16 DE SEPTIEMBRE, C.P. 28239, MANZANILLO, COL. TEL.: 314 332 1986 / 332 2013
DURANGO	TORNILLOS ÁGUILA, S.A. DE C.V. MAZURIÓ #200, COL. LUIS ECHEVERRÍA, DURANGO, DGO. TEL.: 618 817 1946 / 618 818 2844
ESTADO DE MÉXICO	SUCRAL CENTRO JILOTEPEC PARQUE INDUSTRIAL 1, PARQUE INDUSTRIAL JILOTEPEC, JILOTEPEC, EDO. DE MÉX. C.P. 54257, TEL: 761 782 9101 EXT. 5728 Y 5102
GUANAJUATO	CÍA. FERRETERA NUEVO MUNDO S.A. DE C.V. AV. MÉXICO - JAPÓN #225, CD. INDUSTRIAL, C.P. 38010, CELAYA, GTO. TEL.: 461 617 7578 / 79 / 80 / 88
GUERRERO	CENTRO DE SERVICIO ECLIPSE CALLE PRINCIPAL MZ.1 LT. 1, COL. SANTA FE, C.P. 39010, CHILPANCINGO, GRO. TEL.: 747 478 5793
HIDALGO	FERREPRESOS S.A. DE C.V. LIBERTAD ORIENTE #504 LOCAL 30, INTERIOR DE PASAJE ROBLEDO, COL. CENTRO, C.P. 43600, TULANCINGO, HGO. TEL.: 775 753 6615 / 775 753 6616
JALISCO	SUCRAL GUADALAJARA AV. ADOLFO B. HORN # 6800, COL. SANTA CRUZ DEL VALLE, C.P. 45655, TLAJOMULCO DE ZUÑIGA, JAL. TEL.: 33 3606 5285 AL 90
MICHOACÁN	FIX FERRETERÍAS AV. PASEO DE LA REPÚBLICA #3140-A, COL. EX-HACIENDA DE LA HUERTA, C.P. 58050, MORELIA, MICH. TEL.: 443 334 6858
MORELOS	FIX FERRETERÍAS CAPITÁN ANZURES #95, ESQ. JOSÉ PERDIZ, COL. CENTRO, C.P. 62740, CUAUTLA, MOR. TEL.: 735 352 8931
NAYARIT	HERRAMIENTAS DE TEPIC MAZATLÁN #117, COL. CENTRO, C.P. 63000, TEPIC, NAY. TEL.: 311 258 0450
NUEVO LEÓN	SUCRAL MONTERREY CARRETERA LAREDO #300, 1B MONTERREY PARKS, COLONIA PUERTA DE ANÁHUAC, C.P. 66052, ESCOBEDO, NUEVO LEÓN, TEL.: 81 8352 8791 / 81 8352 8790
OAXACA	FIX FERRETERÍAS AV. 20 DE NOVIEMBRE #910, COL. CENTRO, C.P. 68300, TUXTEPEC, OAX. TEL.: 287 106 3092
PUEBLA	SUCRAL PUEBLA AV. PERIFÉRICO #2-A, SAN LORENZO ALMECATLA, C.P. 72710, CUAUTLA, PUE. TEL.: 222 282 8282 / 84 / 85 / 86
QUERÉTARO	ARU HERRAMIENTAS S.A. DE C.V. AV. PUERTO DE VERACRUZ #110, COL. RANCHO DE ENMEDIO, C.P. 76842, SAN JUAN DEL RÍO, QRO. TEL.: 427 268 4544
QUINTANA ROO	FIX FERRETERÍAS CARRETERA FEDERAL MZ. 46 LT. 3 LOCAL 2, COL. EJIDAL, C.P. 77710 PLAYA DEL CARMEN, Q.R. TEL.: 984 267 3140
SAN LUIS POTOSÍ	FIX FERRETERÍAS AV. UNIVERSIDAD #1850, COL. EL PASEO, C.P. 78320, SAN LUIS POTOSÍ, S.L.P. TEL: 444 822 4341
SINALOA	SUCRAL CULIACÁN AV. JESÚS KUMATE SUR #4301, COL. HACIENDA DE LA MORA, C.P. 80143, CULIACÁN, SIN. TEL.: 667 173 9139 / 173 8400
SONORA	FIX FERRETERÍAS CALLE 5 DE FEBRERO #517, SUR LT. 25 MZ. 10, COL. CENTRO, C.P. 85000, CD. ÓBREGÓN, SON. TEL.: 644 413 2392
TABASCO	SUCRAL VILLAHERMOSA CALLE HELIO LOTES 1, 2 Y 3 MZ. #1, COL. INDUSTRIAL, 2A ETAPA, C.P. 86010, VILLAHERMOSA, TAB. TEL.: 993 353 7244
TAMAULIPAS	VM ORINGS Y REFACCIONES CALLE ROSITA #527 ENTRE 20 DE NOVIEMBRE Y GRAL. RODRÍGUEZ, FRACC. REYNOSA, C.P. 88780, REYNOSA, TAMS. TEL.: 899 926 7552
TLAXCALA	SERVICIOS Y HERRAMIENTAS INDUSTRIALES PABLO SIDAR #132, COL. BARRIO DE SAN BARTOLOMÉ, C.P. 90970, SAN PABLO DEL MONTE, TLAX. TEL.: 222 271 7502
VERACRUZ	LA CASA DISTRIBUIDORA TRUPER BLVD. PRIMAVERA ESQ. HORTENSIA S/N, COL. PRIMAVERA C.P. 93508, POZA RICA, VER. TEL.: 782 823 8100 / 826 8484
YUCATÁN	SUCRAL MÉRIDA CLLAE 33 #602, LOCALIDAD ITZINCAB Y MULSAY, MPIO. UMÁN, C.P. 97390, MÉRIDA, YUC. TEL.: 999 912 2451

Code

13694

Model

SOIN-160

Brand **TRUPER®**

This product is guaranteed for 1 year. To make the warranty valid or purchase parts and components you must present the product in Corregidora 22, Col. Centro, Alc. Cuauhtémoc, CDMX C.P. 06060 or at the establishment where you purchased it, or at any Truper® Service Center listed in the annex to the warranty policy and/or in www.truper.com. Transportation costs resulting from compliance of this warranty will be covered by 

For questions or comments, call **800-690-6990**. Made in China. Imported by Truper S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257

**1**
YEAR

Stamp of the business. Date of purchase:

Sello del establecimiento comercial. Fecho de compra:

Industria, Parque Industrial Jiutepec, Jiutepec, Ed. de Mex. C.P. 54257
 Para dudas o comentarios, llame al 800-690-6990. Hecho en China. Importado por Truper S.A. de C.V. Parque
 industrial Jiutepec, Jiutepec, Jiutepec, Ed. de Mex. C.P. 54257.
 Para dudas o comentarios, llame al 800-690-6990. Hecho en China. Importado por Truper S.A. de C.V. Parque
 industrial Jiutepec, Jiutepec, Jiutepec, Ed. de Mex. C.P. 54257.

Sello de garantía de cumplimiento de la legislación de protección de consumidores. Los gastos de transporte que resulten para su cumplimiento serán cubiertos por TRUPER.

Poliza de garantía V/O en www.truper.com. Los gastos de transporte que resulten para su cumplimiento se establecerán dentro lo compre, o en algún Centro de Servicio Truper®, de los establecidos en el anexo de la poliza de garantía V/O en www.truper.com.

Este producto es la garantía otorgada por I año. Para hacer válida la garantía o adquirir piezas y componentes debrá presentar el producto en Corregidora 22, Col. Centro, Alc. Cuauhtémoc, CDMX C.P. 06060 o en el establecimiento donde lo compró, o en algún Centro de Servicio Truper®, de los establecidos en el anexo de la poliza de garantía V/O en www.truper.com.

AÑO




Código	Modelo	Marca	Serie
13694	S01N-160	TRUPER®	

**Poliza de
garantía**

TRUPER®

En caso de tener algún problema para contactar un Centro de Servicio Autorizado Truper®, consulte nuestra página www.truper.com donde obtendrá un listado actualizado, o llame al: 800 690-6990 ó 800 018-7873 donde le informarán cuál es el Centro de Servicio más cercano.

AGUASCALIENTES	DE TODO PARA LA CONSTRUCCIÓN	GRAL. BARAGNA #1201, C.C. GERMÁN, C.P. 20030.	ACUAS CALCULINAS, AGS, TEL.: 449 994 0557	TEL.: 66 995 5100	FLOREDO II, C.P. 22244, TIJUANA, B.C.	TELÉFONOS FEDERATIVOS S.A., RUIZ CORTEZ S/N, C.P. PUEBLO	CALIFORNIA SUR	BAJA	TORNILLERA Y FERRETERÍA AAA	AV. ALVARO OBREGÓN #24, C.C. ESPERANZA	C.P. 24080 CAMPECHE, CAMP. TEL.: 981 815 2808	TAPACHULA, CHIS, TEL.: 962 118 4085	COL. SILENTIA, MEXICO CITY, TEL.: 55 5522 5031 / 5522 44861	TEL.: 55 209 68 23	COLUMIA BOMBA Y MOTORES BMTESA DE MANZANILLO	JUÁREZ, MEXICO #200, COL. LUIS ECHÉVERRÍA DURANGO,	DGCO, TEL.: 618 817 1946 / 618 818 24844	TORNILLERA NUEVO MUNDO S.A. DE C.V.	AV. MECIC - APDO. #225, C.D. INDUSTRIAL, C.P. 83010.	GUANAJAUTA CELAYA, GTO, TEL.: 461 67 7578 / 79 / 80 / 88	CHIAPAS FIX FERRETERÍAS	CALLE PRINCIPAL MZ.1 LT. 1, COL. SANTA FE, C.P. 39010.	CENTRO DE SERVICIO CELESTE	CALLE PRINCIPAL MZ.1 LT. 1, COL. SANTA FE, C.P. 39010.	JALISCO	AV. FERRERIAS GUADALAJARA	VALLE DE LA MONTAÑA C.P. 45349 AL 90	MICHOCÁN																																																																																																																																																																										
MICHOCÁN	AV. FERRERIAS GUADALAJARA	VALLE DE LA MONTAÑA C.P. 45349 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90	TEL.: 33 3606 5285 AL 90



Notas

• TRUPER®

TRUPER®

Solución de problemas

Solución

Problema Causa Solución

- La soldadora no cuesta con ventilación. • Mantenga la soldadora apartada de cualquier pared al menos 30 cm para permitir que el aire circule. • Temperatura ambiente muy alta. • La soldadora es utilizada por más tiempo del recomendado en su ciclo de trabajo.
- El control de ajuste no funciona. • Ajusta a un Centro de Servicio Autorizado • TRUPER® para reemplazar el potenciómetro.

- El control de ajuste no funciona. • Ajusta a un Centro de Servicio Autorizado • TRUPER® para reemplazar el potenciómetro.

- El ventilador no funciona o gira muy lentamente. • Ajusta a un Centro de Servicio Autorizado • TRUPER® para reemplazar el interruptor.

- No hay tensión de circuito abierto. • Tensión alta, tensión baja o falta una fase. • La soldadora se recalentará una vez que la temperatura regresa al rango adecuado para operar.

- El porta electrodo se recalienta. • La capacidad del porta electrodo es muy débil. • Reemplaza el cable por otro de mayor capacidad.

- Los cables demasados. • Las conexiones + y - se separan. • La medida del cable es muy pequeña.
- La soldadora se sobrecalienta. • Reemplaza el cable por otro de mayor capacidad.
- La conexión flotas. • La medida del cable es muy pequeña.
- Mayor resistencia entre el porta electrodo y el cable.
- La soldadora se ha sobrecalentado.

- La fuente de energía se corta. • La soldadora se ha sobrecalentado.
- No hay falla. Es normal que el suministro de energía sea nula.
- El rango adecuado de trabajo para poder encenderla normalmente es de 10°C a 40°C. Existe una regla que dice que la temperatura ambiente debe ser de 10°C a 30°C para que la soldadora funcione bien.

Si los problemas persisten a pesar de realizar las acciones correctivas recomendadas, contacte a un Centro de Servicio Autorizado **TRUPER®**.

contáctese a un Centro de Servicio Autorizado **TRUPER®**.

Si los problemas persisten a pesar de realizar las acciones correctivas recomendadas,

—	Símbolo de corriente alterna	
~	Soldadura manual por arco con protección revestida	
TIG	Sistema de soldadura al arco con protección gaseosa	
MIG	Soldadura por gas interior de metal	
CONVETRIDER	Soldadura con gas interior de tungsteno	
IP	Gradó de protección (objetos sólidos e ingresos al agua)	
I _{max} ...A	Corriente de alimentación máxima efectiva	
I _{nom} ...A	Tensión nominal de alimentación	
U _{nom} ...V	Tensión nominal del circuito abierto	
U ₀ ...V	Símbolo de la tensión de carga convencional	
U ₂	Símbolo de la corriente de la soldadura nominal	
X	Símbolo del ciclo de trabajo (factor de servicio)	
CIRCUITO DE ENTRADA	Circuito de entrada, símbolo para corriente alterna monofásica y frecuencia nominal	
—	Soldadura de metal interior y gas activo induyendo el uso de núcleo fundente	
—	Soldadura manual por arco eléctrico con electrodo revestido	
—	Corriente directa	

Simbología

• En caso que la soldadura vaya a estar almacenada por un período largo de tiempo, se debe mantener en un sitio seco y bien ventilado para evitar que le entre humedad, se debe tener en cuenta que la humedad relativa no debe ser superior a 90%.

- La clavija debe revisarse antes de cada uso.
- Mantenga la clavija del cable de la soldadura en buen estado.
- Aségúrese que no haya partes o componentes sueltos en la soldadura.
- Junto con la limpieza se debe realizar una revisión para detectar defectos en la soldadura.
- El técnico de servicio debe limpiar el polvo de la soldadura con aire comprimido. En caso haber mucho polvo, se debe limpiar de inmediato. Bajo condiciones normales se debe limpiar de inmediato. Si es necesario que la soldadura sea expuesta a mucho polvo, la limpieza debe realizarse cada tres meses.
- Los tornillos que no hayan sido utilizados deben revisarse cada tres meses.
- La limpieza debe realizarse cada tres meses.


Almacenamiento

Mantenimiento regular

- El uso correcto y una limpieza regular prolongan la vida útil de la soldadura.
- AutORIZADO  TRUPER®. Solo personal calificado debe hacer las reparaciones. Es recomendado visitar un Centro de Servicio.

Mantenimiento

TRUPER®



Ejemplos de soldadura

sostenerse el electrodo por la parte recubierta.

electrodo nuevo por el extremo sin recubrimiento. No se recomienda usar el portaelectrodo para soldar.

- Abrir la tenaza del portaelectrodo para sostener el con la mano. Ponga los resortes en un conector de metal tempreratura. No intente manipular los resortes del electrodo para poder seguir soldando.

A TENCIÓN • El electrodo se quemará si no nuevo del portaelectrodo, es necesario cambiarlo por uno nuevo para poder seguir soldando.

• Cuando el electrodo se ha consumido de 1 cm a 2 cm



Reemplazo de electrodo

Diametro: $\frac{3}{32}$ " (2.5 mm), $\frac{1}{8}$ " (3 mm), $\frac{5}{32}$ " (4 mm)
Tipo: 7018

Diametro: $\frac{3}{32}$ " (2.5 mm), $\frac{1}{8}$ " (3 mm), $\frac{5}{32}$ " (4 mm)
Tipo: 6013 / 6011

Para procesos de electrodo revestido (SMAW)

Consumible



A

Puesta en marcha

Preparación para los usos y mantenimiento a las personas que manejan soldadoras despedidas. Utilice

- Al soldar o cepillar la escoria para retirarla.

A TENCIÓN • Espera a que la escoria de la superficie del alambre endurecido para retira la escoria de la superficie del cordón de soldado.

• Al terminar el trabajo de soldado, utilice el cepillo de alambre endurecido para retra la escoria de la superficie del

Retiro de escoria

Indicadora se apague para volverla a utilizar.

encendida, no apague la soldadora y espere a que la función de la luz indicadora de protección térmica (D) se

• En caso de sobrecalentamiento la soldadora dejará de soldar.

indicadora se tra la pieza de trabajo otra alternativa y la

manejarlo simple la punta del electrodo a 2 mm de la pieza de trabajo. Si realiza la soldadura con el electrodo una vez que el arco eléctrico comience a soldar.

• Diríjase la punta del electrodo hacia la unión a trabajar para generar un efecto eléctrico y comience a soldar.

• La pieza de trabajo debe ser constante y uniformes.

• Solvete la punta del electrodo donde durante el proceso de soldado, tome en cuenta que la medida más comoda es amparaje requerido para el trabajo.

• Girle el control de ajuste de corriente (C) hasta alcanzar la luz indicadora de energía se encienda.

• Coloque el interruptor (B) en posición de encendido (I).

Soldadura

sea adecuada (A).

3 mm ($\frac{1}{8}$ "), deben de ser biseladas para la soldadura

• Las uniones entre láminas con calibres mayores de soldadura debe de estar limpia, libre de óxido y pintura.

• El área de las piezas donde se aplicada la resumimientos específicos del trabajo a realizar.

material de desecho para determinar cuáles son los

que antes de realizar una soldadura realice prácticas en y recubrimiento del electrodo. Por lo que se recomienda


trabajo, agujero del material y además el taller, material de soldado, grosor y tipo del material, posición de la pieza de


electrodo y la pieza de trabajo, velocidad y dirección de son muchos: comience rellenar en el proceso de soldadura

• Los factores que intervienen en la puesta en marcha

• Solo con experiencia, práctica y cuidado se puede garantizar un buen trabajo de soldadura.

Preparativos





Partes

TRUPER®

- En caso de requerir extensión entre la soldadora y la pieza de trabajo se debe aumentar el calibre del cable de soldar para mantener la salida de energía de la soldadora con una calida potencial no mayor a 4 V


- A) ATENCIÓN** • Es utilizado para solicitar la atención de los destinatarios y para recordarles que tienen que cumplir con lo que se les pide.

B) ATENCIÓN • Es utilizada para señalar que se deben cumplir las instrucciones dadas.

C) ATENCIÓN • Es utilizada para recordar a los destinatarios que tienen que cumplir con lo que se les pide.

D) ATENCIÓN • Es utilizada para recordar a los destinatarios que tienen que cumplir con lo que se les pide.

E) ATENCIÓN • Es utilizada para recordar a los destinatarios que tienen que cumplir con lo que se les pide.



A ADVERTENCIA No modifique la clavija provista. Si la clavija no ajusta a la salida, adquiera la salida apropiada instalada por un electricista calificado. Los cables usados deben ser cuadrados que se encuentren insulados y aislados con todos los conectores y en condición de ser seguros. Una devolución con conexión a tierra a la clavija debe estar incluida en una descripción eléctrica. Esta herramienta debe equiparse con un cable eléctrico que cumpla con las normas de seguridad establecidas para su uso en el hogar o en el exterior.

Reduquerímenos eléctricos

Estructura	
Código	Descripción
13694	Soldadora inversora
Conductores	12 AWG x 3C con temperatura de almacenamiento de 105 °C
Almacenamiento	Clase I
Bornes de salida	Conector rápido 3/8" (9.5 mm)
Peso	3.9 kg
Tipo de enfriamiento	Forzado con ventilador
Ciclo de trabajo	40% 4 min de trabajo por 6 min de descanso.
Rango de corriente	20 A - 160 A
Tensión de circuito abierto	65 V CC.
Capacidad nominal de entrada	70 kVA
Salida	
No. de fases	2 Fases
Corriente	32 A
Frecuencia	50 Hz / 60 Hz
Tensión	220 V ~

- ATENCIÓN** Realice **MANTENIMIENTO** periódico a su máquina (página 10).
- PROTECT** Se recomienda utilizar una extensión calibre 12 AWG (3,31 mm²) y conectar en un CENTRO DE CARGA INDEPENDIENTE.
- TERMAL** Cuando la máquina se SOBRECALENTA, se activará el protector térmico. Deje enfilar la soldadora por 15 minutos y vuélvala a encenderla.

RECOMENDACIONES DE USO Y CUIDADOS

14	Póliza de Garantía
13	Centros de Servicio Autorizados
12	Notas
11	Solución de problemas
10	Simbología
10	Mantenimiento
8	Puesta en marcha
7	Instalación
6	Partes
5	Soldadores inversores
4	Advertencias de Seguridad para uso de soldadores generales de seguridad
3	Advertencias generales de seguridad para herramientas eléctricas
3	Requerimientos eléctricos
	Especificaciones técnicas
	Para poder sacar el máximo provecho de la herramienta, alargar su vida útil, hacer válida la garantía en caso de ser necesario y evitar riesgos o lesiones graves, es fundamental leer este instructivo por completo antes de usar la herramienta.
	Guarde este instructivo para futuras referencias.
	Los gráficos de este instructivo son para referencia, pueden variar del aspecto real de la herramienta.




Lea este instructivo por completo
antes de usar la herramienta.

ATENCIÓN



SON-160



13694 SON-160

Código Modelo

Este instructivo es para:

40%
Ciclo de trabajo

Soldadoras inversoras

Instructivo de

TRUPER®

ESPAÑOL
ENGLISH