

| No. | Código | Clave | Descripción |
|-------|--------|-----------------|------------------------------------|
| 1N | 954719 | R1N-BOAP-1/2 | Tornillo cabeza hexagonal M5x38 |
| 2N | 954720 | R2N-BOAP-1/2 | Cubierta de bomba |
| 3N | 954721 | R3N-BOAP-1/2 | Sello empaque Diam 8x2.5 |
| 4N | 954722 | R4N-BOAP-1/2 | Tornillo de llenado M10x1 |
| 5N | 954723 | R5N-BOAP-1/2 | Impulsor |
| 6N | 954724 | R6N-BOAP-1/2 | Seguro Diam 12 |
| 7N | 954725 | R7N-BOAP-1/2 | Sello mecánico |
| 8N | 954726 | R8N-BOAP-1/2 | Sello empaque Diam 60x2.5 |
| 9N | 954727 | R9N-BOAP-1/2 | Tornillo cabeza hexagonal M5x16 |
| 10N | 954728 | R10N-BOAP-1/2 | Soporte de bomba |
| 11N | 954729 | R11N-BOAP-1/2 | Sello para agua diam 22x11.6x7 |
| 12N | 954730 | R12N-BOAP-1/2 | Balero de bolas 6201 |
| 13N | 954731 | R13N-BOAP-1/2 | Cuña 10x4x4 |
| 14N | 954732 | R14N-BOAP-1/2 | Rotor |
| 16N | 954733 | R16N-BOAP-1/2 | Arandela ondulada Diam 23x31.5x0.3 |
| 17N | 954734 | R17N-BOAP-1/2 | Ensamble de campo con carcasa |
| 19N | 954735 | R19N-BOAP-1/2 | Cable de alimentación 18 AWG |
| 20N | 954736 | R20N-BOAP-1/2 | Cubierta trasera |
| 22N | 954737 | R22N-BOAP-1/2 | Aspas de ventilador |
| 23N | 954738 | R23N-BOAP-1/2 | Cubierta de ventilador |
| 24N | 954739 | R24N-BOAP-1/2 | Protector de Cable |
| 25N | 954740 | R25N-BOAP-1/2 | Opresor de Cable |
| 26N | 954741 | R26N-BOAP-1/2 | Tornillo cabeza Phillips M4x12 |
| 27N | 954742 | R27N-BOAP-1/2 | Capacitor 20 µF 300VAC |
| 27.1N | 954743 | R27.1N-BOAP-1/2 | Conector con terminales |
| 28N | 954744 | R28N-BOAP-1/2 | Tapa de conexiones |
| 29N | 954745 | R29N-BOAP-1/2 | Tornillo cabeza Phillips M4x38 |

