


A

No.	Código	Clave	Descripción
1	99116	R1-BOAC-1/2	Tapón de drenado
2	99117	R2-BOAC-1/2	Anillo sellador
3	99118	R3-BOAC-1/2	Cubierta de bomba
4	99119	R4-BOAC-1/2	Tuerca
5	99120	R5-BOAC-1/2	Impulsor
6	99121	R6-BOAC-1/2	Sello mecánico
7	99122	R7-BOAC-1/2	Anillo sellador
8	99123	R8-BOAC-1/2	Cubierta de soporte de bomba
9	99124	R9-BOAC-1/2	Tornillo
10	99125	R10-BOAC-1/2	Sello
11	99126	R11-BOAC-1/2	Soporte de bomba
12	99127	R12-BOAC-1/2	Balero de bolas 6201
13	99128	R13-BOAC-1/2	Tornillo
14	99129	R14-BOAC-1/2	Cuña
15	99130	R15-BOAC-1/2	Rotor
16	99131	R16-BOAC-1/2	Balero de bolas 6201
17	99132	R17-BOAC-1/2	Arandela ondulada
18	99133	R18-BOAC-1/2	Tapón de llenado
19	99134	R19-BOAC-1/2	Anillo sellador
20	99135	R20-BOAC-1/2	Campo



A

