

No.	Código	Clave	Descripción
1	ACC		Patas de base
2	954972	R2-BASE-40T	Tuerca plástica
3	954973	R3-BASE-40T	Soporte de pantalla
4	954974	R4-BASE-40T	Tornillo cabeza phillips M3x6
5	954975	R5-BASE-40T	Pantalla con arnés
6	954976	R6-BASE-40T	Tubo
7	954977	R7-BASE-40T	Soporte
8	954978	R8-BASE-40T	Tornillo 4x20
9	954979	R9-BASE-40T	Tornillo 4x30
10	954980	R10-BASE-40T	Tuerca M4
11	954981	R11-BASE-40T	Tornillo 4x10
12	954982	R12-BASE-40T	Base
13	954983	R13-BASE-40T	Soporte de batería
14	ACC		Batería 4 V/ 4 Ah
15	954984	R15-BASE-40T	Tornillo 6x16
16	954985	R16-BASE-40T	Soporte de plato
17	954986	R17-BASE-40T	Celda de carga
18	954987	R18-BASE-40T	Placa de celda
19	954988	R19-BASE-40T	Tornillo 4x12
20	954989	R20-BASE-40T	Soporte para celda
22	954990	R22-BASE-40T	Opresor de cable
23	954991	R23-BASE-40T	Tornillo 3x9
24	954992	R24-BASE-40T	Pantalla frontal
25	954993	R25-BASE-40T	Tornillo 3x8
26	954994	R26-BASE-40T	Tarjeta principal
27	954995	R27-BASE-40T	Arnés
28	954996	R28-BASE-40T	Interruptor
29	954997	R29-BASE-40T	Conector de cargador
30	954998	R30-BASE-40T	Teclado con arnés
31	954999	R31-BASE-40T	Base del teclado
32	955000	R32-BASE-40T	Ensamble de plato con grapas
33	955001	R33-BASE-40T	Carcasa con ensamble de teclado y burbuja de nivel
34	ACC		Cargador de baterías
35	955002	R35-BASE-40T	Tapa de baterías

