



A
CHASIS

No.	Código	Clave	Descripción
1	957827	R1-HILA-15000	Ensamble de carcasa frontal
2	948364	R2-HILA-15000	Perilla de encendido
3	941441	R3-HILA-15000P	Ensamble de interruptor
4	941442	R4-HILA-15000P	Ensamble de motor
5	941443	R5-HILA-15000P	Ens. de cable de alimentación
6	948365	R6-HILA-15000	Rueda
7	941445	R7-HILA-15000P	Ensamble carcasa trasera
8	941446	R8-HILA-15000P	Manija
9	ACC		Pistola
10	ACC		Lanza
11	ACC		Lanza media
12	941447	R12-HILA-15000P	Gancho
13	941448	R13-HILA-15000P	Soporte de gancho
14	941449	R14-HILA-15000P	Manguera de presión
15	ACC		Deposito de carbón
M1	941450	RM1-LAVA-1500P	Tornillo ST3x12
M2	941451	RM2-LAVA-1500P	Tapa de motor
M3	948366	RM3-HILA-15000	Protectora de polvo
M4	948367	RM4-HILA-15000	Soporte
M5	941452	RM5-LAVA-1500P	Carcasa de motor
M6	941453	RM6-LAVA-1500P	Ens. de motor con bomba
M7	941454	RM7-LAVA-1500P	Amortiguador
M8	941455	RM8-LAVA-1500P	Filtro de motor

M
ENSAMBLE DE MOTOR Y BOMBA



M
ENSAMBLE DE MOTOR Y BOMBA




A
CHASIS



ENSAMBLE DE BOMBA

No.	Código	Clave	Descripción
B1	941456	RB1-LAVA-1500P	Ens. motor con carbones
B2	941457	RB2-LAVA-1500P	Sello
B3	941458	RB3-LAVA-1500P	Ensamble de bomba
B4	941459	RB4-LAVA-1500P	Ens. de caja de engranes
B5	941460	RB5-LAVA-1500P	Plato inclinado
B6	941461	RB6-LAVA-1500P	Arandela
B7	941462	RB7-LAVA-1500P	Tornillo Esp M8x20
B8	941463	RB8-LAVA-1500P	Balero especial
B9	941464	RB9-LAVA-1500P	Jgo. 4 tornillo
B10	941465	RB10-LAVA-1500P	Ensamble de bomba
B11	941466	RB11-LAVA-1500P	Jgo. 3 tuerca de válvula
B12	941467	RB12-LAVA-1500P	Jgo. 3 sello empaque
B13	941468	RB13-LAVA-1500P	Ens. 3 válvula de salida
B14	941469	RB14-LAVA-1500P	Tornillo M6x8
B15	941470	RB15-LAVA-1500P	Jgo. 4 tornillo M6x55
B16	941471	RB16-LAVA-1500P	Jgo 3 arandela de presión Ø6
B17	941472	RB17-LAVA-1500P	Jgo. 4 arandela Ø6
B18	941473	RB18-LAVA-1500P	Cabeza de bomba
B19	941474	RB19-LAVA-1500P	Jgo. 3 retén Ø10
B20	941475	RB20-LAVA-1500P	Ensamble 3 válvula de entrada
B21	941476	RB21-LAVA-1500P	Sello Ø6.5
B22	941477	RB22-LAVA-1500P	Ensamble cuerpo de pistón
B23	941478	RB23-LAVA-1500P	Base de sello
B24	941479	RB24-LAVA-1500P	Sello de pistón
B25	941480	RB25-LAVA-1500P	Válvula de paro
B26	941481	RB26-LAVA-1500P	Juego de válvula
B27	941482	RB27-LAVA-1500P	Sello Ø62
B28	941483	RB28-LAVA-1500P	Ensamble de pistón
B29	941484	RB29-LAVA-1500P	Resorte
B30	941485	RB30-LAVA-1500P	Guía de pistón
B31	941486	RB31-LAVA-1500P	Seguro U
B32	941487	RB32-LAVA-1500P	Sello Ø10
B33	941488	RB33-LAVA-1500P	Tubo de entrada
B34	ACC		Filtro de entrada
B35	941489	RB35-LAVA-1500P	Ensamble de micro interruptor



B



Línea de comunicación directa
CENTRO DE SERVICIO AUTORIZADO TRUPER
800-018-7873 En México