


A

No.	Código	Clave	Descripción
1	950500	R1-ROU-MN	Cubierta superior
2	ACC		Etiqueta
3	950501	R3-ROU-MN	Tornillo cbz. phillips St4x14
4	950502	R4-ROU-MN	Opresor de cable
5	950503	R5-ROU-MN	Contralador de velocidad
5.1	950504	R5.1-ROU-MN	Capuchon aislante
6	950505	R6-ROU-MN	Tableta de conexiones
6.1	950506	R6.1-ROU-MN	Arnes
7	950507	R7-ROU-MN	Cable de alimentación
8	950508	R8-ROU-MN	Protector de cable
10	950509	R10-ROU-MN	Tapa de porta carbón
11	ACC		Carbón
12	950510	R12-ROU-MN	Porta carbón
13	950511	R13-ROU-MN	Carcasa de motor
14	950512	R14-ROU-MN	Interruptor
15	950513	R15-ROU-MN	Campo
16	950514	R16-ROU-MN	Tornillo cbz. phillips std. ST4x65
17	950515	R17-ROU-MN	Anillo de seguridad Ø4
18	950516	R18-ROU-MN	Anillo magnetico
19	950517	R19-ROU-MN	Arandela 5x10x.5
20	950518	R20-ROU-MN	Balero de bolas 627
21	950519	R21-ROU-MN	Anillo de asilamiento
22	950520	R22-ROU-MN	Armadura
23	950521	R23-ROU-MN	Seguro Ø16
24	950522	R24-ROU-MN	Balero de bolas 6003
25	950523	R25-ROU-MN	Arandela ondulada 27x34x.5
26	950524	R26-ROU-MN	Soporte de balero



A



B

No.	Código	Clave	Descripción
27	950525	R27-ROU-MN	Carcasa
28	950526	R28-ROU-MN	Tornillo cbz. phillips St4x40
29	950527	R29-ROU-MN	Botón de bloqueo
30	950528	R30-ROU-MN	Resorte autoblocante
31	950529	R31-ROU-MN	Pasador autoblocante
32	950530	R32-ROU-MN	Collet
33	950531	R33-ROU-MN	Tuerca de collet
34	950532	R34-ROU-MN	Tornillo con plástico M6x19
36	950533	R36-ROU-MN	Arandela plana 6x12x1
37	950534	R37-ROU-MN	Base cilíndrica
37.1	950535	R37.1-ROU-MN	Perilla M4x10
38	950536	R38-ROU-MN	Perilla de ajuste M5x35
39	950537	R39-ROU-MN	Engranaje recto
40	950538	R40-ROU-MN	Asiento de leva
41	950539	R41-ROU-MN	Tapa
42	950540	R42-ROU-MN	Conjunto de barra de bloqueo
43	950541	R43-ROU-MN	Arandela plana Ø5x10x.5
44	950542	R44-ROU-MN	Tuerca M5
45	950543	R45-ROU-MN	Placa base cilíndrica
46	950544	R46-ROU-MN	Tornillo phillips base plana M4x10
47	950545	R47-ROU-MN	Ensamble de base



B

