

No.	Código	Clave	Descripción
1	950667	R1-MAX-40S	Tornillo cbz. torx 4x16
2	950668	R2-MAX-40S	Cubierta trasera
3	950669	R3-MAX-40S	Tuerca M5
4	950670	R4-MAX-40S	Ventilador
5	950671	R5-MAX-40S	Soporte izquierdo
6	950672	R6-MAX-40S	Tornillo con arandela 5x10
7	950673	R7-MAX-40S	Manga
8	950674	R8-MAX-40S	Soporte medio
8.1	950675	R8.1-MAX-40S	Terminal de batería
9	950676	R9-MAX-40S	Soporte derecho
10	950677	R10-MAX-40S	Cubierta de la manija
11	950678	R11-MAX-40S	Botón
12	950679	R12-MAX-40S	Cubierta de la cáscara
13	950680	R13-MAX-40S	Conducto de conexión
14	ACC		Ducto de aire
15	950681	R15-MAX-40S	Tornillo cbz. torx 3x14
16	950682	R16-MAX-40S	Difusor
17	950683	R17-MAX-40S	Motor
18	950684	R18-MAX-40S	Soporte de motor
19	950685	R19-MAX-40S	Amortiguador
20	950686	R20-MAX-40S	Fondo de concha
21	950687	R21-MAX-40S	Tablero de prensa
22	950688	R22-MAX-40S	Botón de interruptor
23	950689	R23-MAX-40S	Interruptor
24	950690	R24-MAX-40S	Tarjeta de circuito impreso
25	950691	R25-MAX-40S	Abrazadera
26	950692	R26-MAX-40S	Resorte para micro
27	950693	R27-MAX-40S	Micro interruptor
28	950694	R28-MAX-40S	Parte inferior del mango
29	950695	R29-MAX-40S	Arandela plana 6x14x1
30	950696	R30-MAX-40S	Resorte de botón
31	950697	R31-MAX-40S	Botón turbo
32	950698	R32-MAX-40S	Resorte

