

No.	Código	Clave	Descripción
1	951474	R1-SOPLA-800	Tapa de porta carbón
2	ACC		Carbón
3	951475	R3-SOPLA-800	Inserto de porta carbón
4	951476	R4-SOPLA-800	Porta carbón
5	951477	R5-SOPLA-800	Cubierta trasera
6	951478	R6-SOPLA-800	Campo
7	951479	R7-SOPLA-800	Balero 627
8	951480	R8-SOPLA-800	Clip
9	951481	R9-SOPLA-800	Tornillo cbz. phillips ST4x42
10	951482	R10-SOPLA-800	Armadura
11	951483	R9-SOPLA-800	Balero 629
12	951484	R10-SOPLA-800	Arandela plana 9.5x16x1
13	951485	R13-SOPLA-800	Perno 2x14
14	951486	R14-SOPLA-800	Tornillo cbz. phillips ST4x13
15	951487	R15-SOPLA-800	Cubierta de cable
16	951488	R16-SOPLA-800	Cubierta derecha
17	951489	R17-SOPLA-800	Control de velocidad
19	951490	R18-SOPLA-800	Interruptor
20	951491	R19-SOPLA-800	Opresor de cable
21	951492	R20-SOPLA-800	Tornillo cbz. phillips St4x18
22	951493	R21-SOPLA-800	Tapa de carcasa
23	951494	R22-SOPLA-800	Cubierta izquierda
24	951495	R23-SOPLA-800	Tuerca M6
25	951496	R24-SOPLA-800	Transformación de conductos de aire
26	951497	R25-SOPLA-800	Conector
27	951498	R26-SOPLA-800	Conducto de aire
28	951499	R26-SOPLA-800	Ventilador
29	951500	R20-SOPLA-800	Coenctor de bolsa
30	ACC		Cincho
31	951501	R22-SOPLA-800	Bolsa de polvo
32	951502	R23-SOPLA-800	Protector del cabe
33	951503	R24-SOPLA-800	Cable de alimentación
37	951504	R25-SOPLA-800	Manguera
38	951505	R26-SOPLA-800	Conector de la manguera

