

No.	Código	Clave	Descripción
1	951643	R1-SOIN-130P	Parte inferior de la maquina
1.1	951644	R1.1-SOIN-130P	Tornillo 4x10
2	951645	R2-SOIN-130P	Jgo de conector rápido hembra
3	951646	R3-SOIN-130P	Panel frontal
4	951647	R4-SOIN-130P	Jgo de perilla de potenciómetro
5	951648	R5-SOIN-130P	Tarjeta con display de panel frontal
5.1	951649	R5.1-SOIN-130P	Tornillo cbz. phillips 3x6
6	951650	R6-SOIN-130P	Conector de salida
6.1	951651	R6.1-SOIN-130P	Tornillo cbz. phillips M4x13
7	951652	R7-SOIN-130P	Ensamble de tarjeta principal
7.1	951653	R7.1-SOIN-130P	Tornillo cbz. phillips M4x8
7.2	951654	R7.2-SOIN-130P	Tornillo cbz. phillips pavonado M4x8
7.3	951655	R7.3-SOIN-130P	Tornillo cbz. hex. con arandela plana y presión 6x16
7.4	951656	R7.4-SOIN-130P	Arandela Ø6x18x1
7.5	951657	R7.5-SOIN-130P	Tuerca hex M6
7.6	951658	R7.6-SOIN-130P	Tornillo cbz. phillips M4x6
18	951659	R18-SOIN-130P	Aislante para tarjeta
19	951660	R19-SOIN-130P	Carcasa de maquina
19.1	951661	R19.1-SOIN-130P	Tornillo cbz. phillips St4x8
20	951662	R20-SOIN-130P	Cinturon
21	951663	R21-SOIN-130P	Manija
21.1	951664	R21.1-SOIN-130P	Tornillo cbz. phillips con arandela plana y presión M5x12
22	951665	R22-SOIN-130P	Protector de cable
23	951666	R23-SOIN-130P	Interruptor de encendido
24	951667	R24-SOIN-130P	Panel trasero
25	951668	R25-SOIN-130P	Cable de alimentación
26	951669	R26-SOIN-130P	Ventilador
26.1	951670	R26.1-SOIN-130P	Tornillo cbz. phillips St5x16
27	951671	R27-SOIN-130P	Ensamble de mordaza porta electrodo con cable, conexión rapida macho
28	951672	R28-SOIN-130P	Ensamble de pinza con cable para tierra , conexión rápida macho

