

No.	Código	Clave	Descripción
2	964351	R2-HIDR-3/4x50	Tornillo Allen (M6X12)
3	964352	R3-HIDR-3/4x50	Tornillo hexagonal (M10X6)
4	964353	R4-HIDR-3/4x50	Sello (Ø8.2xØ12x1.9)
5	964354	R5-HIDR-3/4x50	Cuerpo de bomba
6	964355	R6-HIDR-3/4x50	Sello (Ø26.3xØ30.7x2.2)
7	964356	R7-HIDR-3/4x50	Conexión de difusor
8	964357	R8-HIDR-3/4x50	Manguera flexible
9	964358	R9-HIDR-3/4x50	Difusor
10	964359	R10-HIDR-3/4x50	Empaque (Ø21xØ32x2.5)
11	964360	R11-HIDR-3/4x50	Tuerca M10
12	964361	R12-HIDR-3/4x50	Arandela de presión (Ø10.5xØ15.5x2.5)
13	964362	R13-HIDR-3/4x50	Arandela plana (Ø8.5xØ22x1.5)
14	964363	R14-HIDR-3/4x50	Arandela plana (Ø10.5xØ19.5x2)
15	964364	R15-HIDR-3/4x50	Arandela de presión (Ø8.5xØ12.9x2.2)
16	964365	R16-HIDR-3/4x50	Impulsor
17	964366	R17-HIDR-3/4x50	Tornillo hexagonal (M8X14)
18	964367	R18-HIDR-3/4x50	Sello mecánico
19	964368	R19-HIDR-3/4x50	Sello (Ø163xØ170x3.5)
20	964369	R20-HIDR-3/4x50	Cubierta del soporte
21	964370	R21-HIDR-3/4x50	Empaque (Ø14xØ32x5)
22	964371	R22-HIDR-3/4x50	Soporte de bomba
23	964372	R23-HIDR-3/4x50	Ensamble de tanque de presión
24	964373	R24-HIDR-3/4x50	Tapa de ventilador
25	964374	R25-HIDR-3/4x50	Tornillo hexagonal (M5X137)
26	964375	R26-HIDR-3/4x50	Ventilador
27	964376	R27-HIDR-3/4x50	Tapa trasera
28	964377	R28-HIDR-3/4x50	Arandela ondulada (Ø27xØ34x0.5)
31	964378	R31-HIDR-3/4x50	Cable de alimentación (700 mm)
32	964379	R32-HIDR-3/4x50	Pata (M8x35)
33	964380	R33-HIDR-3/4x50	Campo
34	964381	R34-HIDR-3/4x50	Caja de conexiones
35	964382	R35-HIDR-3/4x50	Tornillo Phillips (M4X10)
36	964383	R36-HIDR-3/4x50	Tornillo Phillips (M4X12)
36.1	964384	R36.1-HIDR-3/4x50	Arandela plana (Ø4.2XØ12X1.2)
37	964385	R37-HIDR-3/4x50	Tuerca M17
38	964386	R38-HIDR-3/4x50	Arandela estriada (Ø4xØ7.5x1)
39	964387	R39-HIDR-3/4x50	Tornillo Phillips (M4X8)
40	964388	R40-HIDR-3/4x50	Opresor de cable
41	964389	R41-HIDR-3/4x50	Tornillo Phillips (St4x11)
42	964390	R42-HIDR-3/4x50	Abrazadera
43	964391	R43-HIDR-3/4x50	Sello (Ø38xØ43.2x2.6)
44	964392	R44-HIDR-3/4x50	Tornillo Phillips (St4.5x14)
45	964393	R45-HIDR-3/4x50	Tapa de conexiones
48	964394	R48-HIDR-3/4x50	Tira de sellado
49	964395	R49-HIDR-3/4x50	Capacitor (40µF)
50	964396	R50-HIDR-3/4x50	Tuerca (M4)
51	964397	R51-HIDR-3/4x50	Terminal de ojillo
51.1	964398	R51.1-HIDR-3/4x50	Terminal horquilla
52	964399	R52-HIDR-3/4x50	Arandela plana (Ø4.2xØ8x.5)
55	964400	R55-HIDR-3/4x50	Tableta de conexiones
56	964401	R56-HIDR-3/4x50	Protector de cable
57	964402	R57-HIDR-3/4x50	Arandela plana (Ø9.2xØ16x1)
58	964403	R58-HIDR-3/4x50	Junta de la caja de conexiones (77x72)
59	964404	R59-HIDR-3/4x50	Balero de bolas 6202
60	964405	R60-HIDR-3/4x50	Rotor
61	964406	R61-HIDR-3/4x50	Cuña (4x4x9.5)
62	964407	R62-HIDR-3/4x50	Balero de bolas 6302
63	964408	R63-HIDR-3/4x50	Manómetro
65	964409	R65-HIDR-3/4x50	Niple de 5 vías
66	964410	R66-HIDR-3/4x50	Presostato
67	964411	R67-HIDR-3/4x50	Cable de alimentación (300 mm)



Todos los códigos los puedes adquirir en los Centros de Servicio Autorizado TRUPER o llamando al 800-018-7873

