



No.	Código	Clave	Descripción
1	941648	R1-BOAP-1/2A2	Tornillo cabeza hexagonal M5x35mm
10	941649	R10-BOAP-1/2A2	Tornillo cabeza hexagonal M5x20mm
17	941650	R17-BOAP-1/2A2	Tornillo cabeza phillips M4x28mm
2	941651	R2-BOAP-1/2A2	Carcasa de bomba
11	941652	R11-BOAP-1/2A2	Cuerpo de bomba
3	941653	R3-BOAP-1/2A2	Tornillo de purga
4	941654	R4-BOAP-1/2A2	Sello tornillo de purga
9	941655	R9-BOAP-1/2A2	Sello de cuerpo de bomba
6	941656	R6-BOAP-1/2A2	Seguro C
5	941657	R5-BOAP-1/2A2	Impulsor
7	941658	R7-BOAP-1/2A2	Arandela plana
8	941659	R8-BOAP-1/2A2	Sello mecánico
12	941660	R12-BOAP-1/2A2	Guarda de polvo
13	941661	R13-BOAP-1/2A2	Balero de bolas 6201
14	941662	R14-BOAP-1/2A2	Cuñero
15	946490	R15-BOAP-1/2A2	Rotor
18	941664	R18-BOAP-1/2A2	Tapa de conexiones
19	946491	R19-BOAP-1/2A2	Capacitor 20uF
20	946492	R20-BOAP-1/2A2	Tableta de conexiones
21	946493	R21-BOAP-1/2A2	Ensamble de campo con carcasa
22	941668	R22-BOAP-1/2A2	Tornillo cabeza phillips M4x10
23	941669	R23-BOAP-1/2A2	Opresor de cable
24	941670	R24-BOAP-1/2A2	Protector de cable
25	941671	R25-BOAP-1/2A2	Tapa de motor
27	941672	R27-BOAP-1/2A2	Ventilador
28	941673	R28-BOAP-1/2A2	Tapa de ventilador

