



A

No.	Código	Clave	Descripción
1	911590	R1-BOS-1LP	Cable de alimentación
1.1	911591	R1.1-BOS-1LP	Conector grande
1.2	911592	R1.2-BOS-1LP	Conector chico
2	911593	R2-BOS-1LP	Interruptor flotador
3	911594	R3-BOS-1LP	Tornillo ST4.5x28mm
4	911595	R4-BOS-1LP	Carcasa superior
5	911596	R5-BOS-1LP	Protector de cable
6	911597	R6-BOS-1LP	Sujetador de cable
7	911598	R7-BOS-1LP	Capacitor 35 F
8	911599	R8-BOS-1LP	Opresor
9	911600	R9-BOS-1LP	Tornillo ST3.9x30.5mm
10	911601	R10-BOS-1LP	Cubierta de motor
10.1	911602	R10.1-BOS-1LP	Tornillo M4x8mm
10.2	911603	R10.2-BOS-1LP	Rondana de presión Ø4
10.3	911604	R10.3-BOS-1LP	Cable conexión a tierra
10.4	911605	R10.4-BOS-1LP	Rondana astriada Ø4
11	911606	R11-BOS-1LP	Rondana ondulada Ø25
12	911607	R12-BOS-1LP	Balero de bolas 6201 -ZZ
13	911608	R13-BOS-1LP	Rotor
13.1	911609	R13.1-BOS-1LP	Anillo "C" Ø12
13.2	911610	R13.2-BOS-1LP	Espaciador
13.3	911611	R13.3-BOS-1LP	Rondana plana Ø12
14	911612	R14-BOS-1LP	Protector de cable
15	911613	R15-BOS-1LP	Campo
16	911614	R16-BOS-1LP	Sello
18	911615	R18-BOS-1LP	Sello de hule Ø84.5




A

Si tienes dudas, llama a la
 Línea de Comunicación Directa
800-0187-873 Exclusivo
 para México

B

No.	Código	Clave	Descripción
20	911616	R20-BOS-1LP	Rondana plana Ø4
22	911617	R22-BOS-1LP	Sello de hule Ø89
23	911618	R23-BOS-1LP	Rondana plana Ø8.5
24	911619	R24-BOS-1LP	Impulsor
25	911620	R25-BOS-1LP	Tuerca se seguridad M8
26	911621	R26-BOS-1LP	Carcasa
27	911622	R27-BOS-1LP	Balín de acero Ø6
28	911623	R28-BOS-1LP	Rondana especial Ø3.6
29	911624	R29-BOS-1LP	Tornillo ST2.9x8.5mm
30	911625	R30-BOS-1LP	Sello de hule Ø129
31	911626	R31-BOS-1LP	Base
32	911627	R32-BOS-1LP	Tornillo ST4.5x18mm
33	911628	R33-BOS-1LP	Adaptador
34	911629	R34-BOS-1LP	Sello de hule Ø37.5
35	911630	R35-BOS-1LP	Conector de salida
37	911621	R37-BOS-1LP	Sello mecánico



B