


A


No.	Código	Clave	Descripción
1	911632	R1-BOS-1SP	Cable de alimentación
1.1	911633	R1.1-BOS-1SP	Conector grandes
1.2	911634	R1.2-BOS-1SP	Conector chico
2	911635	R2-BOS-1SP	Interruptor flotador
3	911636	R3-BOS-1SP	Tornillo St4.5x28mm
4	911637	R4-BOS-1SP	Carcasa superior
5	911638	R5-BOS-1SP	Protector de cable
6	911639	R6-BOS-1SP	Sujetador de cable
7	911640	R7-BOS-1SP	Capacitador 35 F
8	911641	R8-BOS-1SP	Opresor
9	911642	R9-BOS-1SP	Tornillo St3.9x30.5mm
10	911643	R10-BOS-1SP	Cubierta de motor
10.1	911644	R10.1-BOS-1SP	Tornillo M4x8mm
10.2	911645	R10.2-BOS-1SP	Rondana de presión Ø4
10.3	911646	R10.3-BOS-1SP	Cable conexión a tierra
10.4	911647	R10.4-BOS-1SP	Rondana estriada Ø4
11	911648	R11-BOS-1SP	Rondana ondulada Ø25
12	911649	R12-BOS-1SP	Balero de bolas 6201-2Z
13	911650	R13-BOS-1SP	Rotor
13.1	911651	R13.1-BOS-1SP	Anillo "C" Ø12
13.2	911652	R13.2-BOS-1SP	Espaciador
13.3	911653	R13.3-BOS-1SP	Rondana plana Ø12



A

B

No.	Código	Clave	Descripción
14	911654	R14-BOS-1SP	Protector de cable
15	911655	R15-BOS-1SP	Campo
16	911656	R16-BOS-1SP	Sello
18	911657	R18-BOS-1SP	Sello de hule Ø84.5
20	911658	R20-BOS-1SP	Rondana plana Ø4
22	911659	R22-BOS-1SP	Sello de hule Ø89.5
23	911660	R23-BOS-1SP	Rondana plana Ø8.5
24	911661	R24-BOS-1SP	Impulsor
25	911662	R25-BOS-1SP	Tuerca de seguridad M8
26	911663	R26-BOS-1SP	Carcasa
27	911664	R27-BOS-1SP	Balín de acero Ø6
28	911665	R28-BOS-1SP	Rondana especial Ø3.6
29	911666	R29-BOS-1SP	Tornillo St2.9x8.5mm
30	911667	R30-BOS-1SP	Sello de hule Ø129
31	911668	R31-BOS-1SP	Base
32	911669	R32-BOS-1SP	Plato base
33	911670	R33-BOS-1SP	Tornillo St4.5x24mm
34	911671	R34-BOS-1SP	Adaptador
35	911672	R35-BOS-1SP	Sello de hule Ø37.5
36	911673	R36-BOS-1SP	Conector de salida
38	911674	R38-BOS-1SP	Tornillo St4.2x13mm
39	911675	R39-BOS-1SP	Sello mecánico



B

Si tienes dudas, llama a la
 Línea de Comunicación Directa
800-0187-873 Exclusivo
 para México