


A

No.	Código	Clave	Descripción
1	919142	R1-BOS-1-1/2SM	Cable
2	919143	R2-BOS-1-1/2SM	Interruptor
3	919144	R3-BOS-1-1/2SM	Tornillo de tapa
4	919145	R4-BOS-1-1/2SM	Agarradera
5	919146	R5-BOS-1-1/2SM	Tuerca
6	919147	R6-BOS-1-1/2SM	Tornillo
7	919148	R7-BOS-1-1/2SM	Cuerpo de bomba
8	919149	R8-BOS-1-1/2SM	Anillo O
9	919150	R9-BOS-1-1/2SM	Cubierta trasera de la bomba
11	919151	R11-BOS-1-1/2SM	Protector de cable
11.1	919152	R11.1-BOS-1-1/2SM	Protector de cable
12	919153	R12-BOS-1-1/2SM	Opresor de cable
13	919154	R13-BOS-1-1/2SM	Capacitor 35 F
14	919155	R14-BOS-1-1/2SM	Bloqueo de cable
15	919156	R15-BOS-1-1/2SM	Tornillo
16	919157	R16-BOS-1-1/2SM	Cubierta trasera
16.1	919158	R16.1-BOS-1-1/2SM	Revestimiento de cable
16.2	919159	R16.2-BOS-1-1/2SM	Rondana de presión
16.3	919160	R16.3-BOS-1-1/2SM	Cable conexión a tierra
16.6	919161	R16.6-BOS-1-1/2SM	Arandela dentada
16.7	919162	R16.7-BOS-1-1/2SM	Tornillo
17	919163	R17-BOS-1-1/2SM	Arandela ondulada
18	919164	R18-BOS-1-1/2SM	Balero
19	919165	R19-BOS-1-1/2SM	Rotor
20	919166	R20-BOS-1-1/2SM	Campo
21	919167	R21-BOS-1-1/2SM	Seguro




A

Si tienes dudas, llama a la Línea de Comunicación Directa

**800-0187-873** Exclusivo para México

**B**

No.	Código	Clave	Descripción
22	919168	R22-BOS-1-1/2SM	Arandela
23	919169	R23-BOS-1-1/2SM	Sellador de hule
24	919172	R24-BOS-1-1/2SM	Inserto
25	919173	R25-BOS-1-1/2SM	Anillo O
26	919174	R26-BOS-1-1/2SM	Cubierta frontal
27	919175	R27-BOS-1-1/2SM	Arandela de ajuste
28	919177	R28-BOS-1-1/2SM	Impulsor
29	919178	R29-BOS-1-1/2SM	Tuerca
30	919179	R30-BOS-1-1/2SM	Anillo O
31	919180	R31-BOS-1-1/2SM	Tuerca de apriete
32	919181	R32-BOS-1-1/2SM	Tornillo
33	919182	R33-BOS-1-1/2SM	Enlace a tierra
34	919183	R34-BOS-1-1/2SM	Anillo de posición
35	919184	R35-BOS-1-1/2SM	Junta
36	919185	R36-BOS-1-1/2SM	Base
37	919186	R37-BOS-1-1/2SM	Anillo O
38	919187	R38-BOS-1-1/2SM	Adaptador
39	919188	R39-BOS-1-1/2SM	Conexión de salida
40	919189	R40-BOS-1-1/2SM	Salida de aire
41	919190	R41-BOS-1-1/2SM	Balín
42	919191	R42-BOS-1-1/2SM	Anillo O
43	919192	R43-BOS-1-1/2SM	Tuerca de salida de aire
44	919193	R44-BOS-1-1/2SM	Conector
44.1	919194	R44.1-BOS-1-1/2SM	Conector



**B**

Si tienes dudas, llama a la  
Línea de Comunicación Directa

**800-0187-873** Exclusivo  
para México