


A

No.	Código	Clave	Descripción
1	939957	R1-BOS-1LM2	Cubierta
2	939958	R2-BOS-1LM2	Junta
3	939959	R3-BOS-1LM2	Cubre polvo
4	939960	R4-BOS-1LM2	Tuerca
5	939961	R5-BOS-1LM2	Arandela de presión
6	939962	R6-BOS-1LM2	Tornillo sin fin
7	939963	R7-BOS-1LM2	Cubierta superior
8	939964	R8-BOS-1LM2	Retén
9	939965	R9-BOS-1LM2	Tornillo de llenado aceite
10	939966	R10-BOS-1LM2	Sello
11	939967	R11-BOS-1LM2	Tapa superior
12	939968	R12-BOS-1LM2	Tuerca de fijación
13	939969	R13-BOS-1LM2	Tornillo
14	939970	R14-BOS-1LM2	Sello mecanico
15	939971	R15-BOS-1LM2	Arandela plana
16	939972	R16-BOS-1LM2	Arandela plana
17	939973	R17-BOS-1LM2	Arandela ondulada
18	939974	R18-BOS-1LM2	Balero
19	939975	R19-BOS-1LM2	Ensamble de cable de alimen.
25	939976	R25-BOS-1LM2	Sello
26	939977	R26-BOS-1LM2	Rotor
27	939978	R27-BOS-1LM2	Cubierta superior
28	939979	R28-BOS-1LM2	Campo 2 HP
29	939980	R29-BOS-1LM2	Cubierta inferior
30	939981	R30-BOS-1LM2	Balero
32	939982	R31-BOS-1LM2	Tapa
33	939983	R33-BOS-1LM2	Tubo
34	939984	R34-BOS-1LM2	Termofit
35	939985	R35-BOS-1LM2	Protector térmico
36	939986	R36-BOS-1LM2	Soporte inferior
37	939987	R37-BOS-1LM2	Carcasa de motor
38	939988	R38-BOS-1LM2	Bolsa para aceite
39	939989	R39-BOS-1LM2	Tapa inferior
40	939990	R40-BOS-1LM2	Anillo de retención




A



B



No.	Código	Clave	Descripción																																																				
1	939991	RB1-BOS-1LM2	Tapón protector																																																				
2	939992	RB2-BOS-1LM2	Tapa de salida																																																				
3	939993	RB3-BOS-1LM2	Tornillo M																																																				
4	939994	RB4-BOS-1LM2	Carcasa de bomba																																																				
5	939995	RB5-BOS-1LM2	Válvula de retención																																																				
6	939996	RB6-BOS-1LM2	Pasacable																																																				
7	939997	RB7-BOS-1LM2	Protector de cable																																																				
8	939998	RB8-BOS-1LM2	Base soporte																																																				
9	939999	RB9-BOS-1LM2	Soporte superior																																																				
10	940000	RB10-BOS-1LM2	Tornillo especial M																																																				
11	940001	RB11-BOS-1LM2	Manga de eje superior																																																				
12	940002	RB12-BOS-1LM2	Buje <tr> <td>13</td> <td>940003</td> <td>RB13-BOS-1LM2</td> <td>Eje</td> </tr> <tr> <td>14</td> <td>940004</td> <td>RB14-BOS-1LM2</td> <td>Arandela</td> </tr> <tr> <td>15</td> <td>940005</td> <td>RB15-BOS-1LM2</td> <td>Difusor</td> </tr> <tr> <td>16</td> <td>940006</td> <td>RB16-BOS-1LM2</td> <td>Impulsor</td> </tr> <tr> <td>17</td> <td>940007</td> <td>RB17-BOS-1LM2</td> <td>Tapa de difusor</td> </tr> <tr> <td>19</td> <td>940008</td> <td>RB19-BOS-1LM2</td> <td>Acoplamiento</td> </tr> <tr> <td>20</td> <td>940009</td> <td>RB20-BOS-1LM2</td> <td>Arandela</td> </tr> <tr> <td>21</td> <td>940010</td> <td>RB21-BOS-1LM2</td> <td>Soporte inferior</td> </tr> <tr> <td>22</td> <td>940011</td> <td>RB22-BOS-1LM2</td> <td>Capuchon inferior</td> </tr> <tr> <td>23</td> <td>940012</td> <td>RB23-BOS-1LM2</td> <td>Acoplamiento del eje</td> </tr> <tr> <td>24</td> <td>940013</td> <td>RB24-BOS-1LM2</td> <td>Tornillo M</td> </tr> <tr> <td>25</td> <td>940014</td> <td>RB25-BOS-1LM2</td> <td>Regilla</td> </tr> <tr> <td>26</td> <td>940015</td> <td>RB26-BOS-1LM2</td> <td>Base conector</td> </tr>	13	940003	RB13-BOS-1LM2	Eje	14	940004	RB14-BOS-1LM2	Arandela	15	940005	RB15-BOS-1LM2	Difusor	16	940006	RB16-BOS-1LM2	Impulsor	17	940007	RB17-BOS-1LM2	Tapa de difusor	19	940008	RB19-BOS-1LM2	Acoplamiento	20	940009	RB20-BOS-1LM2	Arandela	21	940010	RB21-BOS-1LM2	Soporte inferior	22	940011	RB22-BOS-1LM2	Capuchon inferior	23	940012	RB23-BOS-1LM2	Acoplamiento del eje	24	940013	RB24-BOS-1LM2	Tornillo M	25	940014	RB25-BOS-1LM2	Regilla	26	940015	RB26-BOS-1LM2	Base conector
13	940003	RB13-BOS-1LM2	Eje																																																				
14	940004	RB14-BOS-1LM2	Arandela																																																				
15	940005	RB15-BOS-1LM2	Difusor																																																				
16	940006	RB16-BOS-1LM2	Impulsor																																																				
17	940007	RB17-BOS-1LM2	Tapa de difusor																																																				
19	940008	RB19-BOS-1LM2	Acoplamiento																																																				
20	940009	RB20-BOS-1LM2	Arandela																																																				
21	940010	RB21-BOS-1LM2	Soporte inferior																																																				
22	940011	RB22-BOS-1LM2	Capuchon inferior																																																				
23	940012	RB23-BOS-1LM2	Acoplamiento del eje																																																				
24	940013	RB24-BOS-1LM2	Tornillo M																																																				
25	940014	RB25-BOS-1LM2	Regilla																																																				
26	940015	RB26-BOS-1LM2	Base conector																																																				



B

C

No.	Código	Clave	Descripción
1	940016	RC1-BOS-1LM2	Tornillo
2	940017	RC2-BOS-1LM2	Tapa de caja de control
3	940018	RC3-BOS-1LM2	Capacitor 135 uF +/- 5%
4	940019	RC4-BOS-1LM2	Interruptor 16 Amp
5	940020	RC5-BOS-1LM2	Protector térmico 8 Amp
6	940021	RC6-BOS-1LM2	Tabla de conexiones
7	940022	RC7-BOS-1LM2	Cable de alimentación
8	940023	RC8-BOS-1LM2	Opresor de cable
9	940024	RC9-BOS-1LM2	Tornillo
10	940025	RC10-BOS-1LM2	Caja de control
11	940026	RC11-BOS-1LM2	Aislante de terminales
12	940027	RC12-BOS-1LM2	Arnés con terminal
13	940028	RC13-BOS-1LM2	Arnés con terminal
14	940029	RC14-BOS-1LM2	Arnés con terminal



C

