


A

No.	Código	Clave	Descripción
1	940396	R1 BOS-1-1/2LM2	Cubierta
2	940397	R2 BOS-1-1/2LM2	Junta
3	940398	R3 BOS-1-1/2LM2	Cubre Polvo
4	940399	R4 BOS-1-1/2LM2	Tuerca
5	940400	R5 BOS-1-1/2LM2	Arandela de Presión
6	940401	R6 BOS-1-1/2LM2	Tornillo Sin Fin
7	940402	R7 BOS-1-1/2LM2	Cubierta Superior
8	940403	R8 BOS-1-1/2LM2	Reten
9	940404	R9 BOS-1-1/2LM2	Tornillo de Llenado Aceite
10	940405	R10 BOS-1-1/2LM2	Sello
11	940406	R11 BOS-1-1/2LM2	Tapa Superior
12	940407	R12 BOS-1-1/2LM2	Tuerca de fijación
13	940408	R13 BOS-1-1/2LM2	Tornillo
14	940409	R14 BOS-1-1/2LM2	Sello Mecanico
15	940410	R15 BOS-1-1/2LM2	Arandela Plana
16	940411	R16 BOS-1-1/2LM2	Arandela Plana
17	940412	R17 BOS-1-1/2LM2	Arandela Ondulada
18	940413	R18 BOS-1-1/2LM2	Balero
19	940414	R19 BOS-1-1/2LM2	Ensamble de cable de alimentación
25	940415	R25 BOS-1-1/2LM2	Sello
26	940416	R26 BOS-1-1/2LM2	Rotor
27	940417	R27 BOS-1-1/2LM2	Cubierta Superior
28	940418	R28 BOS-1-1/2LM2	Campo 2 HP
29	940419	R29 BOS-1-1/2LM2	Cubierta Inferior
30	940420	R30 BOS-1-1/2LM2	Balero
32	940421	R32 BOS-1-1/2LM2	Tapa
33	940422	R33 BOS-1-1/2LM2	Tubo
34	940423	R34 BOS-1-1/2LM2	Termofit
35	940424	R35 BOS-1-1/2LM2	Protector Termico
36	940425	R36 BOS-1-1/2LM2	Soporte Inferior
37	940426	R37 BOS-1-1/2LM2	Carcasa de Motor
38	940427	R38 BOS-1-1/2LM2	Bolsa para Aceite
39	940428	R39 BOS-1-1/2LM2	Tapa Inferior
40	940429	R40 BOS-1-1/2LM2	Anillo de retención




Motor

A

B

No.	Código	Clave	Descripción
1	940429	RB1-BOS-1-1/2LM2	Tapon Protector
2	940430	RB2-BOS-1-1/2LM2	Tapa de Salida
3	940431	RB3-BOS-1-1/2LM2	Tornillo M
4	940432	RB4-BOS-1-1/2LM2	Carcasa de Bomba
5	940433	RB5-BOS-1-1/2LM2	Válvula de Retención
6	940434	RB6-BOS-1-1/2LM2	Pasacable
7	940435	RB7-BOS-1-1/2LM2	Protector de Cable
8	940436	RB8-BOS-1-1/2LM2	Base Soporte
9	940437	RB9-BOS-1-1/2LM2	Soporte Superior
10	940438	RB10-BOS-1-1/2LM2	Tornillo Especial M
11	940439	RB11-BOS-1-1/2LM2	Manga de Eje superior
12	940440	RB12-BOS-1-1/2LM2	Buje
13	940441	RB13-BOS-1-1/2LM2	Eje
14	940442	RB14-BOS-1-1/2LM2	Arandela
15	940443	RB15-BOS-1-1/2LM2	Difusor
16	940444	RB16-BOS-1-1/2LM2	Impulsor
17	940445	RB17-BOS-1-1/2LM2	Tapa de Difusor
18	ACC		Plato de Flujo
19	940446	RB19-BOS-1-1/2LM2	Acoplamiento
20	940447	RB20-BOS-1-1/2LM2	Arandela
21	940448	RB21-BOS-1-1/2LM2	Soporte Inferior
22	940449	RB22-BOS-1-1/2LM2	Capuchon Inferior
23	940450	RB23-BOS-1-1/2LM2	Acoplamiento del eje
24	940451	RB24-BOS-1-1/2LM2	Tornillo M
25	940452	RB25-BOS-1-1/2LM2	Regilla
26	940453	RB26-BOS-1-1/2LM2	Base de Conector



Bomba

B



C

No.	Código	Clave	Descripción
1	940454	RC1-BOS-1-1/2LM2	Tornillo
2	940455	RC2-BOS-1-1/2LM2	Tapa de Caja de Control
3	940456	RC3-BOS-1-1/2LM2	Capacitor 135 µF+/-5%
4	940457	RC4-BOS-1-1/2LM2	Interruptor 16 Amp
5	940458	RC5-BOS-1-1/2LM2	Protector Termico 8 Amp
6	940459	RC6-BOS-1-1/2LM2	Tableta de conexiones
7	940460	RC7-BOS-1-1/2LM2	Cable de Alimentación
8	940461	RC8-BOS-1-1/2LM2	Opresor de Cable
9	940462	RC9-BOS-1-1/2LM2	Tornillo
10	940463	RC10-BOS-1-1/2LM2	Caja de Control
11	940464	RC11-BOS-1-1/2LM2	Aislante de terminales
12	940465	RC12-BOS-1-1/2LM2	Arnes con Terminal
13	940466	RC13-BOS-1-1/2LM2	Arnes con Terminal
14	940467	RC14-BOS-1-1/2LM2	Arnes con Terminal



Control

C

