

No.	Código	Clave	Descripción
1	929904	R1-ROTO-1/2A7	Carcasa izquierda
36	929905	R36-ROTO-1/2A7	Carcasa derecha
3	929906	R3-ROTO-1/2A7	Palanca de interruptor
5	929907	R5-ROTO-1/2A7	Opresor de cable
6	929908	R6-ROTO-1/2A7	Tornillo ST 4x16
8	929909	R8-ROTO-1/2A7	Interruptor
9	929910	R9-ROTO-1/2A7	Protector de cable
10	929911	R10-ROTO-1/2A7	Cable de alimentación
11	929912	R11-ROTO-1/2A7	Escala de profundidad
12	929913	R12-ROTO-1/2A7	Mango auxiliar
13	929914	R13-ROTO-1/2A7	Tornillo M5x25
14	929915	R14-ROTO-1/2A7	Llave de broquero
15	929916	R15-ROTO-1/2A7	Broquero
16	929917	R16-ROTO-1/2A7	Eje
17	929918	R17-ROTO-1/2A7	Resorte
18	929919	R18-ROTO-1/2A7	Balero de bolas 6201
19	929920	R19-ROTO-1/2A7	Seguro 12
20	929921	R20-ROTO-1/2A7	Engrane
21	929922	R21-ROTO-1/2A7	Balín Ø5
22	929923	R22-ROTO-1/2A7	Balero de agujas Ø12xØ8x8
23	929924	R23-ROTO-1/2A7	Perilla
24	929925	R24-ROTO-1/2A7	Soporte con engrane
25	929926	R25-ROTO-1/2A7	Balero 608
26	929927	R26-ROTO-1/2A7	Armadura
27	929928	R27-ROTO-1/2A7	Porta carbón
28	929929	R28-ROTO-1/2A7	Carbones
29	929930	R29-ROTO-1/2A7	Resorte para carbón
31	929931	R31-ROTO-1/2A7	Tornillo ST 3x8
32	929932	R32-ROTO-1/2A7	Balero de bolas 626
33	929933	R33-ROTO-1/2A7	Campo
34	929934	R34-ROTO-1/2A7	Terminal eléctrica

