


No.	Código	Clave	Descripción
1	908662	R1-LIOR-1/4A2	Tornillo M4x15 mm
2	908663	R2-LIOR-1/4A2	Carcasa derecha
3	908664	R3-LIOR-1/4A2	Retén
4	90865	R4-LIOR-1/4A2	Poste
5	908666	R5-LIOR-1/4A2	Balero de bolas 627-2RS
6	908667	R6-LIOR-1/4A2	Bolsa recolectora
7	908668	R7-LIOR-1/4A2	Armazón bolsa
8	908669	R8-LIOR-1/4A2	Cable de alimentación
9	908670	R9-LIOR-1/4A2	Protector de cable
10	908671	R10-LIOR-1/4A2	Opresor de cable
11	908672	R11-LIOR-1/4A2	Carcasa izquierda
12	908673	R12-LIOR-1/4A2	Interruptor
13	908674	R13-LIOR-1/4A2	Guarda de interruptor
14	908675	R14-LIOR-1/4A2	Tornillo M3.5x16 mm
15	908676	R15-LIOR-1/4A2	Porta carbón
16	908677	R16-LIOR-1/4A2	Resorte
17	908678	R17-LIOR-1/4A2	Carbón
18	908679	R18-LIOR-1/4A2	Armadura
19	908680	R19-LIOR-1/4A2	Campo
19.1	908681	R19.1-LIOR-1/4A2	Terminal switch
19.2	908682	R19.2-LIOR-1/4A2	Terminal A portacarbón
19.3	908683	R19.3-LIOR-1/4A2	Terminal B portacarbón
19.4	908684	R19.4-LIOR-1/4A2	Protector de terminal
20	908685	R20-LIOR-1/4A2	Balero de bolas 608-608-2RS
21	908686	R21-LIOR-1/4A2	Ventilador excéntrico
22	908687	R22-LIOR-1/4A2	Felpa antipolvo
23	908688	R23-LIOR-1/4A2	Balero de bolas 6000-2RS
24	908689	R24-LIOR-1/4A2	Poste flexible
25	908690	R25-LIOR-1/4A2	Cubierta contrapolvo
26	908691	R26-LIOR-1/4A2	Tornillo M3.5x13 mm
27	908692	R27-LIOR-1/4A2	Tornillo M4.2x10 mm
28	908693	R28-LIOR-1/4A2	Clip sujetador
29	908694	R29-LIOR-1/4A2	Sujetador de lija
30	908695	R30-LIOR-1/4A2	Poste
31	908696	R31-LIOR-1/4A2	Base
32	908697	R32-LIOR-1/4A2	Tornillo M4.2x12 mm
33	ACC		Lija



Si tienes dudas, llama a la
Línea de Comunicación Directa

800-0187-873 Exclusivo
para México