

A

No.	Código	Clave	Descripción
1	949956	R1-POPA-1	Tuerca M8
2	949957	R2-POPA-1	Perilla
3	949958	R3-POPA-1	Tornillo hexagonal 6x12
4	949959	R4-POPA-1	Arandela de presión Ø6
5	949960	R5-POPA-1	Ensamble de palanca
6	949961	R6-POPA-1	Cambio de trinquete
7	949962	R7-POPA-1	Eje de cambio del trinquete
8	949963	R8-POPA-1	Resorte del eje
9	949964	R9-POPA-1	Placa de bloqueo
10	949965	R10-POPA-1	Engrane selector
11	949966	R11-POPA-1	Tuerca M8
12	949967	R12-POPA-1	Cubierta de freno
14	949968	R12-POPA-1	Tuerca M6
15	949969	R15-POPA-1	Resorte
16	949970	R16-POPA-1	Pastas de freno
17	949971	R17-POPA-1	Disco del trinquete
18	949972	R18-POPA-1	Asiento de freno
19	949973	R19-POPA-1	Seguro Ø9
20	949974	R20-POPA-1	Trinquete
21	949975	R21-POPA-1	Resorte del trinquete
22	94976	R22-POPA-1	Ensamble de placa A
23	949977	R23-POPA-1	Cubiert de la cadena
24	949978	R24-POPA-1	Baleros
25	949979	R25-POPA-1	Rodillo direccional
26	949980	R26-POPA-1t	Placa bloqueo de cadena




A



B

No.	Código	Clave	Descripción
27	949981	R27-POPA-1	Ensamble de placa B
28	949982	R28-POPA-1	Ensamble de eje
29	949983	R29-POPA-1	Piñón
30	949984	R30-POPA-1	Engrane
31	949985	R31-POPA-1	Seguro Ø21
32	949986	R32-POPA-1	Ensamble de placa exterior
33	949987	R33-POPA-1	Perno 12x44
34	949988	R34-POPA-1	Ensamble de gancho superior
35	949989	R35-POPA-1	Cadena
36	949990	R36-POPA-1	Tornillo hexagonal 6x32
37	949991	R37-POPA-1	Tuerca M6
38	949992	R38-POPA-1	Ensamble de gancho inferior
39	949993	R39-POPA-1	Ancla final
40	949994	R40-POPA-1	Empuñadura
41	949995	R41-POPA-1	Tornillo de bloqueo M4
42	949996	R42-POPA-1	Tornillo 4x6
43	949997	R43-POPA-1	Tornillo 6x44
44	949998	R44-POPA-1	Tuerca M6



B