


A

No.	Código	Clave	Descripción
1	929140	R1-POLE-1000	Tornillo M10x26
2	929141	R2-POLE-1000	Arandela Ø12
3	929142	R3-POLE-1000	Tornillo M12x30
4	929143	R4-POLE-1000	Aro de sejección
5	929144	R5-POLE-1000	Carcasa
6	929145	R6-POLE-1000	Balero 6204
7	929146	R7-POLE-1000	Cuña de cuerda
8	929147	R8-POLE-1000	Carrete de cable
9	929148	R9-POLE-1000	Broche de cuerda
10			Bloqueador de cuerda
11			Cable de acero
12			Guardacabo
13			Gancho
14	929149	R14-POLE-1000	Freno manual
14.1	929150	R14.1-POLE-1000	Soporte placa
14.2	929151	R14.2-POLE-1000	Tornillo M4x8
15	929152	R15-POLE-1000	Pasador
16	929153	R16-POLE-1000	Eje
16.1	929154	R16.1-POLE-1000	Seguro Ø25
17	929155	R17-POLE-1000	Cuña 8x30
18	929156	R18-POLE-1000	Cuña 8x20
20	929157	R20-POLE-1000	Balero de bolas 6205
21	929158	R21-POLE-1000	Tornillos M6x18
22	929159	R22-POLE-1000	Caja de engranes
25	929160	R25-POLE-1000	Engrane secundario
26	929161	R26-POLE-1000	Junta
27	929162	R27-POLE-1000	Balero de bolas 6202
28	929163	R28-POLE-1000	Piñón loco
28.1	929164	R28.1-POLE-1000	Cuñero
29	929165	R29-POLE-1000	Engrane primario
30	929166	R30-POLE-1000	Cubierta frontal
31	929167	R31-POLE-1000	Balero de bolas 6201
32	929168	R32-POLE-1000	Rotor




A



B

No.	Código	Clave	Descripción
33	929169	R33-POLE-1000	Campo
34			Carcasa de motor
35	929170	R35-POLE-1000	Resorte
36	929171	R36-POLE-1000	Tambor de freno
37	929172	R37-POLE-1000	Cubierta de motor
38	929173	R38-POLE-1000	Ventilador
39	929174	R39-POLE-1000	Tornillos M6x190
39.1	929175	R39.1-POLE-1000	Arandela Ø6
39.2	929176	R39.2-POLE-1000	Arandela de presi Ø6
41	929177	R41-POLE-1000	Tapa de ventilador
41.1	929178	R41.1-POLE-1000	Tornillo M4x6
43	929179	R43-POLE-1000	Caja de conexiones
43.1	929180	R43.1-POLE-1000	Tornillo St 2.9x14.7
43.2	929181	R43.2-POLE-1000	Arandela Ø3
44	929182	R44-POLE-1000	Caja de conexiones
44.1	929183	R44.1-POLE-1000	Tornillo M4x12
48	929184	R48-POLE-1000	Caja de conexiones
48.1	929185	R48.1-POLE-1000	Tornillo st4.2x16
49	929186	R49-POLE-1000	Interruptor
49.1	929187	R49.1-POLE-1000	Tornillo St 2.9x14.7
50	929188	R50-POLE-1000	Eje de interruptor
50.1	929189	R50.1-POLE-1000	Seguro de tensin
51	929190	R51-POLE-1000	Tablero de conexiones
51.1	929191	R51.1-POLE-1000	Cable
52	929192	R52-POLE-1000	Seguro de tensin
55	929193	R55-POLE-1000	Cable de alimentacin
55.1	929194	R55.1-POLE-1000	Tornillo St 4.2x16
55.2	929195	R55.2-POLE-1000	Arandela Ø3
55.3	929196	R55.3-POLE-1000	Opresor de cable
56	929197	R56-POLE-1000	Cable de alimentacin
59	929198	R59-POLE-1000	Tornillo St 3.5x18
60	929199	R60-POLE-1000	Carcasa de mango
62	929200	R62-POLE-1000	Capacitor 85 y 90 uf



B



No.	Código	Clave	Descripción
C 63	929201	R63-POLE-1000	Tapa de mango
64	929202	R64-POLE-1000	Seguro para eliminación de filos
65	929203	R65-POLE-1000	Polea
68	929204	R68-POLE-1000	Perno
68.1	929205	R68.1-POLE-1000	Arandela Ø16x27x5.3
68.2	929206	R68.2-POLE-1000	Arandela Ø14x26.5x2
68.3	929207	R68.3-POLE-1000	Chaveta Ø2.5x25
76	929208	R76-POLE-1000	Resorte 18.8 g
78	929209	R78-POLE-1000	Balero de bolas 6203
86	929210	R86-POLE-1000	Seguro de tensión
91	929211	R91-POLE-1000	Arandela plana
92	929212	R92-POLE-1000	Seguro C
95	929213	R95-POLE-1000	Interruptor
97	929214	R97-POLE-1000	Seguro C
124	929215	R124-POLE-1000	Gancho
125	929216	R125-POLE-1000	Tornillo M5x30
126	929217	R126-POLE-1000	Arandela de presión
127	929218	R127-POLE-1000	Balero 6303

