


A

No.	Código	Clave	Descripción
1	926887	R1-ESRE-1/4N	Tornillo Phillips ST4X35
2	926888	R2-ESRE-1/4N	Tuerca M15
3	926889	R3-ESRE-1/4N	Collet Ø 6
4	926890	R4-ESRE-1/4N	Anillo antipolvo
5	926891	R5-ESRE-1/4N	Carcaza de Flecha
6	926892	R6-ESRE-1/4N	Flecha
7	926893	R7-ESRE-1/4N	Balero 6901
8	926894	R8-ESRE-1/4N	Seguro Ø 12
9	926895	R9-ESRE-1/4N	Balerode bolas 6200
10	926896	R10-ESRE-1/4N	Circlip for hole\φ30
11	926897	R11-ESRE-1/4N	Adaptador
12	926898	R12-ESRE-1/4N	Resorte
13	926899	R13-ESRE-1/4N	Seguro Ø 10
14	926900	R14-ESRE-1/4N	Tapa intermedia
15	926901	R15-ESRE-1/4N	Balero de bolas 6000
16	926902	R16-ESRE-1/4N	Seguro Ø 26
17	926903	R17-ESRE-1/4N	Armadura
18	926904	R18-ESRE-1/4N	Balero de bolas 608
19	926905	R19-ESRE-1/4N	Protector de Balero
20	926906	R20-ESRE-1/4N	Deflector
21	926907	R21-ESRE-1/4N	Tornillo ST4X60
22	926908	R22-ESRE-1/4N	Campo



B

No.	Código	Clave	Descripción
23	926909	R23-ESRE-1/4N	Inductor
24	926910	R24-ESRE-1/4N	Carcaza
25	ACC		Carbones
26	948640	R26-ESRE-1/4N	Porta Carbón
27	926911	R27-ESRE-1/4N	Tornillos ST 4X10
28	926912	R28-ESRE-1/4N	Interruptor
29	926913	R29-ESRE-1/4N	Tornillo cabeza phillips ST4X14
30	926914	R30-ESRE-1/4N	Opresor de cable
31	926915	R31-ESRE-1/4N	Capacitor
33	926916	R33-ESRE-1/4N	Cubierta trasera
34	926917	R34-ESRE-1/4N	Tornillo ST4X16
35	926918	R35-ESRE-1/4N	Protector de cable
36	926919	R36-ESRE-1/4N	Cable de alimentación
37	926920	R37-ESRE-1/4N	Boton de encendido
38	926921	R38-ESRE-1/4N	Leva
39	926922	R39-ESRE-1/4N	Carcaza de interruptor
40	926923	R40-ESRE-1/4N	Tornillo cabeza phillips plana ST4X14
42	926924	R42-ESRE-1/4N	Control de velocidad
43	926925	R43-ESRE-1/4N	Llaves
44	926926	R44-ESRE-1/4N	Empuñadura
45	926927	R45-ESRE-1/4N	Tornillo M8X110
46	926928	R46-ESRE-1/4N	Seguro de mango auxiliar
47	926929	R47-ESRE-1/4N	Mango Auxiliar

