

No.	Código	Clave	Descripción
1	930036	R1-TPN-875-2	Ensamble de carcasa
2	930037	R2-TPN-875-2	Ensamble de gatillo
3	930038	R3-TPN-875-2	Perno
4	930039	R4-TPN-875-2	Sello
5	930040	R5-TPN-875-2	Sello
6	930041	R6-TPN-875-2	Vástago de válvula
7	930042	R7-TPN-875-2	Resorte
8	930043	R8-TPN-875-2	Regulador de aire
9	930044	R9-TPN-875-2	Sello
10	930045	R10-TPN-875-2	Sello
11	930046	R11-TPN-875-2	Tapón de válvula
12.1	930047	R12.1-TPN-875-2	Balero de bolas 625
12.2	930048	R12.2-TPN-875-2	Tapón final
12.3	930049	R12.3-TPN-875-2	Perno
12.4	930050	R12.4-TPN-875-2	Rotor
12.5	930051	R12.5-TPN-875-2	Aspas de rotor
12.6	930052	R12.6-TPN-875-2	Cilindro
12.7	930053	R12.7-TPN-875-2	Espaciador de rotor
12.8	930054	R12.8-TPN-875-2	Tapa frontal
12.9	930055	R12.9-TPN-875-2	Balero de bolas 608
12.10	930056	R12.10-TPN-875-2	Engrane
13	930057	R13-TPN-875-2	Conexión de tuerca
14	930058	R14-TPN-875-2	Tuerca
15	930059	R15-TPN-875-2	Cabeza de ángulo
16	930060	R16-TPN-875-2	Válvula para engrasar
17	930061	R17-TPN-875-2	Balero de bolas
18	930062	R18-TPN-875-2	Piñón
19	930063	R19-TPN-875-2	Balero de bolas 608
20	930064	R20-TPN-875-2	Tuerca de seguridad
21	930065	R21-TPN-875-2	Husillo de trabajo
22	930066	R22-TPN-875-2	Cuñero
23	930067	R23-TPN-875-2	Collet
24	930068	R24-TPN-875-2	Tuerca de collet
25	930069	R25-TPN-875-2	Llave
26	930070	R26-TPN-875-2	Llave

