

No.	Código	Clave	Descripción
1	929788	R1-TPN-886-2	Carcasa
2	929789	R2-TPN-886-2	Conector de aire
3	929790	R3-TPN-886-2	Palanca de aceleración
4	929791	R4-TPN-886-2	Remache
5	929792	R5-TPN-886-2	Sello
6	929793	R6-TPN-886-2	Aguja de válvula
7	929794	R7-TPN-886-2	Resorte
8	929795	R8-TPN-886-2	Sello
9	929796	R9-TPN-886-2	Tapa roscada
10.1	929797	R10.1-TPN-886-2	Balero de bolas 626
10.2	929798	R10.2-TPN-886-2	Placa trasera
10.3	929799	R10.3-TPN-886-2	Aspas de rotor
10.4	929800	R10.4-TPN-886-2	Rotor
10.5	929801	R10.5-TPN-886-2	Perno
10.6	929802	R10.6-TPN-886-2	Cilindro
10.7	929803	R10.7-TPN-886-2	Tapa frontal
10.8	929804	R10.8-TPN-886-2	Balero de bolas 608
11	929805	R11-TPN-886-2	Arandela
12	929806	R12-TPN-886-2	Engrane con rosca
13	929807	R13-TPN-886-2	Engrane
14	929808	R14-TPN-886-2	Perno
15	929809	R15-TPN-886-2	Placa de engrane
16	929810	R16-TPN-886-2	Tuerca
17	929811	R17-TPN-886-2	Buje
18	929812	R18-TPN-886-2	Trinquete de carcasa
19	929813	R19-TPN-886-2	Balero de agujas
20	929814	R20-TPN-886-2	Cigüeñal
21	929815	R21-TPN-886-2	Impulsor de buje
22	929816	R22-TPN-886-2	Trinquete de yugo
23	929817	R23-TPN-886-2	Interruptor de reversa
24	929818	R24-TPN-886-2	Resorte
25	929819	R25-TPN-886-2	Perno
26	929820	R26-TPN-886-2	Arandela
27	929821	R27-TPN-886-2	Ensamble trinquete
28	929822	R28-TPN-886-2	Seguro de yunque
29	929823	R29-TPN-886-2	Resorte
30	929824	R30-TPN-886-2	Balín
31	929825	R31-TPN-886-2	Perno
32	929826	R32-TPN-886-2	Arandela
33	929827	R33-TPN-886-2	Seguro C

