

| No. | Código | Clave           | Descripción                      |
|-----|--------|-----------------|----------------------------------|
| 1   | 920947 | R1-SOPLA-1440   | Ensamble de mango                |
| 1.1 | 920948 | R1.1-SOPLA-1440 | Carcasa izquierda de mango       |
| 1.2 | 920949 | R1.2-SOPLA-1440 | Soporte superior                 |
| 1.3 | 920950 | R1.3-SOPLA-1440 | Soporte inferior                 |
| 1.4 | 920951 | R1.4-SOPLA-1440 | Carcasa derecha de mango         |
| 1.5 | 920952 | R1.5-SOPLA-1440 | Tornillo                         |
| 2   | 920953 | R2-SOPLA-1440   | Ensamble de interruptor          |
| 2.1 | 920954 | R2.1-SOPLA-1440 | Botón                            |
| 2.2 | 920955 | R2.2-SOPLA-1440 | Palanca                          |
| 2.3 | 920956 | R2.3-SOPLA-1440 | Interruptor                      |
| 3   | 920957 | R3-SOPLA-1440   | Ensamble de motor                |
| 4   | 920958 | R4-SOPLA-1440   | Ensamble de carcasa de motor     |
| 4.1 | 920959 | R4.1-SOPLA-1440 | Tornillo                         |
| 4.2 | 920960 | R4.2-SOPLA-1440 | Carcasa izquierda de motor       |
| 4.3 | 920961 | R4.3-SOPLA-1440 | Soporte de motor                 |
| 4.4 | 920962 | R4.4-SOPLA-1440 | Carcasa derecha de motor         |
| 5   | 920963 | R5-SOPLA-1440   | Ensamble de válvula de seguridad |
| 6   | 920964 | R6-SOPLA-1440   | Extensión                        |
| 7   | 920965 | R7-SOPLA-1440   | Extensión                        |
| 7.1 | 920966 | R7.1-SOPLA-1440 | Rueda                            |
| 7.2 | 920967 | R7.2-SOPLA-1440 | Rueda                            |
| 8   | 920968 | R8-SOPLA-1440   | Boquilla                         |
| 9   | 920969 | R9-SOPLA-1440   | Extensión                        |
| 10  | 920970 | R10-SOPLA-1440  | Bolsa recolectora                |

