


A

No.	Código	Clave	Descripción
1	938619	R1-ROTO-1/2N6	Tornillo izquierdo M6x25
2	938620	R2-ROTO-1/2N6	Broquero 1/2"
3	938621	R3-ROTO-1/2N6	Flecha
4	938622	R4-ROTO-1/2N6	Balin Ø5
5	938623	R5-ROTO-1/2N6	Resorte
6	938624	R6-ROTO-1/2N6	Balero de bolas 6001
7	938625	R7-ROTO-1/2N6	Seguro Ø 12
8	938626	R8-ROTO-1/2N6	Engrane grande
9	938627	R9-ROTO-1/2N6	Balero de auja HK0808
10	938628	R10-ROTO-1/2N6	Perilla
11	938629	R11-ROTO-1/2N6	Palanca para rotomartillo
12	938630	R12-ROTO-1/2N6	Soporte de balero
13	938631	R13-ROTO-1/2N6	Balero de bolas 608
14	938632	R14-ROTO-1/2N6	Armadura
15	938633	R15-ROTO-1/2N6	Balero de bolas 627
16	938634	R16-ROTO-1/2N6	Campo
17	938635	R17-ROTO-1/2N6	Carbones
18	938636	R18-ROTO-1/2N6	Resorte
19	938637	R19-ROTO-1/2N6	Porta carbón derecho
23	938638	R23-ROTO-1/2N6	Porta carbón izquierdo
20	938639	R20-ROTO-1/2N6	Tornillo ST2.9x12




A



B

No.	Código	Clave	Descripción
21	938640	R21-ROTO-1/2N6	Carcasa derecha
31	938641	R31-ROTO-1/2N6	Carcasa izquierda
22	938642	R22-ROTO-1/2N6	Tornillo ST4.2x16
24	938643	R24-ROTO-1/2N6	Perilla de cambios
25	938644	R25-ROTO-1/2N6	Interruptor
27	938645	R27-ROTO-1/2N8	Protector de cable
28	938646	R28-ROTO-1/2N6	Cable de alimentación
32	938647	R32-ROTO-1/2N6	Tornillo M8x90
33	938648	R33-ROTO-1/2N6	Arandela
34	ACC		Soporte de manija
35	ACC		Manija
36	ACC		Tapón de manija
37	ACC		Barra de profundidades
37	ACC		Llave de broquero



B

