



No.	Código	Clave	Descripción
1	913822	R1-LIOR-1/3P3	Aspas de ventilador
2	913823	R2-LIOR-1/3P3	Armadura
3	913824	R3-LIOR-1/3P3	Cable conector
4	913825	R4-LIOR-1/3P3	Campo
5	913826	R5-LIOR-1/3P3	Buje
6	913827	R6-LIOR-1/3P3	Asiento del buje
7	913828	R7-LIOR-1/3P3	Tapón de hule
8	913829	R8-LIOR-1/3P3	Interruptor
9	913830	R9-LIOR-1/3P3	Carcasa derecha
9.1	913831	R9.1-LIOR-1/3P3	Carcasa izquierda
10	913832	R10-LIOR-1/3P3	Tornillo St M3.9x19
12	913833	R12-LIOR-1/3P3	Tornillo St M3.9x14
13	913834	R13-LIOR-1/3P3	Opresor de cable
14	913835	R14-LIOR-1/3P3	Protector de cable
15	913836	R15-LIOR-1/3P3	Cable de alimentación
16	913837	R16-LIOR-1/3P3	Adaptador para colector de polvo
17	913838	R17-LIOR-1/3P3	Empaque de hule Ø18
18	913839	R18-LIOR-1/3P3	Porta carbón
18.1	913840	R18.1-LIOR-1/3P3	Cable conector
19	913841	R19-LIOR-1/3P3	Inserto porta carbón
20	913842	R20-LIOR-1/3P3	Carbón
21	913843	R21-LIOR-1/3P3	Poste flexible
22	913844	R22-LIOR-1/3P3	Felpa antipolvo
24	913845	R24-LIOR-1/3P3	Tornillo Std M3.9x12
25	913846	R25-LIOR-1/3P3	Base
26	913847	R26-LIOR-1/3P3	Palanca tensora
27	913848	R27-LIOR-1/3P3	Balero bolas 6001Z
28	913849	R28-LIOR-1/3P3	Aspas de ventilador
29	913850	R29-LIOR-1/3P3	Espaciador
30	913851	R30-LIOR-1/3P3	Anillo revestimiento
31	913852	R31-LIOR-1/3P3	Balero bolas 627Z
32	913853	R32-LIOR-1/3P3	Cubre balero frontal

