





A	No.	Código	Clave	Descripción
	A1	943865	RA1-GEN-25P	Tornillo M6x12
	A2	943866	RA2-GEN-25P	Tubo de respiración
	A3	943867	RA3-GEN-25P	Tapa de punterías
	A4	943868	RA4-GEN-25P	Junta de tapa
	A5	943869	RA5-GEN-25P	Tornillo M8x55
	A6	943870	RA6-GEN-25P	Bujía
	A7	943871	RA7-GEN-25P	Tornillo sin fin M6x90
	A8	943872	RA8-GEN-25P	Tornillo sin fin M8x32
	A9	943873	RA9-GEN-25P	Junta de cabeza de cilindro
	A10	943874	RA10-GEN-25P	Buje
	A11	943875	RA11-GEN-25P	Cabeza de cilindro
B	B1	943876	RB1-GEN-25P	Set de anillos de pistón
	B2	943877	RB2-GEN-25P	Perno de pistón
	B3	943878	RB3-GEN-25P	Seguro de pistón
	B4	943879	RB4-GEN-25P	Pistón
	B5	943880	RB5-GEN-25P	Ensamble de biela
C	C1	943881	RC1-GEN-25P	Cigüeñal
	C2	943882	RC2-GEN-25P	Cuñero




D

No.	Código	Clave	Descripción
D1	943883	RD1-GEN-25P	Retén 25x41x6
D2	943884	RD2-GEN-25P	Cárter
D3	943885	RD3-GEN-25P	Tornillo de drena M12x1.5
D4	943886	RD4-GEN-25P	Arandela 12x20x1.5
D5	943887	RD5-GEN-25P	Balero de bolas 6205
D6	943888	RD6-GEN-25P	Eje
D7	943889	RD7-GEN-25P	Arandela 6.2x13x1
D8	943890	RD8-GEN-25P	Gobernador
D9	943891	RD9-GEN-25P	Camisa de eje
D10	943892	RD10-GEN-25P	Interruptor de nivel de aceite
D11	943893	RD11-GEN-25P	Buje 8x14
D12	943894	RD12-GEN-25P	Base de gobernador
E			
E1	943895	RE1-GEN-25P	Conjunto de balancines
E2	943896	RE2-GEN-25P	Placa guía
E3	943897	RE3-GEN-25P	Rotador
E4	943898	RE4-GEN-25P	Retenedor de muelle
E5	943899	RE5-GEN-25P	Resorte
E6	943900	RE6-GEN-25P	Asiento muelle
E7	943901	RE7-GEN-25P	Sello de vástago
E8	943902	RE8-GEN-25P	Válvula de admisión
E9	943903	RE9-GEN-25P	Válvula de escape
E10	943904	RE10-GEN-25P	Varilla de empuje 1
E11	943905	RE11-GEN-25P	Elevador de válvula
E12	943906	RE12-GEN-25P	Árbol de levas

E



D



E



F

No.	Código	Clave	Descripción
F1	943907	RF1-GEN-25P	Junta de cárter
F2	943908	RF2-GEN-25P	Balero de bolas 6205
F3	943909	RF3-GEN-25P	Ensamble de bayoneta
F4	943910	RF4-GEN-25P	Tapa de cárter
F5	943911	RF5-GEN-25P	Retén 25x41x6
F6	943912	RF6-GEN-25P	Tornillo M8x32
G1	943913	RG1-GEN-25P	Tuerca especial M14
G2	943914	RG2-GEN-25P	Polea de arranque
G3	943915	RG3-GEN-25P	Aspas de ventilador
G4	943916	RG4-GEN-25P	Volante
G5	943917	RG5-BASE-40P	Tornillo M6x25
G6	943918	RG6-GEN-25P	Soporte para tensión
G7	943919	RG7-GEN-25P	Unidad de alerta de aceite
G9	943920	RG9-GEN-25P	Tornillo M6x25
G10	943921	RG10-GEN-25P	Bobina
H1	943922	RH1-GEN-25P	Tornillo M6x7
H2	943923	RH2-GEN-25P	Sistema de arranque
H3	943924	RH3-GEN-25P	Tornillo M6x12
H4	943925	RH4-GEN-25P	Cubierta ventilador
I1	943926	RI1-GEN-25P	Barra de aceleración
I2	943927	RI2-GEN-25P	Resorte de aceleración
I3	943928	RI3-GEN-25P	Resorte de retorno
I4	943929	RI4-GEN-25P	Soporte de gobernador
I5	943930	RI5-GEN-25P	Brazo de gobernador
I6	943931	RI6-GEN-25P	Tornillo especial M6x21
I7	943932	RI7-GEN-25P	Tuerca M6
I8	943933	RI8-GEN-25P	Seguro
I9	943934	RI9-GEN-25P	Retén
I10	943935	RI10-GEN-25P	Barra de gobernador


G

H


I



F




G




J

No.	Código	Clave	Descripción
J1	943936	RJ1-GEN-25P	Ensamble de filtro de aire
J2	943937	RJ2-GEN-25P	Filtro
J3	943938	RJ3-GEN-25P	Junta de base carburador
J4	943939	RJ4-GEN-25P	Junta de carburador
J5	943940	RJ5-GEN-25P	Ensamble de carburador
J6	943941	RJ6-GEN-25P	Base carburador
J7	943942	RJ7-GEN-25P	Junta de carburador
K	K1	943943	Tapón de tanque
	K2	943944	Junta de tapón
	K3	943945	Filtro para gasolina
	K4	943946	Tanque de gasolina
	K5	943947	Tornillo M5x10
	K6	943948	Flotador de gasolina
	K7	943949	Tornillo M6x22
	K8	943950	Arandela
	K9	943951	Buje
	K10	943952	Soporte de tanque
	K11	943953	Válvula de paso
	K12	943954	Abrazadera
	K13	943955	Manguera 5x9

J



K




L


No.	Código	Clave	Descripción
L1	943956	RL1-GEN-25P	Ensamble de rotor
L2	943957	RL2-GEN-25P	Tapa de motor
L3	943958	RL3-GEN-25P	Carbón
L4	943959	RL4-GEN-25P	Tornillo M5x20
L5	943960	RL5-GEN-25P	Tornillo M5x16
L6	943961	RL6-GEN-25P	Tabla de conexiones
L7	943962	RL7-GEN-25P	Tuerca M5
L8	943963	RL8-GEN-25P	Arandela 5
L9	943964	RL9-GEN-25P	Arandela de presión 10
L10	943965	RL10-GEN-25P	Tornillo M5x12
L11	943966	RL11-GEN-25P	Regulador de voltaje
L12	943967	RL12-GEN-25P	Arandela de presión 10
L13	943968	RL13-GEN-25P	Tonillo M8x220
L14	943969	RL14-GEN-25P	Tornillo M6x145
L15	943970	RL15-GEN-25P	Tapa trasera de generador
L16	943971	RL16-GEN-25P	Tornillo M5x12
L17	943972	RL17-GEN-25P	Puente rectificador

M

M1	943973	RM1-GEN-25P	Junta de mofle
K12	943974	RM2-GEN-25P	Mofle
M3	943975	RM3-GEN-25P	Arandela de presión
M4	943976	RM4-GEN-25P	Tuerca M8
M5	943977	RM5-GEN-25P	Soporte de mofle
M6	943978	RM6-GEN-25P	Tornillo M8x16
M7	943979	RM7-GEN-25P	Tablero de aislamiento
M8		RM8-GEN-25P	Tornillo M6x12



L




M




N

P

No.	Código	Clave	Descripción
N1	943980	RN1-GEN-25P	Tornillo M6x12
N3	943981	RN3-GEN-25P	Motor
N4	943982	RN4-GEN-25P	Tuerca M8
N7	943983	RN7-GEN-25P	Amortiguador izquierdo
N8	943984	RN8-GEN-25P	Amortiguador derecho
N9	943985	RN9-GEN-25P	Patas
P1	943986	RP1-GEN-25P	Panel frontal
P2	943987	RP2-GEN-25P	Chapa de encendido
P3	943988	RP3-GEN-25P	Voltímetro
P4	943989	RP4-GEN-25P	Interruptor de seguridad
P5	943990	RP5-GEN-25P	Contacto 30A/240V
P6	943991	RP6-GEN-25P	Tornillo M6x18
P7	943992	RP7-GEN-25P	Arandela 6x12x0.9
P8	943993	RP8-GEN-25P	Arandela de presión 6
P9	943994	RP9-GEN-25P	Tuerca M6
P10	943995	RP10-GEN-25P	Cubierta trasera
P12	943996	RP12-GEN-25P	Tornillo M6x12
P13	943997	RP13-GEN-25P	Protector térmico
P14	943998	RP14-GEN-25P	Interruptor de voltaje
P15	943999	RP15-GEN-25P	Contactos 20A/ 125 V
P16	944000	RP16-GEN-25P	Terminales (+)(-)
P18	944001	RP18-GEN-25P	Arnés maestro



N



P