



No.	Código	Clave	Descripción
2	952193	R2-BOS-3/4LPP	Cable de alimentación
3	952194	R3-BOS-3/4LPP	Tornillo ST4x35mm
4	952195	R4-BOS-3/4LPP	Carcasa de bomba
5	952196	R5-BOS-3/4LPP	Protector de cable de alim. 1
6	952197	R6-BOS-3/4LPP	Protector de cable del interr. 2
7	952198	R7-BOS-3/4LPP	Opresor de cable
8	952199	R8-BOS-3/4LPP	Cable 8uf
9	952200	R9-BOS-3/4LPP	Retenedor del capacitor
10	952201	R10-BOS-3/4LPP	Tornillo ST4x30mm
11	952202	R11-BOS-3/4LPP	Cubierta trasera del motor
12	952203	R12-BOS-3/4LPP	Arandela ondulada diam.25.5x31x3
13	952204	R13-BOS-3/4LPP	Balero de bolas 6201
14	952205	R14-BOS-3/4LPP	Seguro tipo "C" diam. 10x20x1
15	952206	R15-BOS-3/4LPP	Rotor
18	952207	R18-BOS-3/4LPP	Ensamble de campo
20	952208	R20-BOS-3/4LPP	Sello de aceite 12x24x4.5
21	ACC		Tubo de conexión de salida
22	ACC		Anillo "O"
23	ACC		Codo de conexión
24	952209	R24-BOS-3/4LPP	Anillo "O" diam.89.5x5
25	952210	R25-BOS-3/4LPP	Cuerpo principal
26	952211	R26-BOS-3/4LPP	Balín diam. 6
27	952212	R27-BOS-3/4LPP	Arandela plana diam. 8.5x16x1
28	952213	R28-BOS-3/4LPP	Impulsor
29	952214	R29-BOS-3/4LPP	Tuerca M8
30	952215	R30-BOS-3/4LPP	Anillo "O" diam. 112x3
31	952216	R31-BOS-3/4LPP	Base

