

No.	Código	Clave	Descripción
1	944999	R1-LIOR-1-3P4	Base de esponja
2	950000	R2-LIOR-1-3P4	Tornillo cbz. phillips ST4x14 zincado
3	950001	R3-LIOR-1-3P4	Base
3.1	950002	R3.1-LIOR-1-3P4	Felpa anti polvo
4	950003	R4-LIOR-1-3P4	Palanca tensora
5	950004	R5-LIOR-1-3P4	Poste flexible
6	950005	R6-LIOR-1-3P4	Balero 6001
7	950006	R7-LIOR-1-3P4	Aspas de rotor
8	950007	R8-LIOR-1-3P4	Balero 607
9	950008	R9-LIOR-1-3P4	Ventilador
10	950009	R10-LIOR-1-3P4	Armadura
10.1	950010	R10.1-LIOR-1-3P4	Arandela 7x12x.5
11	950011	R11-LIOR-1-3P4	Carcasa derecha
12	950012	R12-LIOR-1-3P4	Tornillo 4x19
13	950013	R13-LIOR-1-3P4	Campo
14	950014	R14-LIOR-1-3P4	Porta carbón
15	950015	R15-LIOR-1-3P4	Inserto de carbón
17	950016	R17-LIOR-1-3P4	Balero 627
18	950017	R18-LIOR-1-3P4	Carcasa izquierda
19	950018	R19-LIOR-1-3P4	Conector
20	950019	R20-LIOR-1-3P4	Interruptor
20.1	950020	R20.1-LIOR-1-3P4	Arnes
21	950021	R21-LIOR-1-3P4	Tornillo cbz. phillips St4x14 pavonado
22	950022	R22-LIOR-1-3P4	Opresor de cable
23	950023	R23-LIOR-1-3P4	Protector de cable
24	950024	R24-LIOR-1-3P4	Cable de alimentación

