


A

No.	Código	Clave	Descripción
1	939216	R1-TALI-12P	Tornillo Especial Curda Izquierda
2	939217	R2-TALI-12P	Broquero
3	939218	R3-TALI-12P	Caja de Engranajes
4	939219	R4-TALI-12P	Tornillo
5	939220	R5-TALI-12P	Arandela de Presión
6	939221	R6-TALI-12P	Piñón
7	939222	R7-TALI-12P	Motor CD
8	939223	R8-TALI-12P	Arnes de Luz
9	939224	R9-TALI-12P	Perilla para cambio sentido
10	939225	R10-TALI-12P	Interruptor
11	939226	R11-TALI-12P	Conector Rápido
12	939227	R12-TALI-12P	Carcasa Izquierda
13	ACC		Bateria 12 Volts
14	ACC		Cargador
15	939228	R15-TALI-12P	Carcasa Derecha
16	939229	R16-TALI-12P	Tornillo



A

