


A


No.	Código	Clave	Descripción
1	941207	R1-EBA-5P	Ensamble de rotor
2	941208	R2-EBA-5P	Balero 6002
3	941209	R3-EBA-5P	Tornillo M5x12
4	941210	R4-EBA-5P	Abrazadera
5	941211	R5-EBA-5P	Protector de cable
6	941212	R6-EBA-5P	Cable de alimentación
7	941213	R7-EBA-5P	Cilindro de motor
8	941214	R8-EBA-5P	Campo
9	941215	R9-EBA-5P	Tapa trasera
10	941216	R10-EBA-5P	Tornillo M5x135
11	941217	R11-EBA-5P	Tornillo M8x16
12	941218	R12-EBA-5P	Placa soporte
13	941219	R13-EBA-5P	Soporte derecho para guarda
14	941220	R14-EBA-5P	Tornillo M6x16
15	941221	R15-EBA-5P	Tornillo M4x10
16	941222	R16-EBA-5P	Bisagra de guarda
17	941223	R17-EBA-5P	Arandela plana 4
18	941224	R18-EBA-5P	Tuerca M4
19	941225	R19-EBA-5P	Arandela plana 6
20	941226	R20-EBA-5P	Arandela de presión 6
21	941227	R21-EBA-5P	Tuerca M6
22	941228	R22-EBA-5P	Guarda protectora derecha
23	941229	R23-EBA-5P	Tuerca M5
24	941230	R24-EBA-5P	Soporte de guarda
25	941231	R25-EBA-5P	Tornillo M5x10
26	941232	R26-EBA-5P	Guarda derecha
27	941233	R27-EBA-5P	Tornillo M5x10
28	941234	R28-EBA-5P	Brida exterior 6"
29	941235	R29-EBA-5P	Piedra esmeril desbaste
30	941236	R30-EBA-5P	Tuerca M12



A

B

No.	Código	Clave	Descripción
31	941237	R31-EBA-5P	Tapa de guarda
32	941238	R32-EBA-5P	Tornillo M5x42
33	941239	R33-EBA-5P	Tornillo especial M6x12
34	941240	R34-EBA-5P	Soporte de apoyo
35	941241	R35-EBA-5P	Arandela dentada 6
36	941242	R36-EBA-5P	Arandela plana 6
37	941243	R37-EBA-5P	Perilla M6
38	941244	R38-EBA-5P	Pata
39	941245	R39-EBA-5P	Tornilo M5x10
40	941246	R40-EBA-5P	Tapa inferior
41	941247	R41-EBA-5P	Tornillo M5x8
42	941248	R42-EBA-5P	Arandela de presión 5
43	941249	R43-EBA-5P	Terminal de ojillo 5
44	941250	R44-EBA-5P	Arandela dentada 5
45	941251	R45-EBA-5P	Base
46	941252	R46-EBA-5P	Tornillo M6x12
47	941253	R47-EBA-5P	Capacitor 8uF/250V
47.1	941254	R47.1-EBA-5P	Abrazadera para capacitor
48	941255	R48-EBA-5P	Tornillo M5x14
49	941256	R49-EBA-5P	Interruptor
49.1	941257	R49.1-EBA-5P	Cubrepolvo
50	941258	R50-EBA-5P	Arandela plana 5
51	941259	R51-EBA-5P	Arandela de presión 5
52	941260	R52-EBA-5P	Tuerca M5
53	941261	R53-EBA-5P	Guarda izquierda
54	941262	R54-EBA-5P	Piedra de esmeril para afilar
55	941263	R55-EBA-5P	Tuerca M12 especial
56	941264	R56-EBA-5P	Guarda protectora izquierda
57	941265	R57-EBA-5P	Soporte izquierda para guarda



B

