

A

A

No.	Código	Clave	Descripción
1	931757	R1-CALE 6I-N	Indicación digital
2	931758	R2-CALE 6I-N	Perilla
3	931759	R3-CALE 6I-N	Panel frontal
4	931760	R4-CALE 6I-N	Interruptor con arnes
5	931761	R5-CALE 6I-N	Tornillo M4x12
6	931762	R6-CALE 6I-N	Deflector protector
7	931763	R7-CALE 6I-N	Tornillo M4x10
8	931764	R8-CALE 6I-N	Abrazaderas de bujías
9	931765	R9-CALE 6I-N	Bujía de chispeo
10	931766	R10-CALE 6I-N	Sensor de temperatura
11	941590	R11-CALE 6I-N	Quemador con espreas para gas natural
12	931768	R12-CALE 6I-N	Tornillo M4x12
13	931769	R13-CALE 6I-N	Tornillo M5x12
14	931770	R14-CALE 6I-N	Ensam. de válvula de entrada de gas
14.1	931771	R14.1-CALE 6I-N	Solenoide para gas
14.2	931772	R14.2-CALE 6I-N	Sello Ø25.5x32x2.4
14.3	931773	R14.3-CALE 6I-N	Válvula para gas
14.4	931774	R14.4-CALE 6I-N	Sensor de temperatura
14.5	931775	R14.5-CALE 6I-N	Válvula para agua
14.6	931776	R14.6-CALE 6I-N	Soporte para agua
15	931777	R15-CALE 6I-N	Tornillo M5
16	931778	R16-CALE 6I-N	Tornillo M4x112
17	931779	R17-CALE 6I-N	Ensamble modulo de enc. eléctrico
18	931780	R18-CALE 6I-N	Soporte para modulo
19	931781	R19-CALE 6I-N	Tornillo M5
20	931782	R20-CALE 6I-N	Soporte de salida de agua
21	931783	R21-CALE 6I-N	Tornillo St 4.2x8
22	931784	R22-CALE 6I-N	Panel trasero
23	931785	R23-CALE 6I-N	Tornillo St 4.2x8
24	931786	R24-CALE 6I-N	Soporte para caja de baterías
25	931787	R25-CALE 6I-N	Caja de baterías
26	931788	R26-CALE 6I-N	Sensor de temperatura
27	931789	R27-CALE 6I-N	Tornillo St3x6
28	931790	R28-CALE 6I-N	Sensor de temperatura 70°C
29	931789	R29-CALE 6I-N	Tornillo St3x6
30	931791	R30-CALE 6I-N	Sensor de temperatura 45°C
31	931792	R31-CALE 6I-N	Serpentin
32	931793	R32-CALE 6I-N	Tornillo St4.2x8
33	931794	R33-CALE 6I-N	Chimenea
34	931789	R34-CALE 6I-N	Tornillo St3x6
35	931795	R35-CALE 6I-N	Sensor de temperatura 90°C

