






















































Read this manual thoroughly before using the tool.



**CAUTION**

BOAP-1/2A2  
BOAP-3/4A2  
BOAP-1A2



Code	Models
12114	BOAP-1A2
12113	BOAP-3/4A2
12111	BOAP-1/2A2

Applies for:

# Manual Peripheral pump

