

### Especificaciones

4.5 V c.c. Emplea 3 pilas tipo AAA de 1.5 V c.c. cada una (no incluidas.)  
Distancia: 14 m  
LED: 3W COB (no reemplazable)

### Duración:

Bajo 7.5 h Alto 6.5 h  
Flujo luminoso: 40 lm Flujo luminoso: 100 lm

### Instrucciones importantes de seguridad

1. Antes de usar el producto, lea atentamente las instrucciones.
2. Conserve estas instrucciones para referencias futuras.
3. No hay piezas reparables por el usuario en el interior. No desarme.
4. Este producto está destinado únicamente para uso doméstico y no está diseñado para uso comercial o industrial.
5. ¡Este producto no es un juguete! Mantenga el producto fuera del alcance de los niños.
6. No sumerja en agua.
7. La luz LED es muy brillante. Evite el contacto directo con el haz de luz y evite apuntar la luz hacia otras personas.
8. No permita que entre agua en el dispositivo durante la limpieza.

9. La fuente de luz de esta luminaria no es reemplazable. Cuando la bombilla llegue al final de su vida útil, se debe reemplazar toda la luminaria.

### Instrucciones de funcionamiento

#### **ADVERTENCIA: LA LUZ LED ES MUY BRILLANTE. EVITE EL CONTACTO DIRECTO CON EL HAZ DE LUZ Y NO APUNTE LA LUZ A OTRAS PERSONAS**

1. Coloque las correas alrededor de su cabeza y ajuste las hebillas para un acomodo adecuado.
2. Presione el interruptor para encender la luz LED. Presione el interruptor varias veces para cambiar entre los modos disponibles:  
Alto/Bajo/Intermitente/Apagado.
3. Empuje la cabeza de la lámpara hacia abajo (hasta 30°) para ajustar el ángulo de iluminación.

### **⚠ ATENCIÓN**

No abra la batería, no la exponga al fuego, no las mezcle con pilas de otro tipo y no las ponga en cortocircuito (pueden encenderse, explotar, experimentar fugas o calentarse causando daños y/o lesiones). En caso de ingestión consulte a su médico.

**Garantía.** Duración: 1 año. Cobertura: piezas, componentes y mano de obra contra defectos de fabricación o funcionamiento, excepto si se usó en condiciones distintas a las normales; cuando no fue operado conforme instructivo; fue alterado o reparado por personal no autorizado por Truper®. Para hacer efectiva la garantía presente el producto, póliza sellada o factura o recibo o comprobante, en el establecimiento donde lo compró o en Corregidora 35, Centro, Cuauhtémoc, CDMX, 06060, donde también podrá adquirir partes, componentes, consumibles y accesorios. Incluye los gastos de transportación del producto que deriven de su cumplimiento de su red de servicio. Tel. **800-018-7873**. Made in/Hecho en China. Importador **Truper, S.A. de C.V.** Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Tel. 761 782 9100. **www.truper.com**

Sello del establecimiento comercial  
Fecha de entrega:

## Specifications

4.5 V DC Battery: 3x1.5V DC AAA batteries  
(not included)  
Distance: 46 ft  
LED: 3W COB (not replaceable)

## Runtime:

Low 7.5 h                      High 6.5 h  
Luminous flux: 40 lm      Luminous flux: 100 lm

## Important safety instructions

1. Read all the instructions carefully before using
2. Save these instructions for later use.
3. No user-serviceable parts inside. Do not disassemble.
4. This product is intended for domestic use only and is not designed for commercial, industrial or trade use.
5. This product is not a toy! Keep the product out of reach of children.
6. Do not submerge in water.
7. The LED light is very bright. Avoid direct eye contact with the light beam and avoid pointing the light at others.
8. Do not allow water to enter the unit during cleaning.
9. The light source in this luminaire is not replaceable. When the light source reaches the end of its life, the entire luminaire should be replaced.

## Operating instructions.

**WARNING: THE LED LIGHT IS VERY BRIGHT. AVOID DIRECT EYE CONTACT WITH THE LIGHT BEAM AND AVOID POINTING THE LIGHT AT OTHERS.**

1. Place the straps around your head and then adjust the buckles for a comfortable fit.
2. Press the Power/Mode Switch to turn the LED light on. Press the switch several times to cycle through the available modes:  
High/Low/Flashing/Off.
3. Adjust the lightning angle by pulling the lamp head down (up to 30°).

## ⚠ CAUTION

Do not open the battery, do not expose to the fire, do not mix battery types and do not short-circuit (batteries could ignite, explode, leak or overheat causing damages or injuries). In case of ingestion call a doctor.

**Warranty.** Duration: 1 year. Coverage: parts, components and workmanship against manufacturing or operating defects, except if used under conditions other than normal; when it was not operated in accordance with the instructive; was altered or repaired by personnel not authorized by Truper®. To make the warranty valid, present the product, stamped policy or invoice or receipt or voucher, in the establishment where you bought it or in Corregidora 35, Centro, Cuauhtémoc, CDMX, 06060, where you can also purchase parts, components, consumables and accessories. It includes the costs of transportation of the product that derive from its fulfillment of its service network. Phone number **800-018-7873**. Made in China. Imported by **Truper, S.A. de C.V.** Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Phone number 761 782 9100. **www.truper.com**

Stamp of the business. Delivery date:

09-2023