


CMA-4C

Código: 43351

INSTRUCTIVO

Lea las instrucciones antes de usar su candado.

- Para ajustar a una combinación personal:
La combinación ha sido preestablecida a 0-0-0.
 1. Marque la combinación que tenga en este momento.
 2. Oprima el botón pequeño que se encuentra en la parte derecha del candado (ver Fig.1).
 3. Con el botón oprimido, marque la combinación deseada.
 4. Suelte el botón y mueva las ruedas para asegurar el cierre.
 5. Anote su nueva combinación en un lugar seguro.



INSTRUCTIVE

Before use read the instructions.

- Directions for setting combination padlock:
Combination is preset to 0-0-0.
 1. Set dials to your preset combination.
 2. Push the small button situated on the right side of the padlock (see Fig.1).
 3. Set the dials to your desired combination while pushing de button.
 4. Release the button and scramble wheels to lock.
 5. Keep a record of your new combination in a safe place.

⚠ ATENCIÓN Manténgase fuera del alcance de los niños.

⚠ CAUTION Keep out of reach of children.