

46245

AD-RP

ESPECIFICACIONES

127 V~ 60 Hz 15 A

INSTRUCCIONES

LEA ANTES DE INSTALAR:

1. Conectar el adaptador a la red eléctrica.
2. Conectar el aparato, cuidando de no exceder la corriente indicada.

Para uso en interiores y lugares secos.

MANTENIMIENTO:

Limpie periódicamente con un trapo seco.


⚠ PRECAUCIÓN Para reducir el riesgo de choque eléctrico de las partes vivas expuestas, no se utilice con aparatos previstos con portalámparas o una salida eléctrica. Para reducir el riesgo de fuego o choque eléctrico, quitar el adaptador de viaje y la clavija del receptáculo cuando no se use.

⚠ ADVERTENCIA

Antes de instalar, interrumpa el paso de energía mediante el interruptor de circuito o fusible. Asegúrese que el circuito no esté energizado y que el área esté libre de humedad antes de iniciar la instalación. No sobrepase la corriente indicada. Mantenga la bolsa de plástico fuera del alcance de bebés y niños para prevenir cualquier riesgo de asfixia.

⚠ WARNING

Before installing, interrupt the passage of energy through the circuit breaker or fuse. Make sure that the circuit is not energized and that the area is dry before starting the installation. Do not exceed the indicated current. Maintain plastic bag out of reach of babies and children to avoid risk of suffocation.



7 506240 635109

07-2022