

Selladora de impulso


INSTRUCTIVO

Esta selladora de impulso es ideal para sellar bolsas de PE y PP, lo que la hace adecuada para empacar una amplia gama de productos, como mercancías generales, papelería, productos farmacéuticos y mucho más.

⚠ ATENCIÓN

- Evite usar un paño húmedo para limpiar la plataforma de sellado.
- Si la tela de teflón se desgasta, puede causar un cortocircuito en la máquina y dañar la resistencia. Por lo tanto, al reemplazar la resistencia, siempre inspeccione la tela de teflón y reemplácela por una nueva si muestra signos de desgaste.
- Al reemplazar un nuevo cable termoelectrónico, asegúrese de utilizar una equivalente a la original.
- Por favor, examine el tapón del mango después de un uso prolongado. La efectividad del sellado podría verse afectada si el tapón está desgastado.

- A) Mango de presión
B) Brazo de sellado
C) Base
D) Resistencia
E) Luz indicadora de trabajo
F) Perilla de temporizador
G) Banda de teflón



	SETE-30	SETE-20
Tensión	127 V~	127 V~
Potencia	400 W	300 W
Frecuencia	60 Hz	60 Hz
Corriente	3.3 A	3 A
Tiempo de sellado:	1 s - 4 s	

Uso

Este dispositivo no tiene un botón para encender y apagar.

1. Coloque una bolsa de plástico en la plataforma de sellado, enchufe el cable y ajuste la duración del tiempo de calentamiento según el grosor del material a sellar.
2. Presione la manija hacia abajo. El circuito electrónico desconectará automáticamente la alimentación eléctrica y controlará la duración del calor.
3. Retire la manija después de 1 segundo - 2 segundos y obtenga un sellado perfecto.
4. Deje enfriar la resistencia 30 segundos entre sellado y sellado para prolongar su tiempo de vida.

⚠ ADVERTENCIA

- Es posible que un exceso de exposición al calor cause que el sellado falle. Por favor, acorte el período de calentamiento si esto ocurriera.
- Si el sellado está flojo, es posible que el período de calentamiento haya sido demasiado corto. Por favor, ajuste la duración para que sea más larga.
- Si la bolsa de plástico se adhiere o se jala hacia el mango, es posible que no haya tenido suficiente tiempo para enfriarse. Permita que se enfríe por más tiempo después de que la luz se apague (por favor, mantenga la manija presionada durante un breve período).
- Una vez que haya ajustado la duración del tiempo de calentamiento, no es necesario volver a configurarla para cada operación de sellado posterior. Sin embargo, es importante mantener el proceso de sellado incluso después de que la luz indicadora se apague y el brazo de la platina regrese.
- Mantenga siempre el cable de corriente alterna enchufado, este no consumirá energía cuando no esté en uso.

Nota: Revise antes de cada uso la resistencia y las bandas Teflon. Reemplace cualquier componente dañado. Para evitar la oxidación de cualquier residuo en la plataforma de sellado, manténgala siempre limpia. La vida útil de la resistencia y de la cinta de teflón pueden acortarse debido a este residuo.

Garantía. Duración: 1 año. Cobertura: piezas, componentes y mano de obra contra defectos de fabricación o funcionamiento, excepto si se usó en condiciones distintas a las normales; cuando no fue operado conforme instructivo; fue alterado o reparado por personal no autorizado por TRUPER®. Para hacer efectiva la garantía presente el producto, póliza sellada o factura o recibo o comprobante, en el establecimiento donde lo compró o en Corregidora 35, Centro, Cuauhtémoc, CDMX, 06060, donde también podrá adquirir partes, componentes, consumibles y accesorios. Incluye los gastos de transportación del producto que deriven de su cumplimiento de su red de servicio. Tel. 800-018-7873. Made in/Hecho en China. Importador Truper, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Tel. 761 782 9100.



Sello del establecimiento comercial.
Fecha de entrega:

Impulse sealer

MANUAL

Applies for:


Codes	Models
103220	SETE-30
103189	SETE-20

This impulse sealer is ideal for sealing PE and PP bags, making it suitable for packaging a wide range of items including general merchandise, stationery, pharmaceuticals, and more.

⚠ ATTENTION

- Avoid using a wet cloth to clean the sealing platform.
- If the bottom cloth becomes worn, it can cause a short circuit in the machine and damage the heating element. Therefore, when replacing the heating element, always inspect the bottom cloth, and replace it with a new one if it shows signs of wear.
- When replacing a new thermo-electric wire, make sure to use a specification that is equivalent to the original.
- Please examine the handle rubber after extended use. The effectiveness of the sealing may suffer if the rubber is worn.

- A) Handle
B) Platen arm
C) Enclosure
D) Heating element
E) Indicator light
F) Timer knob
G) Heat-resistant cloth



	SETE-30	SETE-20
Voltage	127 V~	127 V~
Power	400 W	300 W
Frecuency	60 Hz	60 Hz
Current	3.3 A	3 A
Sealing time:	1 s - 4 s	

Operation

There is no power switch on this device.

1. Put a plastic bag on the sealing platform, plug the cord into the socket, set the heat time length based on the thickness of the materials to be sealed.
2. Depress the handle. The electronic circuit will automatically regulate the heat duration and turn off the light (automatically disconnecting the power).
3. Release the handle after 1-2 seconds, and the ideal seal will be made.
4. Let the resistor cool down for 30 seconds between sealing steps to increase its longevity.

⚠ WARNING

- It's possible that too much heat exposure caused the seal to fail or get compromised. Please shorten the heating period.
- If the seal is loose, the heat period may have been too brief. Please change the duration to be longer.
- If the plastic bag pulls or adheres to the rubber handle, it may not have had enough time to cool. Allow more time for cooling after the light turns off (please keep the handle down for a brief period).
- Once you have adjusted the heat time duration, there is no need to readjust it for each subsequent sealing operation. However, it's important to keep the sealing process even after the indicator light goes off and the platen arm returns.
- Please keep the AC cord always plugged into the socket; it will not consume any power when not in use.

Note: Before each use, check the teflon bands and resistor. Any damaged parts should be replaced. To avoid the oxidation of any residue on the sealing platform, always keep the platform clean. The lifespan of the heating element and the heat-resistant cloth may both be shortened by this residue.

Warranty. Duration: 1 year. Coverage: parts, components and workmanship against manufacturing or operating defects, except if used under conditions other than normal; when it was not operated in accordance with the instructive; was altered or repaired by personnel not authorized by TRUPER®. To make the warranty valid, present the product, stamped policy or invoice or receipt or voucher, in the establishment where you bought it or in Corregidora 35, Centro, Cuauhtémoc, CDMX, 06060, where you can also purchase parts, components, consumables and accessories. It includes the costs of transportation of the product that derive from its fulfillment of its service network. Phone number 800-018-7873. Made in China. Imported by Truper, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Phone number 761 782 9100.



Stamp of the business. Delivery date: