

46542
POBS-10

ESPECIFICACIONES

125 V~ 60 Hz 4 A

▲ ADVERTENCIA

Revise que el cable que va a utilizar no este dañado. Use calibre adecuado para la corriente indicada.

INSTRUCCIONES

LEA ANTES DE INSTALAR:

1. Desenrosque la parte superior del portalámpara.
2. Pase el cable a través del orificio de la tapa.
3. Quite el aislante de las puntas de cada conductor para exponer 19 mm de éste. Si usa cable, tuerza los alambres para prevenir hilos sueltos.
4. Enrosque los cables en los tornillos de las terminales y apriete firmemente.
5. Enrosque la parte superior al portalámpara.
6. Vuelva a conectar la corriente eléctrica.

▲ ADVERTENCIA

Antes de instalar, interrumpa el paso de energía mediante el interruptor de circuito o fusible. Asegúrese que el circuito no esté energizado y que el área esté libre de humedad antes de iniciar la instalación. No sobrepase la corriente indicada. Mantenga la bolsa de plástico fuera del alcance de bebés y niños para prevenir cualquier riesgo de asfixia.

▲ WARNING

Before installing, interrupt the passage of energy through the circuit breaker or fuse. Make sure that the circuit is not energized and that the area is dry before starting the installation. Do not exceed the indicated current. Maintain plastic bag out of reach of babies and children to avoid risk of suffocation.

10-2021



7 506240 618195