



Portalámpara con sensor de movimiento

LEA LAS SIGUIENTES INSTRUCCIONES DE USO CUIDADOSAMENTE ANTES DE INSTALAR.

El producto adopta un buen detector de sensibilidad, circuito integrado. Es automática, ofrece seguridad conveniente, ahorro de energía y funciones prácticas. Utiliza la energía infrarroja de los humanos como fuente de señal de control, puede iniciar la carga de inmediato cuando se entra en el campo de detección. Puede identificar el día y la noche automáticamente. Es fácil de instalar y se utiliza ampliamente.


INSTALACIÓN

Fije el soporte en el lugar donde quiera instalarlo según la figura de la derecha.

Después de la instalación del sensor, conectelo con la lámpara, entonces se podrá probar.

PRUEBA

- 1-Después de la instalación, gire la perilla de LUX al máximo en sentido de las manecillas del reloj (★). Gire la perilla de tiempo en sentido contrario a las manecillas del reloj hasta el mínimo (-).
- 2-Encienda la electricidad, el sensor se va a electrificar y se calentará. 30 s después, el dispositivo se habilita en el estado de funcionamiento. Luego de la detección, la carga debe funcionar 5 s ~ 10 s después de que la luz se apague por primera vez.
- 3-Gire la perilla de LUX en sentido contrario a las manecillas del reloj hacia el mínimo. Si se prueba bajo circunstancias por debajo de 3 LUX, la carga no debería funcionar después de que la carga de inducción deje de funcionar; pero si se cubre la ventana de detección con objetos opacos (toalla, etc.), la carga funciona. Bajo la condición de que no haya señales de inducción, la carga debería dejar de funcionar en 5 s ~ 15 s



ESPECIFICACIONES

120 V~ 60 Hz 60 W (máx.)

Rango de detección: 0° - 360°

Distancia de detección: 6 m

Tiempo de retardo: Min. 8 s ± 3 s

Ambient light: Max. 5 min ± 1 min

3 lux - 2000 lux (ajustable)

Altura de instalación: 2 m a 3.5 m

Temperatura de trabajo: -20 °C a 40 °C

NOTA: Al hacer pruebas con luz de día, gire la perilla LUX a la posición (★), de lo contrario el sensor de la lámpara puede no funcionar.

Instructivo



ADVERTENCIA

Antes de instalar, interrumpa el paso de energía mediante el interruptor de circuito o fusible. Asegúrese que el circuito no esté energizado y que el área esté libre de humedad antes de iniciar la instalación. No se instale cerca de fuentes de calor o frío para no afectar el funcionamiento del sensor. No se use para controlar aparatos operados por motor o que no sean para iluminación.

Garantía: Duración: 1 año. Cobertura: piezas, componentes y mano de obra contra defectos de fabricación o funcionamiento, excepto si se usó en condiciones distintas a las normales; cuando no fue operado conforme a instructivo; fue alterado o reparado por personal no autorizado por Truper®. Para hacer efectiva la garantía presente el producto, poliza sellada o factura o recibo o comprobante, en el establecimiento donde lo compró o en Corregidora 22, Centro, Cuauhtémoc, CDMX, 06060, donde también podrá adquirir partes, componentes, consumibles y accesorios. Incluye los gastos de transportación del producto que deriven de su cumplimiento de su red de servicio. Tel. 800-018-7873. Hecho en China. Importado por Truper, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Tel. 761 782 9100.

Sello del establecimiento comercial.

Fecha de entrega:

09-2020 AD



Motion sensor lamp holder

READ THE FOLLOWING INSTRUCTIONS FOR USE CAREFULLY BEFORE INSTALLING.

The product adopts good sensitivity detector, integrated circuit. It gathers automatism, convenient safe, saving-energy and practical functions. It utilizes the infrared energy from human as control-signal source, it can start the load at once when one enters detection field. It can identify day and night automatically. It is easy to install and used widely.


INSTALLATION

Fix the holder in the place where you will want to install according to right figure.

After installation of the sensor, connect with lamp, then you could test it.

TEST

- 1-After installation, Turned LUX knob clockwise to the maximum (★). Turned time knob anti-clockwise to the minimum (-).
- 2-Turn on the power, the sensor will be electrify and warm-up, 30 sec later, the item will be entered into working estate, 5 sec ~ 10 sec after the light goes out for the first time and then sensing, the load should be worked.
- 3-Turns LUX knob anti-clockwise to the minimum. If it is tested under the circumstance below 3 LUX, load should not work after induction load stop working; but if you cover the detection window with opaque objects (towel etc), the load works. Under the condition of no induction signals, the load should stop working within 5 sec - 15 sec.



TECHNICAL PARAMETER

120 V~ 60 Hz 60 W (max.)

Detection range: 0° - 360°

Detection distance: 6 m

Time delay: Min. 8 s ± 3 s

Ambient light: Max. 5 min ± 1 min

3 lux - 2000 lux (adjustable)

Installation height: 2 m to 3.5 m

Working temperature: -20 °C to 40 °C

NOTE: when testing in daylight, please turn LUX knob to (★) position, otherwise the sensor lamp may not work

Instructive



WARNING

Before installing, interrupt the power supply using the circuit breaker or fuse. Make sure the circuit is not energized and the area is free of moisture before beginning installation. Do not install near heat or cold sources so as not to affect the operation of the sensor. Not used to control motor-operated or non-lighting appliances.

Warranty: Duration: 1 year. Coverage: parts, components and workmanship against manufacturing or operating defects, except if used under conditions other than normal; when it was not operated in accordance with the instructive; was altered or repaired by personnel not authorized by Truper®. To make the warranty valid, present the product, stamped policy or invoice or receipt or voucher, in the establishment where you bought it or in Corregidora 22, Centro, Cuauhtémoc, CDMX, 06060, where you can also purchase parts, components, consumables and accessories. Includes the costs of transportation of the product that derive from its fulfillment of its service network. Phone number 800-018-7873. Made in China. Imported by Truper, S.A. de C.V. Parque Industrial 1, Parque Industrial Jilotepec, Jilotepec, Edo. de Méx. C.P. 54257, Phone number 761 782 9100.

Stamp of the business.
Delivery date:

09-2020 AD

